

SALTER

PERSONAL SCALES

Instructions and Guarantee



Register your product today at
www.homedicsgroup.com/register

GB

NEW FEATURE! This scale features our convenient step-on operation. Once initialised the scale can be operated by simply stepping straight on the platform – no more waiting!

PREPARING YOUR SCALE 1. Open the battery compartment on the scale underside. 2. Remove isolating tab from beneath the battery (if fitted) or insert batteries observing the polarity signs (+ and -) inside the battery compartment. 3. Close the battery compartment. 4. Select kg, st or lb weight mode by the switch on the underside of the scale. 5. For use on carpet attach enclosed carpet feet. 6. Position scale on a firm flat surface.

INITIALISING YOUR SCALE 1. Press the platform centre and remove your foot. 2. '0.0' will be displayed. 3. The scale will switch off and is now ready for use.

This initialisation process must be repeated if the scale is moved.

At all other times step straight on the scale.

OPERATING YOUR SCALE 1. Step on and stand very still while the scale computes your weight. 2. Your weight is displayed. 3. Step off. Your weight will be displayed for a few seconds. 4. The scale will switch off.

WARNING INDICATORS

---- Weight exceeds maximum capacity.


Lo Replace battery.


Err Unstable weight. Stand still.

0Err Incorrect zero. Repeat initialising your scale.

ADVICE FOR USE AND CARE Always weigh yourself on the same scale placed on the same floor surface. Do not compare weight readings from one scale to another as some differences will exist due to manufacturing tolerances • Placing your scale on a hard, even floor will ensure the greatest accuracy and repeatability • Weigh yourself at the same time each day, before meals and without footwear. First thing in the morning is a good time • Your scale rounds up or down to the nearest increment. If you weigh yourself twice and get two different readings, your weight lies between the two • Clean your scale with a damp cloth. Do not use chemical cleaning agents • Do not allow your scale to become saturated with water as this can damage the electronics • Treat your scale with care – it is a precision instrument. Do not drop it or jump on it • **Caution:** the platform may become slippery when wet.

TROUBLESHOOTING GUIDE If you experience any difficulty in the use of your scale: • Check the battery is correctly fitted • Check that you have selected your preference of stones/pounds, kilograms or pounds • Check that the scale is on a flat, level floor and not touching against a wall • Repeat the 'Initialisation' procedure every time the scale is moved • If when you use the scale there is no display at all or if 'Lo' is displayed – try a new battery • If '----' is displayed the scale has been overloaded.

 **WEEE EXPLANATION** This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

 **BATTERY DIRECTIVE** This symbol indicates that batteries must not be disposed of in the domestic waste as they contain substances which can be damaging to the environment and health. Please dispose of batteries in designated collection points.

GUARANTEE This product is intended for domestic use only. Salter will repair or replace the product, or any part of this product, free of charge if within 15 years of the date of purchase, it can be shown to have failed through defective workmanship or materials. This guarantee covers working parts that affect the function of the scale. It does not cover cosmetic deterioration caused by fair wear and tear or damage caused by accident or misuse. Opening or taking apart the scale or its components will void the guarantee. Claims under guarantee must be supported by proof of purchase and be returned carriage paid to Salter (or local Salter appointed agent if outside the UK). Care should be taken in packing the scale so that it is not damaged while in transit. This undertaking is in addition to a consumer's statutory rights and does not affect those rights in any way. For UK Sales and Service contact HoMedics Group Ltd, HoMedics House, Somerhill Business Park, Five Oak Green Road, Tonbridge, Kent TN11 0GP, UK. Helpline Tel No: (01732) 360783. For Ireland, please contact Petra Brand Masters, Unit J4 Maynooth Business Campus, Maynooth, Co. Kildare, Ireland. Tel +00 353 (0) 1 6510660. e-mail sales@petrabrandmasters.ie. www.salterhousewares.com/servicecentres

GB ELECTROMAGNETIC COMPATIBILITY

This product is intended for domestic use.

ADVICE TO THE USER This product is a sensitive electronic instrument and as such may temporarily be affected by Radio Transmitting Devices being used in close proximity to it (such as Mobile Phones, Walkie Talkies, CB Radios, Radio Model Controllers, and some Microwave Ovens, etc.) Additionally, extreme levels of Electrostatic Interference may cause this product to temporarily malfunction. In such case it may be necessary to remove and re-install the battery to re-establish normal working. If the problem persists then contact your local agent.



SALTER

HoMedics Group Ltd

Homedics House, Somerhill Business Park
Five Oak Green Road, Tonbridge,
Kent TN11 0GP
www.salterhousewares.co.uk

IB-9099GB-0316-02