


# Atlas - Bedside

Assembly Instructions - Please keep for future reference

145/3900

166/2533

159/7206



## Dimensions

Width - 47.5cm

Depth - 40cm

Height - 48cm



**MADE IN  
BRITAIN**

**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



# Safety and Care Advice

**Important - Please read these instructions fully before starting assembly**

- **Warning:** This unit weighs approximately 13.5kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings (not supplied).

- Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

**Note:** If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


# Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the panels listed below




**1** Left Side (D2380A)  
(461 x 395mm)



**2** Right Side (D2381A)  
(461 x 395mm)




**3** Top (D2379A)  
(473 x 396mm)




**4** Rail (D2382A)  
(441 x 60mm) x 2




**5** Small Drawer Front (D2388A)  
(475 x 189mm)




**6** Large Drawer Front (D2383A)  
(475 x 264mm)



**7** Small Left Drawer Side (W370-124LH)  
(370 x 124mm)



**8** Small Right Drawer Side (W370-124RH)  
(370 x 124mm)



**9** Small Wrap Back (W391-124)  
(391 x 124mm)



**10** Large Left Drawer Side (W370-165LH)  
(370 x 165mm)




**11** Large Right Drawer Side (W370-165RH)  
(370 x 165mm)



**12** Large Wrap Back (W391-165)  
(391 x 165mm)



**13** Drawer Base (T402-367)  
(402 x 367mm) x 2



**14** Back (X453-467)  
(453 x 467mm)



















# Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p><b>A</b> </p> <p>Wooden dowel (F22) x 6</p>	<p><b>B</b> </p> <p>Metal dowel (F901) x 12</p>	<p><b>C</b> </p> <p>Large locking nut (F900) x 8</p>
<p><b>D</b> </p> <p>Small locking nut (F3) x 4</p>	<p><b>E</b> </p> <p>19mm Screw (F461) x 4</p>	<p><b>F</b> </p> <p>13mm Screw (F52) x 12</p>
<p><b>G</b> </p> <p>13mm Screw (F63) x 12</p>	<p><b>H</b> </p> <p>Nail (F51) x 13</p>	<p><b>I</b> </p> <p>Knock-in Peg (F171) x 8</p>
<p><b>J a</b>  L Runner (F159) x 2  <span style="margin-left: 40px;">← 350mm long →</span></p> <p><b>J b</b>  R Runner (F160) x 2</p> <p><b>J c</b>  L Runner (F161) x 2</p> <p><b>J d</b>  R Runner (F162) x 2</p>		<p><b>K</b>  304mm            Handle (F266) x 2</p> <p><b>L</b>  Wedgefix (F639) x 8</p>
<p><b>M</b> </p> <p>Plastic Nail (F91) x 4</p>		

## Tools required



Rule



Cross-head screwdriver



Scissors




Hammer



Eye protection (when using a hammer or drill)

Ruler - Use this ruler to help correctly identify the screws



# Assembly Instructions


If you have damaged or missing components, call the  
**Customer Helpline: 08456 400800** quoting the reference  
numbers below

## Step 1

### Prepare the small drawer front

Screw 2 metal dowels **B** into the holes shown on the back of the small drawer front **5**.

**Note:** Tighten the metal dowels up fully against the panels.




## Step 2

### Prepare the small drawer sides

Insert a small locking nut **D** into the hole shown on the small left drawer side **7** and small right drawer side **8**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.

**Note:** Due to the manufacturing process, the holes for the locking nut can be on either surface of the drawer sides.



## Step 3


### Attach the drawer sides to the drawer front

Push the small left drawer side **7** and small right drawer side **8** onto the back of the small drawer front **5**.

Turn the small locking nuts **D** on the small left drawer side **7** and small right drawer side **8**.

**Note:** Turn the locking nuts **D** clockwise to secure panels - more than 1/2 a turn.

**Note:** The locking nuts can be on either surface of the drawer sides. Make sure that the groove is on the inside, as shown.




# Assembly Instructions

## Step 4

### Fit the drawer base

Slide the drawer base **13** down the grooves in the small drawer sides **7** and **8** and down into the groove in the small drawer front **5**.




## Step 5

### Fit the small drawer back

Fit the small drawer back **9** between the small drawer sides **7** and **8**.

Make sure that the drawer base **13** fits into the groove in the small drawer back **9**.


Hold the small drawer back **9** in position and tap the knock-in pegs **I** through the holes in the small drawer sides **7** and **8**.



## Step 6

### Attach the handle

Attach a handle **K** to the small drawer front **5** using 2 screws **E**.





# Assembly Instructions

## Step 7

### Fit 4 wedgexes

Turn the drawer over.

Slide 4 wedgexes **L** into the small grooves on the drawer assembly and tighten up the screws.



## Step 8


### Fit runners to the small drawer

Turn the small drawer assembly over.

Fit runner **Jd**, marked with 'R', to the bottom edge of the small right drawer side **8**, as shown, making sure that it is pushed up against the back of the small drawer front **5**. Use a bradawl to mark the fixing positions, then secure with 2 screws **G**.

Fit runner **Jc**, marked 'L', to the bottom edge of the small left drawer side **7** using the same method.

Runners must be pushed up against the drawer front




## Step 9

### Prepare the large drawer front

Screw 2 metal dowels **B** into the holes shown on the back of the large drawer front **6**.

**Note:** Tighten the metal dowels up fully against the panels.




# Assembly Instructions

## Step 10

### Prepare the large drawer sides

Insert a small locking nut **D** into the hole shown on the large left drawer side **10** and large right drawer side **11**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.



## Step 11


### Attach the drawer sides to the drawer front

Push the large left drawer side **10** and large right drawer side **11** onto the back of the large drawer front **6**.

Turn the small locking nuts **D** on the large left drawer side **10** and large right drawer side **11**.

**Note:** Turn the locking nuts **D** clockwise to secure panels - more than 1/2 a turn.


**Note:** The locking nuts can be on either surface of the drawer sides. Make sure that the groove is on the inside, as shown.



## Step 12

### Fit the drawer base

Slide the drawer base **13** down the grooves in the large drawer sides **10** and **11** and down into the groove in the large drawer front **6**.





# Assembly Instructions


## Step 13

### Fit the large drawer back

Fit the large drawer back **12** between the large drawer sides **10** and **11**.

Make sure that the drawer base **13** fits into the groove in the large drawer back **12**.


Hold the large drawer back **12** in position and tap the knock-in pegs **I** through the holes in the large drawer sides **10** and **11**.



## Step 14

### Attach the handle

Attach a handle **K** to the large drawer front **6** using 2 screws **E**.





## Step 15

### Fit 4 wedgexes

Turn the drawer over.

Slide 4 wedgexes **L** into the small grooves on the drawer assembly and tighten up the screws.



# Assembly Instructions


## Step 16

### Fit runners to the large drawer

Turn the large drawer assembly over.

Fit runner **Jd**, marked with 'R', to the bottom edge of the large right drawer side **11**, as shown, making sure that it is pushed up against the back of the large drawer front **6**. Use a bradawl to mark the fixing positions, then secure with 2 screws **G**.


Fit runner **Jc**, marked 'L', to the bottom edge of the large left drawer side **10** using the same method.



## Step 17

### Prepare the top

Screw 4 metal dowels **B** into the top **3**.



# Assembly Instructions

## Step 18

### Prepare the left side

**a:** Fit runner **Ja** to the left side **1**.

The 1st screw **F** uses the 2nd hole in from the front of the runner.

The 2nd and 3rd screws **F** use the holes that line up with the other panel holes.

**b:** Fit a screw **G** into the 2nd hole in at the top of the runner **Ja**.





Screw 2 metal dowels **B** into the left side **1**.

Insert 2 large locking nuts **C** into the left side **1**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.

Tap a wooden dowel **A** into the left side **1**.

**Note:** Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.



# Assembly Instructions

## Step 19

### Prepare the right side

**a:** Fit runner **Jb** to the right side **2**.

The 1st screw **F** uses the 2nd hole in from the front of the runner.


The 2nd and 3rd screws **F** use the holes that line up with the other panel holes.

**b:** Fit a screw **G** into the 2nd hole in at the top of the runner **Jb**.

Screw 2 metal dowels **B** into the right side **2**.

Insert 2 large locking nuts **C** into the right side **2**.

Tap a wooden dowel **A** into the right side **2**.




## Step 20

### Fit the top to the right side

Push the top **3** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the right side **2**.

**Note:** Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




# Assembly Instructions

## Step 21

### Prepare the 2 rails

Tap 2 wooden dowels **A** into each of the 2 rails **4**.

Insert 2 large locking nuts **C** into each of the 2 rails **4**.




## Step 22

### Fit the 2 rails

Push the 2 rails **4** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the rails **4**.




## Step 23

### Fit the left side

Push the left side **1** onto the assembly.

Use a screwdriver to tighten the 4 large locking nuts **C** fitted to the left side **1** and the 2 rails **4**.






# Assembly Instructions

## Step 26

### Fit the drawers

Slide the wheels of the runners fitted to the drawers, over the wheels of the runners fitted to the side panels and push the drawers into position.

**Assembly is complete**



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW






# Atlas - 4 Drawer Chest

Assembly Instructions - Please keep for future reference

181/6815

146/7233

171/5129



## Dimensions

Width - 79.5cm

Depth - 41.5cm

Height - 86cm



**MADE IN  
BRITAIN**

**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



# Safety and Care Advice

**Important - Please read these instructions fully before starting assembly**

- **Warning:** This unit weighs approximately 31kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings (not supplied).

- Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

**Note:** If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


# Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below


Please check you have all the panels listed below



**1** Left Side (D2390A)  
(845 x 395mm)




**2** Right Side (D2391A)  
(845 x 395mm)




**3** Top (D2389A)  
(793 x 396mm)




**4** Rail (D2392A)  
(761 x 60mm) x 3




**5** Small Drawer Front (D2393A)  
(795 x 189mm) x 3




**6** Large Drawer Front (D2394A)  
(795 x 264mm)



**7** Small Left Drawer Side (W370-124LH)  
(370 x 124mm) x 3



**8** Small Right Drawer Side (W370-124RH)  
(370 x 124mm) x 3



**9** Small Wrap Back (W711-124)  
(711 x 124mm) x 3




**10** Large Left Drawer Side (W370-165LH)  
(370 x 165mm)



**11** Large Right Drawer Side (W370-165RH)  
(370 x 165mm)



**12** Large Wrap Back (W711-165)  
(711 x 165mm)



**13** Drawer Base (T722-367)  
(722 x 367mm) x 4



**14** Back (X836-787)  
(836 x 787mm)





















# Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p><b>A</b> </p> <p>Wooden dowel (F22) x 8</p>	<p><b>B</b> </p> <p>Metal dowel (F901) x 18</p>	<p><b>C</b> </p> <p>Large locking nut (F900) x 10</p>
<p><b>D</b> </p> <p>Small locking nut (F3) x 8</p>	<p><b>E</b> </p> <p>19mm Screw (F461) x 8</p>	<p><b>F</b> </p> <p>13mm Screw (F52) x 24</p>
<p><b>G</b> </p> <p>13mm Screw (F63) x 24</p>	<p><b>H</b> </p> <p>Nail (F51) x 22</p>	<p><b>I</b> </p> <p>Knock-in Peg (F171) x 16</p>
<p><b>J a</b>  L Runner (F159) x 4            ← 350mm long →</p> <p><b>J b</b>  R Runner (F160) x 4</p> <p><b>J c</b>  L Runner (F161) x 4</p> <p><b>J d</b>  R Runner (F162) x 4</p>		<p><b>K</b>  Handle (F227) x 4 623mm</p> <p><b>L</b>  Bracket (F327) x 1</p>
<p><b>M</b> </p> <p>13mm Screw (F79) x 1</p>	<p><b>N</b> </p> <p>Wedgefix (F639) x 16</p>	<p><b>O</b> </p> <p>Plastic Nail (F91) x 4</p>

## Tools required



Rule



Cross-head screwdriver



Scissors




Hammer



Eye protection  
(when using a hammer or drill)

Ruler - Use this ruler to help correctly identify the screws



# Assembly Instructions


If you have damaged or missing components, call the  
**Customer Helpline: 08456 400800** quoting the reference  
numbers below

## Step 1

### Prepare the small drawer fronts

Screw 2 metal dowels **B** into the holes shown on the back of each small drawer front **5**.

**Note:** Tighten the metal dowels up fully against the panels.




## Step 2

### Prepare the small drawer sides

Insert a small locking nut **D** into the hole shown on each small left drawer side **7** and small right drawer side **8**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.



## Step 3


### Attach the drawer sides to the drawer fronts

Push the small left drawer sides **7** and small right drawer sides **8** onto the back of the small drawer fronts **5**.

Turn the small locking nuts **D** on the small left drawer sides **7** and small right drawer sides **8**.

**Note:** Turn the locking nuts **D** clockwise to secure panels - more than 1/2 a turn.


**Note:** The locking nuts can be on either surface of the drawer sides. Make sure that the groove is on the inside, as shown.



## Step 4

### Fit the drawer bases

Slide the drawer base **13** down the grooves in the small drawer sides **7** and **8** and down into the groove in the small drawer fronts **5**.




## Step 5

### Fit the small drawer backs

Fit the small drawer back **9** between the small drawer sides **7** and **8**.

Make sure that the drawer base **13** fits into the groove in the small drawer back **9**.


Hold the small drawer back **9** in position and tap the knock-in pegs **1** through the holes in the small drawer sides **7** and **8**.



## Step 6

### Attach the handles

Attach handles **K** to the small drawer fronts **5** using 2 screws **E**.



# Assembly Instructions


## Step 7

### Fit runners to the small drawers

Turn the small drawer assemblies over.

Fit runner **Jd**, marked with 'R', to the bottom edge of the small right drawer side **8**, as shown, making sure that it is pushed up against the back of the small drawer front **5**. Use a bradawl to mark the fixing positions, then secure with 2 screws **G**.

Fit runner **Jc**, marked 'L', to the bottom edge of the small left drawer side **7** using the same method.




## Step 8

### Fit the wedgfixes

Slide 2 wedgfixes **N** into the small groove located on the back of the drawer front **5** and 2 into the small groove in the drawer back **9**.

Once in place, tighten up the screws in the wedgfixes **N**.




## Step 9

### Prepare the large drawer front

Screw 2 metal dowels **B** into the holes shown on the back of the large drawer front **6**.

**Note:** Tighten the metal dowels up fully against the panels.




# Assembly Instructions

## Step 10

### Prepare the large drawer sides

Insert a small locking nut **D** into the hole shown on the large left drawer side **10** and large right drawer side **11**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.



## Step 11


### Attach the drawer sides to the drawer front

Push the large left drawer side **10** and large right drawer side **11** onto the back of the large drawer front **6**.

Turn the small locking nuts **D** on the large left drawer side **10** and large right drawer side **11**.

**Note:** Turn the locking nuts **D** clockwise to secure panels - more than 1/2 a turn.


**Note:** The locking nuts can be on either surface of the drawer sides. Make sure that the groove is on the inside, as shown.



## Step 12

### Fit the drawer base

Slide the drawer base **13** down the grooves in the large drawer sides **10** and **11** and down into the groove in the large drawer front **6**.





# Assembly Instructions


## Step 13

### Fit the large drawer back

Fit the large drawer back **12** between the large drawer sides **10** and **11**.

Make sure that the drawer base **13** fits into the groove in the large drawer back **12**.


Hold the large drawer back **12** in position and tap the knock-in pegs **I** through the holes in the large drawer sides **10** and **11**.



## Step 14

### Attach the handle

Attach a handle **K** to the large drawer front **6** using 2 screws **E**.




## Step 15

### Fit runners to the large drawer

Turn the large drawer assembly over.

Fit runner **Jd**, marked with 'R', to the bottom edge of the large right drawer side **11**, as shown, making sure that it is pushed up against the back of the large drawer front **6**. Use a bradawl to mark the fixing positions, then secure with 2 screws **G**.

Fit runner **Jc**, marked 'L', to the bottom edge of the large left drawer side **10** using the same method.




# Assembly Instructions

## Step 16

### Fit the wedgexes

Slide 2 wedgexes **N** into the small groove located on the back of the drawer front **6** and 2 into the small groove in the drawer back **12**.

Once in place, tighten up the screws in the wedgexes **N**.



## Step 17


### Prepare the top

Screw 4 metal dowels **B** into the top **3**.

Fix a bracket **L** to the top **3**.

The bracket **L** must be flush against the back edge.

Secure the bracket **L** using screw **M**.



# Assembly Instructions

## Step 18

### Prepare the left side

**a:** Fit runner **Ja** to the left side **1**.

The 1st screw **F** uses the 2nd hole in from the front of the runner.

The 2nd and 3rd screws **F** use the holes that line up with the other panel holes.

**b:** Fit a screw **G** into the 2nd hole in at the top of the runner **Ja**.





Screw 3 metal dowels **B** into the left side **1**.

Insert 2 large locking nuts **C** into the left side **1**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.

Tap a wooden dowel **A** into the left side **1**.

**Note:** Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.



# Assembly Instructions

## Step 19

### Prepare the right side

**a:** Fit runner **Jb** to the right side **2**.

The 1st screw **F** uses the 2nd hole in from the front of the runner.





The 2nd and 3rd screws **F** use the holes that line up with the other panel holes.

**b:** Fit a screw **G** into the 2nd hole in at the top of the runner **Jb**.

Screw 3 metal dowels **B** into the right side **2**.

Insert 2 large locking nuts **C** into the right side **2**.

Tap a wooden dowel **A** into the right side **2**.



# Assembly Instructions


## Step 20

### Fit the top

Push the top **3** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the right side **2**.

**Note:** Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




## Step 21

### Prepare the 3 rails

Tap 2 wooden dowels **A** into each of the 3 rails **4**.

Insert 2 large locking nuts **C** into each of the 3 rails **4**.




## Step 22

### Fit the 3 rails

Push the 3 rails **4** onto the right side **2**.

Use a screwdriver to tighten the 3 large locking nuts **C** fitted to the rails **4**.




# Assembly Instructions

## Step 23

### Fit the left side

Push the left side **1** onto the assembly.

Use a screwdriver to tighten the 5 large locking nuts **C** fitted to the left side **1** and the 3 rails **4**.



## Step 24

### Fit the back

**a:** Square up the unit by making sure that measurement **x to x** equals **y to y**.


**b:** Place the back **14** onto the unit.

Nail **H** around the outside edges of the back **14**.

**Note:** Nails should be spaced about 150mm apart.

**Stand the unit up for the next step.**




**a:** The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




# Assembly Instructions

## Step 25


### Fit the 4 plastic nails

Tap 2 plastic nails  into the bottom edge of each of the sides  and .



## Step 26


### Secure unit to a wall

To prevent possible overbalancing we recommend that this unit is secured to a suitable wall by use of the metal bracket  fitted under the top plinth.

Fixings are not supplied as they will need to suit the wall type, and the length of screw will depend on the distance of the back of the unit to the wall.



**Warning:** Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.





# Assembly Instructions

## Step 27

### Fit the drawers

Slide the wheels of the runners fitted to the drawers, over the wheels of the runners fitted to the side panels and push the drawers into position.

### Assembly is complete



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW




# Atlas - Double Robe Carcass

Assembly Instructions - Please keep for future reference

157/3309

151/4739

152/7458



There is the option of purchasing an Internal 3 Drawer Chest that can be placed inside your Robe

## Dimensions

Width - 100cm

Depth - 59.5cm

Height - 212.5cm

## IMPORTANT

This unit **MUST** be fixed to a wall using both of the brackets supplied.



**MADE IN  
BRITAIN**

**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



# Safety and Care Advice

**Important - Please read these instructions fully before starting assembly**

- **Warning:** This unit weighs approximately 49kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the bracket supplied.

- Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

**Note:** If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


# Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the panels listed below



**1** Universal End (D2396A)  
(2074 x 591mm) x 2




**2** Top/Base (D2395A)  
(1000 x 592mm) x 2



**3** Fixed Shelf (D2397A)  
(968 x 590mm)



**4** Hanging Rail (FHR960)  
(960mm long) x 2



**5** Back (X2100-994)  
(2100 x 994mm)


















# Components - Fittings











If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below


**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p><b>A</b> </p> <p>Wooden dowel (F22) x 2</p>	<p><b>B</b> </p> <p>Metal dowel (F901) x 4</p>	<p><b>C</b> </p> <p>Large locking nut (F900) x 4</p>
<p><b>D</b> </p> <p>Nail (F51) x 40</p>	<p><b>E</b> </p> <p>Allen Key (F36) x 1</p>	<p><b>F</b> </p> <p>50mm Screw (F49) x 12</p>
<p><b>G</b> </p> <p>25mm Screw (F50) x 6</p>	<p><b>H</b> </p> <p>19mm Screw (F461) x 4</p>	<p><b>I</b> </p> <p>13mm Screw (F79) x 2</p>
<p><b>J</b> </p> <p>13mm Screw (F63) x 24</p>	<p><b>K</b> </p> <p>Rail Holder (F891) x 4</p>	<p><b>L</b> </p> <p>Bracket (F327) x 2</p>
<p><b>M</b> </p> <p>Feet (F854) x 6</p>	<p><b>N</b> </p> <p>Handle (F323) x 2</p>	<p><b>O</b> </p> <p>Hinge (F328) x 8</p>

## Tools required

<p></p> <p>Rule</p>	<p></p> <p>Spirit level</p>	<p></p> <p>Eye protection (when using a hammer or drill)</p>	<p></p> <p>Cross-head screwdriver</p>	<p></p> <p>Electric drill (only use when drilling into walls)</p>	<p></p> <p>Step ladder</p>
<p></p> <p>Square</p>	<p></p> <p>Scissors</p>	<p></p> <p>Hammer</p>	<p></p> <p>Bradawl</p>		

Ruler - Use this ruler to help correctly identify the screws




# Assembly Instructions


If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

## Step 1

**Are you fitting 1 or 2 hanging rails or, a shelf pack?**



If you are just fitting 1 hanging rail, the fixed shelf will need to go here. **Follow Steps 2 and 3.**



If you are fitting 2 hanging rails, the fixed shelf will need to go here. **Follow Step 4 and 5.**

## Step 2





### Prepare the left end

Refer to step 1 and, if you have chosen to fit 1 hanging rail, screw 2 metal dowels **B** into the left end **1**.

**Note:** Tighten the metal dowels up fully against the panels.

To fit the rail holder **K**, screw through its top hole with screw **J** and into the shallow mark hole drilled in the left end **1**. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **J** using the lower hole.

Only follow Steps 2 and 3 if you are just fitting 1 hanging rail. If you are fitting 2 hanging rails, follow Step 4 and 5.



# Assembly Instructions

## Step 3


### Prepare the right end

Refer to step 1 and, if you have chosen to fit 1 hanging rail, screw 2 metal dowels **B** into the right end **1**.

**Note:** Tighten the metal dowels up fully against the panels.

To fit the rail holder **K**, screw through its top hole with screw **J** and into the shallow mark hole drilled in the right end **1**. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **J** using the lower hole.

Only follow Steps 2 and 3 if you are just fitting 1 hanging rail.  
If you are fitting 2 hanging rails, follow Step 4 and 5.



## Step 4


### Prepare the left end

Refer to step 1 and, if you have chosen to fit 2 hanging rails, screw 2 metal dowels **B** into the left end **1**.

**Note:** Tighten the metal dowels up fully against the panels.

To fit the 2 rail holders **K** screw through the top hole with screw **J** and into the shallow mark hole drilled in the left end **1**. Make sure that they are fitted straight, in line with the panel edges and then fit another screw **J** using the lower hole.

Only follow Steps 4 and 5 if you are fitting 2 hanging rails.  
If you are just fitting 1 rail, follow Step 2 and 3.



# Assembly Instructions

## Step 5


### Prepare the right end

Refer to step 1 and, if you have chosen to fit 2 hanging rails, screw 2 metal dowels **B** into the right end **1**.

**Note:** Tighten the metal dowels up fully against the panels.

To fit the 2 rail holders **K** screw through the top hole with screw **J** and into the shallow mark hole drilled in the right end **1**. Make sure that they are fitted straight, in line with the panel edges and then fit another screw **J** using the lower hole.

Only follow Steps 4 and 5 if you are fitting 2 hanging rails.  
If you are just fitting 1 rail, follow Step 2 and 3.



## Step 6


### Prepare the fixed shelf

Tap 2 wooden dowels **A** into the fixed shelf **3**.

**Note:** Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.

Insert 4 large locking nuts **C** into the fixed shelf **3**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.



# Assembly Instructions


## Step 7

### Join the fixed shelf to the right side

Push the fixed shelf **3** onto the right side **1**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the fixed shelf **3**.

**Note:** Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




## Step 8

### Fit the left side

Push the left side **1** onto the fixed shelf **3**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the fixed shelf **3**.

The following diagrams will show the fixed shelf at the top end of the unit. You may have fitted it in the middle of the unit.






# Assembly Instructions

## Step 9

### Prepare the base


Screw the 6 feet **M** into the shallow mark holes on the base **2** using screws **G**.



## Step 10

### Fit the base

Attach the base **2** to the ends **1** using 6 screws **F** and tighten them using the allen key **E**.




# Assembly Instructions

## Step 11

### Fit the top

Attach the top **2** to the ends **1** using 6 screws **F** and tighten them using the allen key **E**.



## Step 12

### Fit the back

**a:** Square up the unit by making sure that measurement **x to x** equals **y to y**.


**b:** Place the back **5** onto the unit.

Nail **D** around the outside edges of the back **5**.

**Note:** Nails should be spaced about 150mm apart.

**Stand the unit up for the next step.**

**a:** The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y



**Warning:** The unit is heavy. Lift with care.

# Assembly Instructions

## Step 13

### Fit the 2 brackets

To prevent possible overbalancing, we recommend that this unit is secured to a suitable wall by use of the 2 brackets **L** fitted to the top of the unit.

Fixings are not supplied, as they will need to suit the wall type and the length of screws will depend on the distance from the back of the unit to the wall.

Fix the brackets **L** loosely onto the top of the unit using screws **I** and mark the wall for the wall fixing.

Swivel the brackets **L** away from the wall and drill the holes in the wall using a suitable drill bit and fit your wall fixings.

Swivel the brackets **L** back and fix the brackets to the wall, then tighten the screws **I**.


**Note:** Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.



**Warning:** The unit is heavy. Lift with care.

## IMPORTANT

This unit **MUST** be fixed to a wall using both of the brackets supplied. The unit must be level and square before fitting the brackets.



### NOTE


The unused fittings from this assembly are used to fit the doors. Please refer to the instructions packed with the doors.

# Assembly Instructions

## Step 14

### Fit the hanging rail(s)


Push the hanging rail(s) **4** into the rail holders **K** fitted to the side panels.



## Step 15

### Fit the doors and, if required, the internal chest

Please refer to the instructions packed with the doors or chest.



If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800 and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW


# Atlas - Standard Double Door

Assembly Instructions - Please keep for future reference

151/7396

157/2063

157/7240



## Dimensions for each door

Width - 49.5cm

Depth - 1.5cm

Height - 210cm



**MADE IN  
BRITAIN**

**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



# Safety and Care Advice

**Important - Please read these instructions fully before starting assembly**

- **Warning:** These panels weigh approximately 22kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings (not supplied).

- Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

**Note:** If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

# Component - Panel

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have the panel listed below




Standard Door (D2398A)  
(2100 x 495mm) x 2

# Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

These fittings are packed with the Robe Carcass.  
The quantities will depend on which robe you have bought.




**H** 19mm Screw (F461)




**J** 13mm Screw (F63)

**N**



Handle (F328)

**O**



Hinge (F328)



# Assembly Instructions

If you have damaged or missing components, call the  
Customer Helpline: 08456 400800 quoting the reference  
numbers below

## Step 1

Have you purchased a  
Mirror Door?

### IMPORTANT

If you have purchased a Mirror Door,  
DO NOT follow these instructions.  
Please use the instructions packed  
with the Mirror Door.


## Step 2

### Prepare the doors

Push fit 4 hinges **O** into  
each door.

Secure each hinge with  
2 screws **J**.

**Note:** Before securing  
with the screws, make  
sure that the hinges are  
positioned at 90 degrees  
with the edge of the  
door.





# Assembly Instructions

## Step 3

**For a door which has a handle on the left, drill these 2 handle holes**

**Important:** Please follow these instructions carefully.

Lay the door down onto a smooth surface.

Check that the hinges and holes are in the same place as the diagram.

**Note:** We recommend the use of a small piece of waste wood, placed behind the holes while drilling, to reduce the possibility of any breakout.


Using the pilot holes in the rear face of the door, drill through the 2 holes indicated opposite, using a 2.5mm diameter drill.

Turn the door over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.


## IMPORTANT

This step shows which handle holes to drill for doors that have their handles on the LEFT, as shown below.

Go to Step 4 for how to drill a door with its handle on the RIGHT.



## ONLY drill these 2 holes



# Assembly Instructions

## Step 4

**For a door which has a handle on the right, drill these 2 handle holes**

**Important:** Please follow these instructions carefully.

Lay the door down onto a smooth surface.

Check that the hinges and holes are in the same place as the diagram.

**Note:** We recommend the use of a small piece of waste wood, placed behind the holes while drilling, to reduce the possibility of any breakout.


Using the pilot holes in the rear face of the door, drill through the 2 holes indicated opposite, using a 2.5mm diameter drill.

Turn the door over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.


### IMPORTANT

This step shows which handle holes to drill for doors that have their handles on the RIGHT, as shown below.

Go to Step 3 for how to drill a door with its handle on the LEFT.



### **ONLY** drill these 2 holes



# Assembly Instructions

## Step 5

### Fit the doors and the handles

#### 2 people are needed here

Make sure that the doors are the correct way around. The bottom hole on the back surface of the door will be one of holes that you have drilled.


Line up the 2 screws in the top hinge **O** with the 2 holes at the top of the panel and push them in.

Working down the door, push in the other hinges.


When all of the hinges have been pushed into place, tighten the 2 screws on each hinge.

Attach a handle **N** to each door using 2 screws **H**.


Press the screws into the holes in the panels



When the hinges have been pushed in, tighten up their screws



This shows a door being fitted onto the right side of a double robe. The same assembly method applies to all doors and robes.



**Warning:** The door is heavy. Lift with care.

# Assembly Instructions

## Step 6

### Adjust the doors if needed

**a:** Before adjusting the doors, use a spirit level to check the base (or top) of the unit is level, front-to-back and side-to-side in the 3 positions shown. Use suitable packing pieces (not supplied) to make the unit level BEFORE making any adjustment to the hinges, as shown.

### **b:** Height adjustment.


Loosen screws A on hinge plates and move door up or down as required. Retighten screw A.

### **c:** Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required. Retighten screw B.

### **d:** Sideways adjustment.

To move door 'out' loosen screw C. To move door 'in' tighten screw C.



If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800 and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW