

Razor RipStik Electric

Problem	Possible Cause	Solution
-Does not work out of the box	-Product must be travelling at least 3 mph (5 km/h) before motor will engage -Product not paired with remote	-Kick start to at least 3 mph (5 km/h) while the lever on the remote is in the "GO" position to engage motor. -Refer to page 4-5 for pairing information
-No longer works	-No lights on charger -Undercharged battery -Battery will not hold a charge	-Check power to wall outlet and/or try a different outlet. -Check lights on charger: Plugged into wall - Green Plugged into wall & unit - Red (charging) Plugged into wall & unit - Green (charging complete) No lights/Blinking lights - Replace Charger -Turn product over. Turn the power switch on the remote and product to the ON position. Move the lever on the remote to the GO position and hold. Manually (use caution) spin the rear wheel forward. If motor engages - replace battery
-Short run time/runs slow	-Riders weight -Riding conditions -Battery not fully charged -Old/damaged battery	-Do not exceed 143 lb (65 kg) maximum weight limit. -Use only on flat, dry surfaces. Avoid inclines and areas with heavy debris. -Charge product - refer to page 6 for charging information. Replace battery. -Charge battery at least once a month when not in use.

