

Service and Repairs

Your ACCURIST watch is guaranteed against defects in materials and workmanship for a period of 2 years from the date of purchase. During this period, we will exchange or repair, at our discretion, any defective components free of charge.

IMPORTANT - Not covered by Guarantee

1. Batteries, straps and bracelets.
2. Damage caused by accident, misuse or lack of care.
3. Water penetrations except in watches marked as "Water Resistant".

SERVICING AND REPAIRS UNDER GUARANTEE

Please post your watch, together with the Retailer's Sales Receipt or proof of purchase, the completed Guarantee slip, and a brief note to explain the nature of the fault, by Registered Post or Recorded Delivery to the address shown. Do not send the presentation box as this will NOT be returned.

SERVICING AND REPAIRS OUTSIDE OF GUARANTEE

Available at a reasonable charge after an estimate has been sent by T.P. (UK) Ltd. Send your watch to us by Registered Post or Recorded Delivery to the address shown.

Important Note

It is important to identify your watch correctly. If, after reading this Instruction Guide, you have any further questions regarding the use, operation or adjustment of your watch, please call us during office hours on 0116 288 2500.

T.P. (UK) Ltd, Alexander House, Chartwell Drive, Wigston, Leicester
LE18 2EZ
United Kingdom.

Water Resistance

If your watch is water resistant, it will clearly state "Water Resistant" or have a static water pressure indication (e.g. "30/50/100/200 metres") on the dial and/or case back.

If it is not marked as water resistant, it should not be allowed to come into contact with water or be worn in conditions that could expose it to moisture (e.g. washing, heavy rain etc.). Certain chemicals in water may damage the watch seals. To maintain water resistance, we recommend that your watch is serviced and re-sealed at least every 12 months by T.P. (UK) Ltd.

IMPORTANT

Buttons must not be operated while in contact with water.

WATER RESISTANT or RESISTANT TO 30 METRES

Suitable for normal everyday use and will resist exposure to splashes and rain; it is NOT designed to be used whilst bathing or swimming.

WATER RESISTANT TO 50 METRES

As 30 metres plus bathing or swimming.


WATER RESISTANT TO 100 METRES

As 50 metres plus pool side diving and snorkelling, but not high board or scuba diving.


WATER RESISTANT TO 200 METRES

As 100 metres plus scuba diving, but not high board diving.

System Settings



Time/Date Settings



Digital Instructions

Using the backlight feature

1. Press 'A' button to activate the backlight for 3 seconds.

System Settings:

Using the night feature

1. Hold down 'C' and press 'B' to enter system settings mode.
 2. Press 'D' to select "NGT" on/off.
- When "NGT" is on the backlight will activate when any button is pressed.

Setting the time schedule

- Before setting the time please check correct time schedule is selected.
- To select the time schedule press the buttons in the following sequence.

1. Hold down 'C' button and press 'B' to enter system settings mode
2. Press 'C' to cycle through time zones and press 'D' to select either "STD" standard time or "DST" daylight saving time.
3. Press 'B' to set selection and return to real time mode.

Digital Instructions

Setting the time

1. Hold down 'B' to enter time setting mode.
2. When whole display is flashing press 'D' to select the chime hourly function on/off, then press 'C'.
3. When the time zone display is flashing press 'D' to cycle through time zones, then press 'C'.
4. When the seconds display is flashing press 'D' to reset to zero, then press 'C'.
5. When the minute display is flashing press 'D' to increase the value or hold 'D' to increase quickly, then press 'C'.
6. When the hour display is flashing repeat step 5.

Setting the date

- Continuing on from setting the time, press the buttons in the following sequence to set the date.
1. When the month display is flashing press 'D' to cycle through the values, then press 'C'.
 2. When the day display is flashing press 'D' to cycle through the values, then press 'C'.
 3. Repeat step 2 to set the year.

Selecting 12/24h format

- Continuing on from setting the date, when the display is flashing press 'D' to select either 12h or 24h format. Press 'B' to return to real time mode.

* Instructions continued overleaf.

GUARANTEE

PLEASE USE BLOCK CAPITALS

NAME

ADDRESS

POST CODE

DAYTIME TELEPHONE NUMBER

IMPORTANT

This guarantee slip should be retained by the owner of the product and should be sent to Timeproducts (UK) Ltd. together with the product and £12 to cover the handling and postage when service under Guarantee is required.



GUARANTEE


DATE OF PURCHASE:

Retailers stamp if required or full name and address:


Please attach the receipt or proof of purchase; failure to attach these may invalidate this Guarantee.
This Guarantee does not affect your statutory rights.

IA05/05-2015

Alarm settings mode



Stopwatch mode



Digital Instructions

Setting the alarm feature

1. Press 'B' to enter settings mode and press 'C' to cycle through and select the time zone.
 2. Hold down 'B' for 2 seconds to enter the alarm settings mode.
 3. Press 'D' to select alarm on/off, then press 'C'.
 4. Press or hold 'D' to set the hour value, then press 'C'.
 5. Repeat step 4 to set the minute value, then press 'B' to set the alarm and return to settings mode.
- There are 3 alarms, each can be set for different times in different time zones independantly. Press 'B' to cycle between the alarms and follow the sequence above to set the alarms.

Using the stopwatch feature

1. Press 'B' until display shows "CHR" mode.
- *Stopwatch measurement can time up to 10 hours.*
- Standard measurement:
 1. Press 'D' to start the counter, then press 'D' again to stop.
 2. Press 'C' and 'D' together to reset the counter.
 - Accumulated elapsed time measurement:
 1. Press 'D' to start the counter, then press 'D' again to stop.
 2. Restart the counter by pressing 'D' as many times as required.
 3. Press 'D' to stop the counter, then press 'C' and 'D' together to reset.

Digital Instructions

Using the stopwatch feature continued

- Split time measurement:
 1. Press 'D' to start the counter, then press 'C' to split the timing.
 2. Press 'D' to stop and restart the counter.

**The stopwatch can record up to 10 LAPS. If the counter is still running after the 10 LAPS have been recorded, any additional elapsed time will be added to the final LAP time.*

**Once the counter has been stopped and no further timing is required, press 'C' to cycle through and view the recorded LAP times.*

**If the mode is changed by pressing 'B', whilst the counter is running, timing will continue in the background until the counter is stopped.*

Using the countdown feature

1. Press 'B' until display shows "TMR" then press 'C' to enter the countdown timer settings mode.
2. Press or hold 'D' to increase the timer duration. Press 'C' to turn on/off the repeat countdown function.

**Maximum duration is 180 minutes. The repeat countdown function will automatically restart the same countdown once the timer reaches zero.*

3. Press 'B' to set the countdown time, then press 'D' to start and stop the timer.

**The countdown timer will automatically set if no button is pressed after 1 minute.*

Digital Instructions


Using the countdown feature continued

4. To restart the timer press 'C' to enter the countdown timer settings mode, then press 'B' to return to the start.

**Before restarting, the countdown timer must be stopped.*

- During the countdown a tone will sound for every 10 seconds elapsed. During the last 10 seconds of the countdown a tone will sound for every second elapsed. Once the countdown is complete an alarm tone will sound until any button is pressed.


Countdown timer settings mode



Analogue Instructions

Setting the time

1. Pull the crown out to position 2.
2. Turn the crown until the hands show the correct time.
3. Return the crown to position 1.



World Time Zone Reference Table

City Code	City	Country	Time Difference
UTC	Coordinated Universal Time	N/A	N/A
LON	London	UK	±00:00 UTC
PAR	Paris	France	+01:00 UTC
ROM	Rome	Italy	+01:00 UTC
CAI	Cairo	Egypt	+02:00 UTC
MOW	Moscow	Russia	+03:00 UTC
DXB	Dubai	UAE	+04:00 UTC
KHI	Karachi	Pakistan	+05:00 UTC
DEL	New Delhi	India	+05:30 UTC
DAC	Dhaka	Bangladesh	+06:00 UTC
BKK	Bangkok	Thailand	+07:00 UTC
SIN	Singapore	Singapore	+08:00 UTC
HKG	Hong Kong	China	+08:00 UTC
TYO	Tokyo	Japan	+09:00 UTC
SYD	Sydney	Australia	+10:00 UTC
NOU	Noumea	New Caledonia	+11:00 UTC
AKL	Auckland	New Zealand	+12:00 UTC
HNL	Honolulu	USA	-10:00 UTC
ANC	Anchorage	USA	-09:00 UTC
LAX	Los Angeles	USA	-08:00 UTC
DEN	Denver	USA	-07:00 UTC
CHI	Chicago	USA	-06:00 UTC
NYC	New York	USA	-05:00 UTC
CCS	Caracas	Venezuela	-04:00 UTC
RIO	Rio de Janeiro	Brazil	-03:00 UTC