

BUSH

Instruction manual

Steam Station Model:

EB2480



You'll soon be enjoying your new Bush Steam Station.

It all begins here, with your instructions. Don't worry, there's nothing too technical coming up. Just simple, step-by-step guidance to get you up and running quickly. Sound good? Then let's get started.

Help and Guidance

We're here to help you get the most from your Bush Steam Station. Should you require any guidance; call our Help line on 0345 604 0105. Further contact details can be found online at: **www.bush-support.com**

Or by calling one of our experts on **0345 604 0105**

Contents

| | | |
|---|------------------------------------|----|
| 1 | Safety information | 4 |
| 2 | Getting to know your steam station | 8 |
| 3 | Using your steam station | 10 |
| 4 | Care and maintenance | 14 |
| 5 | Product support | 18 |

Safety information 1



Safety information

Important - Please read these instructions fully before installing or operating

- The iron must be used only for its intended purpose.
- The iron must not be left unattended while it is connected to the supply mains.
- Always unplug the appliance from the socket outlet before you fill in the water reservoir, when emptying it or when not in use.
- The steam generator must be used and rested on a flat, stable and heat-resistant surface.
- When placing the iron on its heel, ensure that the surface on which the heel is placed is stable.
- The iron is not to be used if it has been dropped, if there are visible signs of damage or if it is leaking.
- Keep the iron and its cord out of reach of children less than 8 years of age when it is energized or cooling down.
- The surfaces of the iron are liable to get hot during use. Burns can occur from touching hot parts, hot water or steam.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instructions concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Check the mains cord regularly for possible damage. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never immerse the iron, cable or plug in water
- Do not leave the hot iron touching fabrics or inflammable surfaces, do not let the cord come into contact with hot soleplate of the iron.



Safety information

Important - Please read these instructions fully before installing or operating

- Never touch the appliance with wet or damp hands.
- Do not put scented substances, descaling agents or other chemicals in the water tank. Failure to comply will lead to the loss of guarantee.
- Only connect the steam generator to an earthed wall socket. If the extension cord is required, a 10-ampere cord should be used. Cords with lower amperage may overheat.

The appliance does not work without the filter cartridge. Filter cartridge needs to be replaced when the light indicator switches on.

Do not pour vinegar or any other descaling solutions into the water reservoir.



Safety information

Important - Please read these instructions fully before installing or operating

Plug / Wiring advice

The wires in this mains lead are coloured in accordance with the following UK electrical code:


BLUE = NEUTRAL

BROWN = LIVE

GREEN + YELLOW = EARTH

Rewireable plug

The colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in a rewireable plug. **Rewireable plugs should only be replaced by a suitably competent person. If in doubt, consult a qualified electrician.**



The BLUE wire must be connected to the terminal marked with the letter N

The BROWN wire must be connected to the terminal marked with the letter L

The GREEN & YELLOW wire must be connecting to the terminal

Getting to know your steam station 2

Getting to know your steam station


You'll be up and running in no time

Ready? Let's begin...

Please read these instructions carefully. They contain important information which will help you get the best from your steam iron and ensure safe and correct installation and operation.

If you require any further assistance, our technical experts are happy to help. For full details, refer to the product support section at the end of these instructions.


Part identification



- | | |
|-----------------------------|---|
| 1) Lock button | 10) Control panel |
| 2) Supply cable with plug | 11) Resin box |
| 3) Temperature control knob | 12) Filler |
| 4) Steam button | 13) Power button with indicator light |
| 5) Iron light indicator | 14) Resin box change indicator light Reset button |
| 6) Soleplate | 15) Menu selection button |
| 7) Handle | 16) MIN mode with indicator light |
| 8) Water tank | 17) MAX mode with indicator light |
| 9) Water tank ornament | 18) Self Clean mode with indicator light |

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions

Using your steam station 3







Using your steam station

Let's get started

Note: When using the iron for the first time, you may notice a slight emission of smoke and hear some sounds made by the expanding plastics. This is quite normal and it stops after a short time. We also recommend passing the iron over an ordinary cloth before using it for the first time.

PREPARATIONS:

Sort the laundry to be ironed according to the international symbols on the garment label, or if this is missing, according to the type of fabric.

| GARMENT LABEL | FABRIC TYPE | THERMOSTAT REGULATION |
|---|-------------------------|--------------------------|
|  | synthetic | • low temperature |
|  | silk - wool | •• medium temperature |
|  | Cotton - linen | ••• high temperature |
|  | Fabric not to be ironed | |

Start ironing the garments requiring a low temperature.
This reduces the waiting times (the iron takes less time to heat up than to cool down) and eliminates the risk of scorching the fabric.

Using your steam station

Let's get started

- **PREPARATION FOR USE**

- The appliance uses ordinary tap water.
- If the water is very hard (hardness higher than 27 degrees French), we suggest using distilled or demineralized water.
- Before using the equipment, find the water inlet (12) and first fill the water tank (8) with an appropriate amount of water, not exceeding the MAX water level.
- Connect the appliance to the power supply.
- Press the power button with indicator light (13), the default MAX mode indicator light will switch on and the generator will start heating up.
- Select the desired temperature by turning the thermostat knobs (3). The colored part indicates the steam ironing sector.
- The steam indicator (17) and the iron heating indicator (5) are on for about 90 seconds, indicating that the iron can start using steam.

- **STEAM IRONING**

- When using the iron for the first time, iron a plain cloth first.
 - It takes about 30 secs to obtain steam after pressing the steam button (4).
- NOTE:** When the steam button is released (4), some steam will come out from the iron soleplate.

CAUTION: Do not disconnect the appliance if the steam is still coming out from the soleplate. Wait till all the steam is released and then unplug the appliance. This will prevent water and steam being released when you switch the iron on next time.

This appliance is also able to generate steam in a vertical position and can therefore be used to refresh fabrics easily with a jet of steam.

Using your steam station

Let's get started

- **STEAM IRONING**

When the indicator light (14) switches on, the filter cartridge needs to be replaced. Once the cartridge is replaced, press the button (14) to reset. The indicator light will switch off.

To order replacement cartridge please contact :

0345 604 0105

www.bush-support.com

- **DRY IRONING**

- Connect the appliance to the power supply, press the power button with the indicator light (13), and then rotate the temperature control knob (3) to select the desired temperature. Wait until the iron heating indicator (5) lights up to indicate that the desired temperature has been reached.

- **SELF CLEANING**

- When the steam function has been used for a cumulative total of 7 hours, the self-cleaning indicator light (18) will flash, prompting the user to initiate the de-scaling process.

- To activate the de-scaling mode, press and hold the menu selection button (15) for 5 seconds. Once activated, the indicator light (18) will flash rapidly (0.5 seconds on, 0.5 seconds off).

- In this mode, place the iron soleplate over a sink. The appliance will automatically discharge a large amount of wastewater within approximately one minute.

- The cleaning process is complete when the indicator light turns off.

Care and maintenance 4

Care and maintenance

Looking after your appliance

• HOW TO PUT IT AWAY

- After use, always allow the iron to cool before putting it away.
- Empty the water tank.
- Place the steam flexible hose and power cable in the base of the appliance .
- Always keep the surface the ironing plate perfectly clean. To clean it, just wipe the cold surface with a damp cloth. The appliance must not be cleaned with descaling agents.
- Do not iron over zippers, hooks, rings, etc; as these may scratch the plate.
- When you have finished ironing. Place the iron correctly on its stand. Ensure that there are no traces of water under the plate, as these may cause stains.
- Store the appliance in a dry place.

• ADVICE FOR GOOD IRONING

- Divide the washing according to the correct ironing temperatures. Start by ironing those garments that require a lower temperature. For fuller details, refer to the chart at end of this booklet.
- Fabrics such as velvet and wool, and accessories such as gloves, handbags, etc. will regain their brand-new look and texture by simply passing the iron near the surface of the fabric and pressing the steam button.
- Imprints left in carpets by furniture can be removed by applying steam on the parts where the pile is crushed and the brushing lightly.
- If the carpet is made of synthetic material, do not select a high temperature.

Care and maintenance

Looking after your appliance

• HOW TO GET A PROFESSIONAL IRONING FINISH

- A normal iron generates only a small quantity of steam. In this case it is necessary to products steam constantly in order to eliminate crease in the fabric being ironed.
- A professional ironing system works rather differently. The fabric is first made damp by the steam and then, in a second phase, dry-ironed in the normal way. This means that every. Tiniest crease is removed and your garments are ironed to perfection.
- In the first phase (steam-damping of the fabric),hold the iron about 20 cm above the fabric and press the steam button (4) . Pass the iron over the garment in a circular movement so that the powerful jet of steam damps the fabric. Lightly creased garments require only a few moments of steaming. While very heavy fabrics or garments with particularly difficult creases must be damper, so steam must be applied for a few seconds more.
- During the second phase (dry ironing), check that the thermostat knob is in the correct position for the type of fabrics; dry-iron the garment. The special ironing plate will prevent the fabrics from becoming shiny. Using this ironing technique, and following the suggestions in the chart below, you will find it easy to give your garments a really professional ironing finish.

Other information

Technical Specification

| | |
|--------------------------|--------------------|
| Model | EB2480 |
| Argos Number | 434320 |
| JS Number | 2709703 |
| Rated voltage | 220-240V ~ 50/60Hz |
| Power | 2200W |
| Class rating | Class I |
| BS 1362 fuse | 10A |
| Heating time | <3minutes |
| Water reservoir capacity | 1.8L |
| Cord length | 1.9m |
| Ingress protection | IPX4 |
| Accessory(water jug) | 200ml |



Recycling electrical products



You should now recycle your waste electrical goods and in doing so help the environment.

This symbol means an electrical product should not be disposed of with normal household waste. Please ensure it is taken to a suitable facility for disposal when finished with.

Visit www.recycle-more.co.uk, click on "bank locator" and enter your postcode to find your nearest recycling site.

Product support 5

Product support

Help is always at hand

Help and assistance

If you require any technical guidance or find that your Bush steam cleaner is not operating as intended, a simple solution can often be found in the Troubleshooting section of these instructions or online at www.bush-support.com

If you still require further assistance, call one of our expert on 0345 604 0105*.

To help give us give you a fast and efficient service please have the following information ready:

| | | |
|------------------|----------------------|--|
| Model Ref: | <input type="text"/> | You can find this information on the rating plate – a small sticker (usually a sticker or metal plate on the rear of your product) |
| Serial number | <input type="text"/> | |
| Date of purchase | <input type="text"/> | This will be shown on your receipt |

Local call rate applies*

Lines open 8am-7pm Monday to Saturday and
10am-4pm Sunday.

*Calls to Bush enquiry lines may attract a charge and set up fee from residential lines depending on your call plan / tariff. Mobile and providers costs may vary, see www.bt.com/pricing for details

For security and training purchase, telephone calls to and from customer service centres maybe recorder and monitored. Calls from Republic of Ireland will attract international call charges.

Product support

Help is always at hand

BUSH

Call us now and register your 12 month guarantee

Thank you for choosing Bush. Your new product is guaranteed against faults and breakdowns for 12 months. Don't forget to register it with us today so we can provide you with our best possible after-sales service and useful updates.

www.bush-support.com

FREEPHONE*

0800 597 8548

Lines open 8am-8pm, 365 days a year. *Calls may be recorded and monitored.

Your Bush Guarantee

This product is guaranteed for twelve months from the date of original purchase. Any defect that arises due to faulty materials or workmanship will be repaired free of charge (or if applicable the product will be replaced or the purchase price refunded) where possible during this period by the dealer from whom you purchased the unit.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in the material.
- It must be used solely for domestic purposes. The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- Specifications are subject to change without notice.
- Bush disclaim any liability for loss or damage arising from the breakdown of the product.
- This guarantee is in addition to and does not diminish your statutory or legal rights.

For your personal Guarantee Confirmation code call 0800 597 8548

Guarantee Confirmation Code

Or by calling one of our experts on **0345 604 0105**

Product support

Help is always at hand

Important Data Protection Information

Bush has appointed Domestic & General Insurance PLC to provide product registration services and protection plans to accompany its products.

What we do with your information

At Domestic & General we want to reassure you that we use your information both responsibly and securely to provide you with the best possible service. Below we explain what we do with your information and your rights to your information. If you would like any further details you can get in touch with us using the contact details below or visit our website (www.domesticandgeneral.com).

Using your information

Domestic & General Insurance PLC ("we") is the "data controller" of your information. We process two sets of information about you. "Personal Information" (your name, address, contact and payment details) and the "Good Information" you provide to register your appliance or device (your name, address, contact and good details). We'll use your information: (i) as necessary to fulfill our contract with you (including to recover any amounts owing); (ii) for our legitimate interests in: undertaking marketing (about our products and services and those of our third party partners) by post, telephone, email and/or other electronic messaging services; recording your conversations for training, quality and compliance purposes; and for analytics and profiling for marketing purposes; and (iii) where required to do so by law. We may also ask for your consent to some uses of your information.

Sharing your information

From time to time your Personal Information and Goods Information may also be shared with other members of the Domestic & General Group of Companies (Domestic & General Insurance or Services and other future members of the Group whose details we will notify to you ("Group")), with companies acting on our behalf or providing services to us (e.g. the companies we use to carry out repairs, IT & mailing services storage of paper records and telecommunications) and with the Sainsbury's Argos Group (which currently includes Sainsbury's Supermarkets, Sainsbury's Bank, Argos Limited, Tu Clothing, Habitat, Argos Financial Services, Nectar and Insight 2 Communication, Argos Business Solution Limited). The Sainsbury's Argos Group will process your Personal information for their legitimate business interests (marketing and analytic) in accordance with their privacy policy, which can be found at www.argos.co.uk/help/privacy-policy

Transferring your information

In exceptional cases, we may transfer your information to countries outside the European Economic Area (including the US) which may not have data protection laws, which provide the same level of protection as provided in the UK. We have put in place Model Clause as an appropriate safeguard to ensure that such information is adequately secured and protected and that such transfers meet the requirements of appliance data protection law.

Product support

Help is always at hand

Keeping your information

We keep your Personal Information for six years after you terminate your policy so that we can deal with any claims. Your goods information we keep for a bit longer, normally 10 years (that average life of an appliance) for health and safety. We also keep your information to send you marketing that you might be interested in, unless we receive a request from you to opt-out of marketing.

Rights to your information

By writing to the Data Protection Officer using the contact details provided below, you have the right to ask us:

- for a copy of the Personal Information we hold about you
- for a copy of the Personal Information you provided to us be sent to you or a third party in a commonly used, machine readable format
- to update or correct your Personal Information to keep it accurate
- to delete your Personal Information from our records if it is no longer needed for the original purpose; and
- to restrict the processing of your Personal Information in certain circumstances

And you may also:

- object to us processing your Personal Information – in which case we will wither agree to stop processing or explain why we're unable to; and
- where we rely on your consent, withdraw that consent at any time.

Please note that the above rights are not absolute and certain exemptions apply to them.

You can also make a complaint to the Information Commissioner (www.ico.org.uk) if you feel your personal Information has been mishandled.

Marketing

We, along with other members of our Group, Argos Limited, and other members of the J Sainsbury's Group of Companies may use your information to tell you about any offers, products or services which may be of interest to you. We may contact you by post, telephone, email, and/or other electronic messaging services. To change your marketing preference, let us know by emailing marketingpreference@domesticandgeneral.com or by writing to us using the contact details provided below. If you don't want Argos to send you marketing by phone, email or post then please see Argos's Privacy Policy, which can be found on their website at www.argos.co.uk/help/privacy-policy to opt out of this marketing. Argos will stop sending you marketing communication but will still contact you service-related messages every now and then.

Contact Details

If you need to contact us about your information or your information rights, or to see a copy of our Model Clauses, please write to: Freepost Plus RTKS-CLRA-GRYE, Data Protection Officer, Domestic & General, Leicester House, 17 Leicester Street, Bedworth, CV12 8JP or dataprotection@domesticandgeneral.com and we'll be happy to help you.

Or by calling one of our experts on **0345 604 0105**

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions

BUSH

Should you require any guidance:
call our Help line on 0345 604 0105.
Further contact details can be found online at:
www.bush-support.com

Produced in China for Argos Limited, London, EC1M 6HA, UK.
Argos (N.I.) Ltd., forestside Shopping Centre.
Upper Galwally, Belfast, BT8 6FX UK.