

Alba 8" Android Tablet Instruction manual



You'll soon be up and running

Looking forward to your new Alba 8 Tablet? Great. Then let's get you started.

Just follow this simple step-by-step guide and you'll be good to go.

Help and Guidance

We're here to help you get the most from your Alba 8 Tablet. Should you require any guidance, a simple solution can often be found online at: **www.argos-support.co.uk.** If you still require further assistance, call one of our experts on 020 8068 1044.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the

Contents

Safety information	5	Using
Getting to know your Alba 8	21	Using
Ready let's begin	22	Prod
Accessories	22	Troul
Chargerassembly	23	Help
Device description	24	Envir
Starting up	26	Your
Connecting to a WiFi network	28	
The Android [™] interface	30	

Using your Alba 8	35
Using your Alba 8	36
Product support	47
Troubleshooting	48
Help and assistance	51
Environmental considerations	52
Your Alba guarantee	53

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044.





1

Important - Please read these instructions fully before installing or operating

Warranty and Limited Liability

In this document, with regard to the use of the name "Alba", Alba is a brand owned by Argos Ltd, 489 – 499 Avebury Boulevard, Milton Keynes, MK9 2NW.

This product is sold with a limited warranty and specific remedies are available to the original purchaser in the event the product fails to conform to the limited warranty. Manufacturer's liability may be further limited in accordance with its sales contract.

Nothing in this document affects the consumers statutory rights under UK law, in particular Sale of Goods Act 1979 (as Amended), Consumer Rights Act 2015 and Consumer Contract (Information, Cancellation and Additional Charges) Regulations 2013.

In general, and in an non-limited manner, the manufacturer shall not be responsible for product damages caused by natural disasters, fire, static discharge, misuse, abuse, neglect, improper handling or installation, unauthorized repair, alteration or accident. In no event shall the manufacturer be liable for loss of data stored on disk media unless the cause is proven to be a defective product or a defect in any digital content supplied with the unit. If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the Safety information

Important - Please read these instructions fully before installing or operating

Please see Argos.co.uk for a complete statement of warranty rights, remedies and limitation of liability.

Furthermore, the warranty as far as is permitted by law does not apply to:

1. Damages or problems resulting from misuse, abuse, accident, alteration or incorrect electrical current or voltage.

2. Any product tampered-with or damaged warranty seal or serial number label.

3. Any product without a warranty or serial number label.

The end user is required to use this product only in conformity with its original purpose and is strictly forbidden to make any technical modifications that could potentially impinge on the rights of third parties. Any modification to the hardware, software, or physical enclosure of the product must be approved in writing by Alba. Non approved modified products are subject to the withdrawal of any or all guarantee clauses.

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044 Safety information



Important - Please read these instructions fully before installing or operating

In the event that your product ceases to operate within 24 months of purchase, return it along with all accessories to your place of purchase along with proof of purchase for either a free repair, replacement or refund to be determined by Alba on receipt of your faulty device. This Guarantee is provided by Argos Ltd, 489 – 499 Avebury Boulevard MK9 2NW, and does not affect your consumer rights.

Lithium-ion Battery Caution

This product is equipped with a Lithium-Ion battery. Do not pierce, open, disassemble it, or use it in a humid and/or corrosive environment. Do not put, store or leave your product in or near sources of heat, in direct strong sunlight, in a high temperature location, in a pressurized container or in a microwave oven. Do not expose it to temperatures over 60 C (140 F). If the battery leaks and you come into contact with the leaked fluids, rinse thoroughly with water and seek medical attention immediately. Failure to follow these instructions could cause the Lithium-Ion battery to leak acid, become hot, explode or ignite and cause injury and/or damage.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the



Important - Please read these instructions fully before installing or operating

Optimising battery performance

Do not leave your battery charging for more than one day. Doing so runs the risk of overcharging the battery and shortening its total life span.

If the device is not used for an extended period of time, the battery will slowly discharge and the device will need to be recharged before using again.

Unplug the charger from the wall when it is not being used.

Use only a Alba approved battery in the device.

Warnings and Safety Instructions

CAUTION

To prevent risks of electric shock, this unit must only be opened by qualified service personnel. Power off and disconnect the power supply cable before opening the unit.

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture. Use of this product is for personal use only. Copying CDs or loading music, video, or picture files for sale or other business purposes is or may be a violation of copyright law.

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044.

Safety information



Important - Please read these instructions fully before installing or operating

Copyrighted materials, works of art, and/or presentations may require authorization to be fully or partially recorded. Please be aware of all such applicable laws concerning the recording and use of such for your country and jurisdiction.

SAFETY

For driving safety, only a passenger should operate the device when the car is in motion and not the driver. Laws governing the usage of electronic devices by the driver may be applicable in your jurisdiction and/or country.

Install your Alba product carefully

Make sure your Alba product and its accessories are solidly secured when you are using them in a car. Avoid mounting your Alba device and its accessories near the airbag opening areas. Equipment that is not securely fixed in a car could result in serious injury when the airbag activates. Handle the batteries and charger with care and respect the recycling instructions. Use only Alba certified batteries and charger for your Alba product. Using batteries or a charger that is not certified by Alba can result in serious injury or damage your product. Never throw a battery into a fire. See your current local regulations for information on battery recycling.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the

10 ALBA Safety information

Important - Please read these instructions fully before installing or operating

Never put your Alba device inside of, or on top of, a heating device such as microwave oven, toaster oven, or heater. When batteries heat up, there is a risk of explosion. Be careful to never crush or perforate the battery. Avoid exposing the battery to high external pressure which could provoke an internal short-circuit and overheating.

Use only accessories that are Alba branded or recommended by Alba. The use of incompatible accessories with the Alba device can cause injury. Handle your Alba product with care. Keep your product away from any sources of humidity. This can seriously damage the device. Do not manipulate your Alba device with wet hands. Any damage done to the device due to its contact with water voids your guaranty. Do not use or store your product in an area that is dusty or dirty. This can deteriorate the components in your device. Your Alba device is a complex electronic product. Keep it protected from falls and physical shock. Do not subject it to violent movements.

Do not paint your product. Doing so could make movable parts unusable and reduce or limit its functionality. Only Alba certified technicians are qualified to repair your Alba device In calling upon non qualified persons to repair your Alba product, you run the risk of damaging your device and voiding your guarantee, this does not affect your consumer rights.

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044 Safety information ALBA 11

Important - Please read these instructions fully before installing or operating

Avoid interference with other electronic products

Your Alba device radiates radio frequency (RF) signals that could interfere with the functioning of other electronic devices that are insufficiently or incorrectly protected from RF energy, such as pacemakers, hearing aids, medical devices, or any other electronic device found in your home or car. Contact the maker of the maker of the equipment to resolve any possible interference problems.

Other Security Instructions

Always manipulate your Alba device with care. Keep it in a clean environment away from dust. Do no expose the device to extreme temperatures. Do not drop or throw the device. Do not allow the device to come in close contact to a flame.

CHILD PROTECTION:

This device is not a toy. Keep the device away from babies and infants, young children should only use the item under adult supervision. Unsupervised play can lead to injury or damage to the device. The mains adapter should be connected to the power supply close to the equipment and be easily accessible. To isolate the unit from power switch off power to the mains adapter and disconnect it from the power supply before disconnecting the USB lead from the product.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the



Safety information

Important - Please read these instructions fully before installing or operating

Electrostatic Discharge (ESD)

Normal functioning of the product may be disturbed by ESD. If so, simply reset the product to resume normal operation by following the instruction manual. During file transmission, please handle with care and operate in a static-free environment.

Avoiding Hearing Damage



This product respects the current regulations for limiting the output volume of consumer audio devices to a safe level. It must be only used with earphones complying with the EN 50332 norm. By listening to your device with headphones or earbuds at high volumes, you run the risk of permanent damage to your ears. Even if you get used to listening at high volumes and it seems normal to you, you still risk the possibility of damaging your hearing. Reduce the volume of your device to a reasonable level to avoid permanent hearing damage. If you hear ringing in your ears, reduce the volume or shut off your device and see a doctor.

Copyright Notice

Copyright Argos Limited © 2017. All rights reserved.

This document may not, in whole or part, be copied, photocopied, reproduced, translated or reduced to any electronic medium or machine-readable form without prior consent, in

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044 Safety information 13 ALBA

Important - Please read these instructions fully before installing or operating

writing, from Argos Limited. All brands and products names are registered trademarks and the property of their respective owners. Specifications are subject to change without notification. Errors and omissions accepted. Images and illustrations may not always match contents.

Disclaimer of warranty:

To the extent allowed by applicable law, representations and warranties of noninfringement of copyrights or other intellectual property rights resulting from the use of the product under conditions other than as here above specified, are hereby excluded.

END USER LICENSE AGREEMENT for Alba SOFTWARE

PLEASE CAREFULLY READ THE BELOW TERMS AND CONDITIONS OF THE END USER LICENSE AGREEMENT (EULA) BEFORE USING YOUR Alba PRODUCT. THE "Alba SOFTWARE" (all software distributed within the Alba hardware product) ON THIS DEVICE IS LICENSED TO YOU, YOU DO NOT OWN IT. BY USING THE SOFTWARE ON THE DEVICE, YOU ARE THUS GIVING YOUR CONSENT TO BE BOUND BY THIS AGREEMENT. IF YOU DO NOT AGREE WITH ANY PART OF THIS EULA, Alba WILL NOT LICENSE THE SOFTWARE TO YOU. IN SUCH A CASE, PROMPTLY SEE YOUR VENDOR OR CONTACT Alba DIRECTLY in order to FIND an adequate solution to this disagreement. On first use you may be required to accept license agreements, terms and conditions for third party software If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the Safety information

Important - Please read these instructions fully before installing or operating

supplied with the device additional to the terms set out here.

1. **GRANT OF LICENSE** – Subject to the terms and conditions of this license, Alba grants you the nonexclusive right to use the software within the Alba hardware product. The Alba SOFTWARE can only be used on the Alba manufactured product that it is delivered with.

2. **TITLE** – You have no title, ownership rights, rights to trade secrets, or intellectual rights to the Alba SOFTWARE.

3. **LIMITATIONS** - You may not alter, decrypt, disassemble, decompile, or reverse engineer in part or in whole the Alba SOFTWARE except as permitted by mandatory applicable law.

4. **COPYRIGHT / INTELLECTUAL RIGHTS** – The Alba SOFTWARE is protected by the laws of England and Wales, United States and other applicable International Copyright and intellectual property laws and treaties.

5. NO WARRANTY / LIMITED LIABILITY

A. Alba SOFTWARE is licensed to you.

B. Alba makes not guarantees either expressed or implied as to the correctness, accuracy, reliability, fitness of use for a particular purpose or otherwise of its SOFTWARE. This does not affect your consumer rights set out in the Consumer Rights Act 2015

6. LICENSED COMPONENTS – Within the Alba SOFTWARE are components licensed to

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044 Safety information ALBA 15

Important - Please read these instructions fully before installing or operating

Alba and/or its partners and/or suppliers and such licensors reserve rights that may not be expressed herein. Alba's licensor(s) makes no warranties, express or implied, including, without limitation, the implied warranties of merchantability and fitness for a particular purpose, regarding the licensed materials. Alba' licensor(s) does not warrant, guarantee or make any representations regarding the use or the results of the use of the licensed materials in terms of its correctness, accuracy, reliability, or otherwise. You assume the entire risk as to the results and performance of the licensed materials. Where the exclusion of implied warranties is not permitted by some jurisdictions, this exclusion may not apply to you.

In no event will Alba's licensor(s), and their directors, officers, employees or agents (collectively Alba's licensor) be liable to you for any consequential, incidental or indirect damages (including damages for loss of business profits, business interruption, loss of business information, and the like) arising out of the use of inability to use the licensed materials even if Alba's licensor has been advised of the possibility of such damages. Where some jurisdictions do not allow the exclusion or limitation of liability for consequential or incidental damages, the above limitations may not apply to you.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the



Important - Please read these instructions fully before installing or operating

7. **ILLEGAL USE** – You cannot use the Alba SOFTWARE to engage in illegal activities including the reproduction, storage and/or distribution of copyrighted materials that you do not have the express written consent to.

8. **TRANSFER** – You can permanently transfer your rights to the Alba SOFTWARE through the transfer or the sale of your Alba hardware product to a second party. You must not retain any copy of the software, upgrades, versions, or documentation, and the party to whom you transfer the agreement must make written notice that he accepts the conditions of this EULA.

9. **TERMINATION** – You may terminate this agreement at any time, at which point you cannot use the Alba SOFTWARE. To do so, you must destroy all originals and copies of the Alba Software and all documentation. You can write to Alba for instructions on having the software removed from your device. This license will terminate automatically (without notice from Alba) if any part of this license agreement is violated.

10. **DECOMPOSITION** – If any part or condition of this agreement is held by governing law to be invalid or unenforceable, such part will be enforceable to the extent allowed by law and will have no effect on any other sections of this agreement.

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044.

Safety information



Important - Please read these instructions fully before installing or operating

GOVERNING LAW – This license is governed under the law of England and Wales, If you have any questions about this end user license agreement please write to Argos Ltd (owner of the Alba Brand), 489 Avebury Boulevard, Milton Keynes, MK9 2NW, UK.

Argos declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

 (ϵ)

A copy of the declaration of conformity can be obtained from: Argos Ltd.

489-499 Avebury Boulevard

Milton Keynes, MK9 2NW, UK

ALBA

WI AN Standard Frequency Avg. Power (dBm) 802.11b/g 2412 ~ 2472 MHz 9~10 dBm 802.11n - HT20 2412 ~ 2472 MHz 9~10 dBm 8~10 dBm 802.11n - HT40 2422 ~ 2462 MHz Bluetooth Bluetooth Version Frequency Range Avg. Power (dBm) 2402 ~ 2480 MHz FDR 3~4 dBm BLE 2402 ~ 2480 MHz -4~-3 dBm

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the

Safety information

18

Important - Please read these instructions fully before installing or operating

Open Source Software Offer

The software bundled with this product may include software files subject to certain open source license requirements. Such open source software files are subject solely to the terms of the relevant open source software license. Such open source software is provided on an "AS IS" basis to the maximum extent permitted by applicable law.

For the open source files contained herein, please access "Open source license" section located at: Settings\About tablet\Legal information on the device for the relevant copyright and licensing terms. You may obtain a copy of Apache License, Version 2.0 at http://www.apache.org/licenses/LICENSE-2.0.

You may also obtain a copy of GNU General Public License, Version 2 at the Free Software Foundation, INC, 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA. Until the date that is three years after our last shipment of this product, you may obtain a copy of the source code corresponding to the binaries for any GPL-Licensed file by contacting Argos customer service at http://www.argos.co.uk and Argos will send you a link to such source code or will provide instructions to get the source on a physical medium. This offer is valid to anyone in receipt of this information.

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044.

Safety information



2


You'll be up and running in no time

Ready? Let's begin...

Please read these instructions carefully. They contain important information which will help you get the best from your Alba tablet and ensure safe and correct installation and operation. If you require any further assistance, our technical experts are happy to help. For full details, refer to the product support section at the end of these instructions.

Accessories

22




If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the

You'll be up and running in no time

Charging

- 1. Charge your device by plugging your power cable into the micro-USB port. The device will start charging.
- 2 Press the Power button to turn on the device. You can use your tablet while it charges. Let your device charge completely the first time you use it. Use only the supplied charger.



When your device is completely discharged, you need to charge it for at least 10 minutes before the charging battery icon can be displayed.


Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044



You'll be up and running in no time

Device description

ALBA



If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the 24

You'll be up and running in no time

Device description



(6)

- Camera
- 2 Light sensor
- (3) Volume buttons
- (4) ON/OFF button
- (5) Camera
 - Reset button

Micro-SD card slot
Headphone jack
Micro-HDMI port
Micro-USB port
Loudspeaker
Microphone

You'll be up and running in no time

Starting up

- 1. Before you switch on for the first time, ensure that:
- 2. Your tablet is fully charged
- 3. You have a good WiFi connection (ideally your usual WiFi zone)
- 4. You have your WiFi name and password to hand.

Charging

26

Connect the supplied charger to the device and to a wall outlet. The Alba device will start charging. You can use the device whilst on charge .

Turning the device on

ALBA

Press the ON/OFF button for 2-3 seconds.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the

You'll be up and running in no time

Startup Wizard

The first time you start up your device, the startup wizard will help you set up your device:

- Language
- Date & time
- WiFi connection
- Location service options
- Third-party applications

We strongly recommend that you open a Google account (you need this to download new apps) and we recommend that you answer yes to backing up your tablet to the Google account. This will save your files and settings in case you need to restore your tablet to factory defaults at any point.

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044.



You'll be up and running in no time

Connecting to a WiFi network

Δ Make sure that you are in a WiFi zone.

 Touch 'Settings' to open the WiFi settings menu.
 If the WiFi is off, slide the WiFi switch to the 'ON' position. Once the WiFi is ON, the device will scan for WiFi networks in range.

3. Touch the name of network you want to connect to. Private networks are shown with a lock icon and will require you to enter your password.



If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the

ALBA

28

You'll be up and running in no time

4. When entering a WiFi password, Select 'Show password' so you can see the characters you are typing.

	FFICE
	eurity PA/WPA2 PSK
P	assword
W	ifipassword

\wedge

- To get the correct WiFi password (or settings) for the network, contact the WiFi network provider.

- If your WiFi is on and you are in range of a network that you previously connected to, your device will automatically attempt to connect to it.

- To keep your WiFi connection ON when the device is on sleep, select the Menu icon in the 'WiFi' page. Then select on the right-top corner icon select Advanced > Keep WiFi on during sleep > Always.

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044.

Getting to know your Alba



CANCEL

CONNECT

Getting to know your Alba 8 Tablet You'll be up and running in no time

The Android[™] interface

30

ALBA



If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the

You'll be up and running in no time

- Google[™] Search
 - >Touch "Google" for text search or touch the microphone icon for voice search.
- Android[™] apps shortcuts
 - > Touch to start an application.
- 3 Permanent Android[™] apps shortcuts
 - > Touch to start an application
- (4)
 - All Apps button

> Swipe this icon up to show all the applications and widgets installed on your device. All your downloaded applications are here.



Back button



Home button



Recent apps buttons



The status bar


> Displays notifications and quick settings

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044.



Getting to know your Alba 8 Tablet You'll be up and running in no time

The Android $^{\text{TM}}$ interface



32

ALBA

The quick settings

Touch the top of the screen and pull down to open the notifications. Tap the arrow on the right side to pull down one more time to open the quick settings menu.

- . To access all your settings.
- . Brightness: To adjust the screen brightness.
- 4. Tap on the icon to turn your WiFi on/off connection.
 - . Display the battery percentage
 - Tap on the icon to select a notification option.
- Tap to activate the Flashlight
- 8. Auto-rotate screen: To activate/deactivate automatic screen orientation as you turn your tablet.
- 9. Tap on the icon to turn your Bluetooth connection on/off.
- 10. To activate/deactivate your GPS location system.
 - To turn on/off all wireless connections
 - To edit the quick settings options.

⁽¹⁾New multi-user support for tablets lets different users have their own separate, customizable spaces on a single device.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the

Getting to know your Alba 8 Tablet You'll be up and running in no time

The Android[™] interface

The recent apps

Opens a list of thumbnail images of apps you've worked with recently:

- To open an app, touch it.
- To close an app, swipe it left or right.

Double tap the recent apps button to display fully the last opened application.



Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044. Getting to know your Alba ALBA 33

Using your Alba 8 Tablet

3

Using your Alba 8 Tablet

Let's get started



Moving a home screen icon: touch and hold your finger onto it until the positioning gridlines appear, then slide it to the desired location, and release your finger.

Removing a home screen icon: touch and hold it, slide your finger towards the top of the screen and drop it over the 'Remove' icon.




Uninstalling an application: you can only uninstall downloaded third-party applications. Applications built into the firmware such as some Google apps (e.g. clock, calculator, settings etc.) cannot be deleted, but some may be disabled in 'Settings'. Apps downloaded during the initial set up or afterwards may

be deleted to free up memory space. From the 'All apps' screens, touch and hold the app icon, slide your finger towards the top of the screen and drop it over 'Uninstall' bin. To check which applications are downloaded or built-in, go to 'Settings' then 'Apps'. You can also uninstall apps in 'Settings'.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the Using your Alba

Let's get started



Creating application folders: to organise your apps, drop one app icon over another on the home screen and the two icons will create a folder. You can add many more apps in it. To remove one app from a folder, touch, hold, and drag it to 'Remove' (appearing on the top of the screen). Tap on 'Unamed Folder' to name it.



Changing your wallpaper and widgets: hold your finger on the home screen at an empty location, then touch 'Wallpapers' or 'Widgets' and choose from the list.

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044. Using your Alba

÷	Choose screen lock
	Swipe
	Voice Unlock
	Pattern
	PIN
	Password

Locking the touchscreen: from the quick settings dashboard in the status bar, touch 'Settings'. In 'Settings', scroll down and touch 'Security'. Touch 'Screen lock'. Touch the type of lock you would like to use. After you set a lock, a lock screen is displayed whenever your screen wakes up, requesting the pattern, pin or other specified key.

Downloading new apps:



To download new apps for your tablet touch the Google Play Store icon. There you will find over 1 million apps including many which are free. Even if you only use free apps you will still need to create a Google account but you don't need to enter your credit card details to do this.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the



Backing up your files with your Google account

1. Make sure that you are connected to a WiFi network

2. Make sure the files you want to back-up are added to your Google Drive.

3. Go to 'Settings'. Under Accounts/Google, touch your Google email address and tick all the data you want to back up, including 'Drive'. You can access the data from anywhere you have access to your Google account. If your Google account has not been set up yet, choose 'Add account' and proceed to set up an existing or create a new one.

At the last set up step, choose 'Keep this tablet backed up with my Google account' and all your data will be backed up.

← Sync	۹ :
8 test@gmail.com Google	
Drive Last synced 10/05/2015 19:50	o 💿
Gmail Last synced 13/05/2015 09:19	
Google Fit data Last synced 13/05/2015 10:04	
Google Play Books Last synced 02/05/2015 00:21	-
Google Play Movies & TV Last synced 12/05/2015 19:02	-
Google Play Newsstand Last synced 12/05/2015 19:02	
Google+ Last synced 13/05/2015 10:04	
Google+ Photos Last synced 06/05/2015 18:56	e g

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044. AI RA 39

Using your Alba

Syncing your photos/videos automatically on your Android device

1. Make sure that you are connected to a WiFi network.

2.Go to 'Google Photos' app and select your Google account.

3. Make sure 'Auto-Backup' is turned on < Auto-Backup

4. Select how you want to back-up your photos and videos (over Wifi or mobile network).

5. Go to 'Settings'. Under Accounts/Google, touch your Google email address and verify 'Google Photos' are checked to sync.

- After setting up your account, open 'Photos' app.

- Sign into your Google account.
- In the app Settings, turn on 'Auto Back up'.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the



Let's get started

Transfering files to your tablet:

From a computer, use the USB lead provided in the package box.

From a USB device with a standard male USB connection, you will need to purchase a female USB to micro USB lead in order to connect it (e.g. USB card reader, USB connection from a camera etc.).

Via e-mail, simply add attachments to e-mail messages and send to your Google e-mail address. Then open Gmail, open the message and save the file from e-mail to your tablet memory.

Adding a micro-SD card

You can increase the memory of your tablet quite cheaply by buying a micro SD card. For the position of your micro SD slot see page 24. When you insert the card into your tablet and switch it back on, the tablet will offer you 2 options.

1. Use as portable storage – for moving photos and other media between devices

2. Use micro-SD as internal memory – for storing anything on this device only, including apps.

If your tablet does not automatically offer you the SD options above, you can find them in

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044 Using your Alba 41

Settings – storage – SD card – 🛿 – settings.

If you pick option 1 you can take the card out anytime you like and use it in other compatible devices, e.g. a PC or phone to transfer files e.g. mp3 files, photos etc. Note that in this method you can only store media files, you cannot store Android apps on the card. The operating system will not allow it.

If you chose option 2 (to format as internal memory) you increase capacity for apps as well as files.

However, the memory is truly integrated with the tablet, so if you remove it, you will lose files and apps. So if you pick option 2, its best to pick a large capacity card so you don't ever need to upgrade. It's also very important to use a fast card or the performance of your apps may be affected. We recommend you use App Performance Class A1 cards for integrated storage. The next best choice is to opt for a card with fast read write speeds like Ultra High Speed (UHS) cards. The maximum recommended capacity for this tablet is 64GB.

Note its best to format the card in your tablet before you load anything onto it. Your Android tablet knows what format to use. If you prefer to do this in your PC, the format

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the

42 ALBA Using your Alba

Let's get started

required is FAT32. Your tablet will not work with cards formatted in NTFS or other formats and may not even recognize them.

Improving security on your tablet

Online

In order to avoid online threats we recommend that you install antivirus and security software on your device and keep these and your browser and other software up to date to take advantage of security fixes.

Physical theft

If you store valuable information on your tablet including passwords and logins for personal accounts etc. you may want to enhance the security of your tablet in case it is stolen or lost.

Setting a PIN or password

You can set a pin code (4-8 digit numerical code) or you can set a password which is 4 to 17 digits. We recommend you set a password, the longer and more complex it is the harder it is to break. For the best passwords use a mixture of upper and lower case letters, numbers and special characters such as %, # and *. In 'Settings', select 'Security', then 'screen lock', then select PIN or Password.

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our

experts on 020 8068 1044

Using your Alba



Let's get started

Encryption

As a feature of Android 7, the personal data on your Bush tablet is automatically encrypted to prevent any unauthorized persons getting access to it. So, in the event of your tablet being lost or stolen your data is safe. In order for encryption to be effective you must set an effective password. Security on your device is very effective so remember to write down your password and Google account address and password. In the event that you forget them you will not be able to access your device by any means. We suggest that you write down your account details and passwords in this book and then keep this book in a safe place.

Erasing your personal data

If you sell your tablet on or discard it, you should remove your personal data from it. 1.Remove your Google account

Settings – accounts – Google – select your account then press the (3 dots symbol) and press 'remove account'.

2.Return your phone to factory defaults

Settings – Back up and reset – Factory data reset – reset phone.

If you prefer to be extra sure, you can also use an eraser app.

To download a file eraser, go to Google Play

store, select a file eraser program such as Remo File Eraser – download and install. Open

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the

44 ALBA Using your Alba

Let's get started

the app and follow instructions to securely erase your data..

Further Advice

For further advice on how to stay safe there are government lead initiatives such as Get Safe Online https://www.getsafeonline.org/ which give good advice about a how to avoid a range of security threats. Don't let security issues spoil your enjoyment of your tablet. This manual can also be viewed as a pdf file on the device, to open locate the pdf file in the 'files' folder on the device and touch to open.

NOTE: you may need to install a pdf viewer in order to open this file.

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044 Using your Alba

4

Help is always at hand

Troubleshooting

If your device is frozen:

Press the ON/OFF button for at least 10 seconds or use the hardware reset.

To use the Hardware reset, press the "pinhole reset" button by using a sharp object such as a toothpick.

If your device doesn't turn on:

Charge your device then switch on normally.

If this does not work, press the ON/OFF button for at least 10 seconds or use the hardware reset. To use the Hardware reset, press the "pinhole reset" button by using a sharp object such as a toothpick.

If you want to extend the life of your battery:

Decrease the screen brightness and turn off the wireless connections if not in use.

If your device is functioning too slowly:

Close all apps which are not currently being used.

If your WiFi reception is poor:

Make sure you are not far from the WiFi hotspot.

Update the firmware of the device.

Reset and redefine your connection parameters.

Contact your WiFi connection provider.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the Product support



Help is always at hand

If you want to restore your product (erase all your settings? forgotten password?):

If your device is turned on:

1. Go to 'Settings', under 'Personal', go to 'Backup & reset'

2. Choose 'Factory data reset', then 'Reset tablet': this will erase all your files, settings and applications, so make sure you have backed-up your data in your Google account (see page 39) or a flash drive. Make sure you have your Google account e-mail address and password as without these you will not be able to access your tablet after factory data reset.. This is a security feature designed to deter thieves.

3. When you restart your tablet it will open the Startup wizard again, follow the onscreen instructions (see page 27). The wizard will not download the free apps that were downloaded the first time you did this but most of these are available for free from Google Play Store.

4. Access your Google account to retrieve your backed-up data in Google.

If your device doesn't turn on:

1. Press and hold the Volume + button. Still holding it, press the ON/OFF button for 10 seconds. The tablet will display recovery mode.

2. Press Volume+/- buttons to scroll. Scroll down to wipe data/factory reset

3. Press the ON/OFF button to confirm

4. Scroll down the confirmation screen to Yes – delete all user data - This will erase all your files, settings and applications.

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044. Product support **ALBA** 49

Help is always at hand

5. The tablet will display a working graphic and then offer to reboot.

6. Reboot - the wizard will start as if you had a brand new tablet!

7. Please note, if you use this method to wipe your tablet to pass it on, first remove your Google account or the tablet will still be locked to your Google account.

Charging issues

The most common casue of charging issues on tablets is damage to the USB lead and and USB socket. This is commonly caused by the user charging the tablet while using it and then forgetting it's plugged in and pulling the tablet against the lead.

To avoid such damage charge the tablet overnight rather than in use.

If you do find your tablet won't charge try changing the USB lead. This will often fix the issue.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in



Help is always at hand

Help and assistance

If you require any technical guidance or find that your Alba tablet is not operating as intended, a simple solution can often be found in the Troubleshooting section of these instructions or online at www.argos-support.co.uk

If you still require further assistance, call one of our experts on 0208 068 1044*. Please have the following information ready: 7 digit Argos catalogue code e.g. 123/4567 from your receipt of product packaging or 7 digit PN e.g. 503XXX from the product or packaging

Date of purchase – from your receipt

Helpline business hours:

Monday to Friday 9.00 – 18.00 Saturday 9.00 – 16.00 Sunday Closed

Or e-mail for written support to; argos@cordonweb.com

the **Troubleshooting** section of these instructions, or online at **www.argos-support.co.uk** If you still require further assistance, call one of our experts on 020 8068 1044.

Product support



Help is always at hand

Environmental Considerations

X

Protection of the environment is an important concern to Alba. In order to put this concern into tangible actions, Alba has consciously included a set of methods that favour a respect for the environment into the entire cycle of its products; from fabrication to consumer usage, to final disposal.

Batteries : If your product contains a detachable battery pack, you should only dispose of it in a designated collection point for used batteries.

The Product : The crossed-out wheelie bin symbol on your product signifies that it falls into the category of electric/electronic equipment. Products of this type contain substances that are potentially dangerous to the environment and to human health. Therefore, you should not dispose of the Alba electronic device in a regular trash. As such, the current European directives ask that this device be collected:

At places of distribution in the case of a purchase of a similar electronic product. At locally created disposal areas (waste disposal centres, sorted trash system, etc.) By doing this, you are actively participating in the reuse and recycling of disposed

electronic and electric equipment that could have potential effects on the environment and human health.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the

52 ALBA Product support

Help is always at hand



Your Alba Guarantee

This product is guaranteed for 24 months from the date of original purchase. Any defect that arises due to faulty materials or workmanship will be repaired free of charge (or if applicable the product will be replaced or the purchase price refunded) where possible during this period by the dealer from who your purchased the unit.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in the manual.
- It must be used solely for domestic purposes. The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.

- Specifications are subject to change without notice.
- Alba disclaim any liability for loss or damage arising from the breakdown of the product.
- This guarantee is in addition to and does not diminish your statutory or legal rights.

Troubleshooting section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 020 8068 1044

Product support



ALBA

Contact: www.argos-support.co.uk Helpline: 020 8068 1044

PN: 114361V6

