


Fold


Fold

Important Precautions


1. When lifting and lowering the cover, always lift from the side of the handle. (Figure J)



2. Never lift the cover so that your arm or any part of your body is directly over the cooking surface. Escaping steam can cause serious injury. (Figure K)



3. Do not touch or handle any part of the Red Copper™ 5 Minute Chef besides the handle when the Red Copper™ 5 Minute Chef is plugged in or cooling down. (Figure L)



Cleaning

1. Before cleaning, unplug the unit and let cool completely.
2. Do not put any part of unit in water. Neither the cord nor any component should be immersed in water. The unit is not dishwasher safe.
3. Clean cooking surfaces with sponge dipped in warm, soapy water. Do not use abrasive cleaners on any of the surfaces.
4. Dry with a soft towel or allow to air dry.
5. If you notice burnt food stuck to areas of the cooking surface, remove it by putting a small amount of cooking oil on the area and waiting 10 minutes. Next, remove the food with a soft sponge. Wipe clean with a damp cloth, then dry the unit. If the food continues to stick, repeat this step and wait longer, up to several hours.
6. Before storing, make sure the unit is completely dry and clean. Lock the latch to store unit, if necessary.

www.highstreettv.com

DISTRIBUTED BY: **high street tv**
 High Street TV,
 PO Box 724,
 Altrincham,
 WA15 5BJ

Back



IMPORTANT SAFETY INSTRUCTIONS
READ AND FOLLOW ALL WARNINGS AND INSTRUCTIONS BEFORE USING THIS PRODUCT. INJURY CAN RESULT FROM IMPROPER USE.
SAVE THESE INSTRUCTIONS - HOUSEHOLD USE ONLY

WARNING



General

1. Read and follow all warnings and instructions. Use only as instructed. Failure may lead to injury to persons or property.
2. For household use only. Not for outdoor or commercial use. Do not use other than for intended use.
3. Remove all packaging before using. Use only with included accessories. Using accessories or attachments not recommended by the manufacturer may cause injuries or damage the unit. Clean before first use following cleaning instructions on back.
4. Not for use by children. This product is not a toy. Close supervision is necessary when this unit is used near children.
5. Do not lock latch while on. Lock latch for storage only. The latch will fall into a down position, but only locks when you push firmly. (You can usually hear a click when the latch locks.)

Using the Red Copper™ 5 Minute Chef

1. Do not leave unattended. Carefully monitor unit whenever plugged in or cooling.
2. Do not lock latch while on. Locking latch may cause pressure build-up and forceful release of steam and hot food.
3. Always follow recipe instructions. Do not overfill cooking well. Excess food in cooking well could cause pressure build-up and forceful release of steam and hot food.
4. When opening, keep arm and body to side of unit, not directly above the cooking surface. Heat and steam can escape from the unit during opening. (Figure 1 & Figure 2)

Burn and Fire Hazards



5. Do not touch hot surfaces. Use handle to open and close unit. Use oven mitt when touching any part of unit other than the handle while operating. (Figure 3)
6. Use extreme caution when moving unit containing hot oil or other hot liquids to avoid spills.
7. Unplug unit to turn it off. Let it cool completely before handling, cleaning, or storing.
8. Keep away from flammable fumes or liquids. Do not use in the presence of explosives.
9. Use and store away from sources of water, heat, or fire. Do not place on or near a hot gas or electric burner, or on or in a heated oven.

Protecting the Unit

10. Do not use sharp or metal kitchen utensils on unit's cooking surface. They can scratch or damage the surface.
11. Unit is not dishwasher or oven safe. Always follow cleaning instructions.

Electrical Safety

1. Unplug from outlet when not in use and before cleaning. Allow to cool completely before putting on or taking off parts, and before cleaning unit.
2. Do not operate unit with a damaged cord or plug, or if unit malfunctions or has been damaged in any manner. Return unit to the nearest authorized service facility for examination, repair or adjustment.
3. Do not abuse the cord. Do not carry the unit by the cord or yank the cord to disconnect.
4. Do not let cord hang over edge of table, counter, or sharp edges, or touch hot surfaces.
5. Do not immerse cord, plugs, or unit in water or other liquid.
6. Do not operate unit if the power cord has received a sharp blow, been dropped, or otherwise damaged in any other way.
7. The use of accessory attachments not recommended by the manufacturer may cause injuries.

Shock Hazards

Front

CAUTION


1. A short power-supply cord (or detachable power-supply cord) is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
2. Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.
3. If a long detachable power-supply cord or extension cord is used:
 - 1) The marked electrical rating of the cord or extension cord should be at least as great as the electrical rating of the appliance;
 - 2) The longer cord should be arranged so that it does not drape over the countertop or table top where it can be pulled on by children or tripped over unintentionally.

Before First Use

Clean the cooking surfaces by using a soft sponge that has been dipped into warm soapy water. Dry with a soft towel or allow to air dry. Do not immerse in water.

Product Components

- A. Cooking Top Surface
- B. Cooking Well
- C. Latch (lock latch for storage only)
- D. Handle
- E. Cover
- F. Red Indicator Light
- G. Green Indicator Light
- H. Power Cord
- I. Spatula



PRODUCT MAY VARY FROM IMAGES SHOWN

How to Use

You can make more than omelettes with the Red Copper™ 5 Minute Chef. These instructions show how you can make omelettes without flipping the unit. Please refer to the recipe book for other cooking ideas. Always follow safety and recipe instructions.




Figure A

1. Place the Red Copper™ 5 Minute Chef on a flat, dry, sturdy surface and plug in the power cord. The cooking surfaces are heating when the red indicato light is on. (Figure A)




Figure B

2. In one bowl, whisk 2 medium/large eggs. Do not use larger eggs. Using larger eggs may result in overflowing. Put desired fillings, if any, in separate bowl. Do not exceed 1 cup of combined eggs plus filling. (Figure B)




Figure C

3. The cooking well is ready for your food once the green light becomes illuminated. (Figure C)




Figure D

4. Raise the lid with care. You may wish to add a small amount of butter or oil to the cooking surfaces, though it is not necessary. Pour fillings into the cooking well. Stir gently with the provided spatula until heated adequately. (Figure D)




Figure E

5. Pour eggs into the cooking well. The eggs and filling should never come to the top of the cooking well. (Figure E)

WARNING: Burn hazard.

Excess food in cooking well could cause pressure build-up and forceful release of steam and hot food.




Figure F

6. Close lid. Take care not to lock the latch located on the front of the unit while cooking. Allow the eggs to cook for 3 to 4 minutes. (Figure F)

WARNING: Burn hazard.

Locking latch may cause pressure build-up and forceful release of steam and hot food.




Figure G

7. No flipping needed for a perfectly cooked omelette. (Figure G) When your omelette is done cooking, use handle to carefully open the lid.

WARNING: Burn hazard.

- Keep arm and body to side to prevent potential burns from escaping steam or heat.
- Always use oven mitt when touching any part of exterior other than handle.
- Use care when handling hot food.




Figure H

8. When your omelette is done cooking, open the lid carefully from the side. (Figure H) Refer to the Important Precautions Section (on the next page) for proper lid opening technique. Careful when opening, contents will be very hot.




Figure I

9. Use the provided spatula to remove the omelette from the Red Copper™ 5 Minute Chef. (Figure I)

WARNING

- Do not use sharp or metal kitchen utensils that can damage the surface of the unit.
- Before cleaning, moving, or storing your unit, unplug and allow it to cool completely.
- Always follow cleaning instructions.



Continue on back