




5+




# FOLDING T-MOTION SCOOTER

## UNFOLDING THE SCOOTER


TO BE SUPERVISED BY AN ADULT.



Pull the 'handlebar lock' to release.




Pull up the handlebars to a vertical position.



Ensure the 'handlebar lock' is pushed back down to lock the bars in position.



## FOLDING THE SCOOTER

TO BE SUPERVISED BY AN ADULT.



Pull up the 'handlebar lock' to release.

Push down the handlebars




Ensure the 'handlebar lock' springs back to lock in position.


## ADJUSTING THE HANDLEBAR HEIGHT

TO BE SUPERVISED BY AN ADULT.

Loosen the handlebars stem adjuster & pull out handlebars...




...until the button pops out.



Push in the button and pull the handlebars up and down until it is the correct height for your child.

There are three height options




When at the desired height, screw tight the stem adjuster.

## STEERING THE SCOOTER

TO BE SUPERVISED BY AN ADULT.

The T-Motion is a 'Lean and Steer' Scooter.  
So instead of turning the handlebars, you lean them to the left or right.



## TO USE

TO BE SUPERVISED BY AN ADULT.

1. Grip the handle bars with your hands, place one foot on the deck and the other foot on the ground.
2. Pay attention to your surroundings and make sure that your riding area is clear.
3. Kick backwards with your foot beside the scooter to give you motion.
4. Repeat this kicking action in order to stay in motion.
5. To stop or slow down, place your kicking foot on the brake pedal above the rear wheel to slow down, then put your kicking foot on the ground.
6. Do not over-steer as this could cause you to fall off the scooter.

## IMPORTANT SAFETY INFORMATION

1. The product is recommended for users of 5 years and up.
2. After checking that all parts are in good condition, remember to check that all the screws and wheels are tightly in place before using the scooter. (Hex keys are supplied to tighten these if necessary)
3. Remember to wear a helmet, knee pads, wrist pads, elbow pads, protective clothing and proper shoes.
4. The maximum weight that this product can hold is 80kg.
5. The scooter must only be used by one rider at a time.
6. Do not use this product for jumping stunts or tricks. The scooter is not designed for such use.
7. This product is not a road vehicle and should be used for leisure purposes only.
8. Do not use this product at night, poor weather (rain, snow or poor visibility) or around heavily populated areas (pavements, streets, muddy areas, rocky surfaces and slippery surfaces). We recommend that you use this product in a park or other open space.
9. Do not take this product apart.
10. The brake will get hot from continuous use. Do not touch after braking.
11. Do not take this scooter on the road or public highway.

## WARNING!

Warning! Not suitable for children under 36 months, due to small parts. This scooter must be assembled by an adult.

The scooter is not designed to be dropped when not in use. If the scooter is dropped after use, over a period of time you will damage the plastic end piece, the foam and the aluminium tubing. If you damage this part of the scooter, it is strongly advised that you replace the damaged parts as soon as possible to avoid any accident caused by making contact with these parts.

The scooter should not be used on any other surface other than on flat even ground. It is not designed for graveled roads, on grass surfaces or any other uneven surfaces as this could cause not only damage to scooter but also the rider.

Warning: Protective equipment should be worn. Not to be used in traffic. 80kg max. The scooter shall be used with caution, since it requires great skill, so as to avoid falls or collisions causing injury to the user and the third parties.

Adult supervision is recommended

CAUTION! PLEASE REGULARLY CHECK THAT ALL FIXINGS INCLUDING WHEELS ARE TIGHTENED DURING USE

- Never ride the scooter without tightening the scooter
- Check all clamping devices for tightness and foot brake prior to riding

## MAINTENANCE

1. After use, please wipe the product with mild detergent.
2. Do not leave this product in high temperature, intense sunlight or dusty areas.
3. Store in a dry place.
4. Always make sure all screws and nuts are securely tightened before every use.
5. No modification other than to the manufacturer's instructions shall be made.
6. Please rotate the bearings and wheels to check if they are rolling smoothly.
7. It is suggested to clean and add lubricant every 6 months paying extra attention to the moving parts, clearing them of grit and dirt so they move freely.
8. Self-locking nuts and other self-locking fixing may lose their effectiveness over time. If any of these components are no longer functioning how they should, it is strongly recommended that you discontinue use of the product and seek replacement parts from the dealer or importer of this product.

## CUSTOMER HELPLINE

Hy-Pro advise you to contact us directly and not to return this item to the place of purchase. Hy-Pro has taken great care to ensure this item has reached you in good condition, should you have a query please ring our helpline 0800 731 0006 where your call will be dealt with promptly. Alternatively, please email: [customerservices@zincq.com](mailto:customerservices@zincq.com).

REMOVE ALL THE PACKAGING AND ASSEMBLE BEFORE GIVING TO A CHILD.

**HY-PRO**  
LU5 5BN, UK

Hy-Pro House, Centrus Park, Arenson Way,  
Dunstable, Bedfordshire LU5 5BN. UK  
[www.hy-pro.co.uk](http://www.hy-pro.co.uk)  
[www.zincsports.com](http://www.zincsports.com)

- Complies to EN14619:2015. Maximum weight 80kg for Class A
- PLEASE RETAIN PACKAGING AND MANUAL FOR FUTURE REFERENCE
- COLOUR & CONTENTS MAY VARY FROM THOSE SHOWN ON PACKAGING

