

# London Clock





## COMPANY

Thank you for your purchase of this radio controlled alarm clock. Please read these instructions carefully and keep the manual for future reference.

### INSTALLATION

1. Place your clock face down on a flat and soft surface.
2. Remove the battery cover at the back of the clock.
3. Insert 3 x new AAA batteries into the battery compartment by observing the correct "+" and "-" polarity.
4. Replace the battery cover.

### FUNCTION



# London Clock C O M P A N Y

## TO SET THE TIME, 12/24 AND CALENDAR

Please note that during the below process, if the clock is left untouched for 10 seconds, the clock will return to normal time display mode.

1. Press and hold the "SET" button on the top of the clock for 4 seconds until 12Hr flashes on the display. Use the ▲ and ▼ buttons on the top of the clock to select 12Hr or 24Hr. If you select 12Hr format, AM or PM will appear on the left hand side of the display to indicate morning and afternoon time. Press the "SET" button to confirm.
2. The hour digit will now flash. Use the ▲ and ▼ buttons on the top of the clock to select the correct hour. (Press and hold the ▲ and ▼ buttons to accelerate setting). Press the "SET" button to confirm.
3. The minute digits will now flash. Use the ▲ and ▼ buttons on the top of the clock to select the correct minute. (Press and hold the ▲ and ▼ buttons to accelerate setting). Press the "SET" button to confirm.
4. The display will now show Zz and 05 will flash. Use the ▲ and ▼ buttons on the top of the clock to select the desired snooze duration. Please note that the snooze duration can be changed to between 5 and 60 minutes. (Press and hold the ▲ and ▼ buttons to accelerate setting). Press the "SET" button to confirm.
5. The year will now flash. Use the ▲ and ▼ buttons on the top of the clock to select the correct year. (Press and hold the ▲ and ▼ buttons to accelerate setting). Press the "SET" button to confirm.
6. The month will now flash. Use the ▲ and ▼ buttons on the top of the clock to select the correct month. (Press and hold the ▲ and ▼ buttons to accelerate setting). Press the "SET" button to confirm.
7. The date will now flash. Use the ▲ and ▼ buttons on the top of the clock to select the correct date. (Press and hold the ▲ and ▼ buttons to accelerate setting). The day will set automatically according to the date. Press the "SET" button to confirm and return to normal time display.

## TO SET ALARM 1

Please note that during the below process, if the clock is left untouched for 10 seconds, the clock will return to normal time display mode.

1. Press the "AL 1" button on the top left hand side of the clock once, 6:00 will appear on the display and A1 will appear on the lower right hand side of the display.
2. Press and hold the "AL 1" button for 4 seconds until the hour digit begins to flash. Use the ▲ and ▼ buttons on the top of the clock to select the desired hour for Alarm 1. (Press and hold the ▲ and ▼ buttons to accelerate setting). Press the "SET" button to confirm.
3. The minute digit will now flash. Use the ▲ and ▼ buttons on the top of the clock to select the desired minute for Alarm 1. (Press and hold the ▲ and ▼ buttons to accelerate setting). Press the "SET" button to confirm and return to normal time display.



## TO SET ALARM 2

Please note that during the below process, if the clock is left untouched for 10 seconds, the clock will return to normal time display mode.

1. Press the "AL 2" button on the top right hand side of the clock once, 6:00 will appear on the display and A2 will appear on the lower right hand side of the display.
2. Press and hold the "AL 2" button for 4 seconds until the hour digit begins to flash. Use the ▲ and ▼ buttons on the top of the clock to select the desired hour for Alarm 2. (Press and hold the ▲ and ▼ buttons to accelerate setting). Press the "SET" button to confirm.
3. The minute digit will now flash. Use the ▲ and ▼ buttons on the top of the clock to select the desired minute for Alarm 2. (Press and hold the ▲ and ▼ buttons to accelerate setting). Press the "SET" button to confirm and return to normal time display.





## TO TURN THE ALARM ON AND OFF

With the clock in normal time display:

1. Press the "ALM ON.OFF" button on the top of the clock once to activate Alarm 1.  will appear to indicate Alarm 1 is activated.
2. Press the "ALM ON.OFF" button on the top of the clock once again to activate Alarm 2.  will appear to indicate Alarm 2 is activated.

# London Clock

## COMPANY

3. Press the "ALM ON.OFF" button on the top of the clock once again to activate both Alarm 1 and Alarm 2.
2.  and  will appear to indicate both Alarm 1 and Alarm 2 is activated.
4. Press the "ALM ON.OFF" button on the top of the clock once again to deactivate both Alarm 1 and Alarm 2.  and  will disappear to indicate both Alarm 1 and Alarm 2 are deactivated.

### TO STOP AND RESET THE ALARM TO COME ON THE NEXT DAY

When Alarm 1 or 2 is sounding, the related alarm icon will flash. Press the "ALM ON.OFF" button on the top of the clock once to stop the alarm and reset it for the following day. The alarm icons will remain on the display.

### TO ACTIVATE THE SNOOZE FUNCTION

When the alarm is sounding, the related alarm icon will flash. Press the "SNOOZE.LIGHT" button on the top of the clock to snooze the alarm. The default snooze duration is 5 minutes but this can be changed to between 5 and 60 minutes.

**Please note that the duration of the alarm is 2 minutes.**

### TO ACTIVATE THE WAKE-UP LIGHT FEATURE

This clock has a colour changing wake-up light function. When the alarm is sounding, the colour changing side lights will be activated. The colour changing function involves the side lights flashing through a series of 7 colours. These lights will automatically be activated when the alarm is sounding.

1. To activate the side lights in normal time display, press the "SNOOZE.LIGHT" button on the top of the clock twice – this will activate the side lights to one colour for 5 seconds.
2. Press and hold the "SNOOZE.LIGHT" button on the top of the clock for 5 seconds to activate the series of colour changing side lights. The lights will be activated for 45 seconds and will flash through the series of colours.

**Please note that constant use of the backlight/side lights will significantly reduce battery life.**

### TROUBLE SHOOTING

If your clock displays irrelevant time or does not function properly, reset the clock by pressing the "RESET" button on the top of the clock. The clock will be reset to default settings and you will need to set it again.


### Care instructions

- Wipe clock with a soft dry cloth only.
- Replace battery every 12 months or when the clock stops.

### Battery safety & disposal

- Dispose of batteries and electrical products responsibly at local authority household waste recycling facility.
- **DO NOT dispose of batteries in a fire as the batteries may explode or leak.**
- Never use rechargeable batteries.
- Replace all batteries at the same time; NEVER mix new and used batteries, different types or brands.
- Never try to dismantle batteries.
- Never short circuit batteries.
- Exhausted batteries must be removed from the clock promptly.
- Remove batteries from the product before extended storage.



This symbol  indicates that this product, and any batteries, should not be disposed of in normal household waste but taken to appropriate local recycling centres, where available. Never throw batteries in a fire or attempt to open outer casing.

# London Clock

COMPANY