
PENTON - Sideboard

Assembly Instructions - Please keep for future reference

462/7757



Dimensions

Width - 92cm

Depth - 42cm

Height - 84cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400 800



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.

- This product has been produced from natural timber; you may notice some variation in the grain and colour of different component parts which is normal for furniture produced using natural wood and is not the result of any manufacturing fault.
- The product has been treated with a wax and oil finish to prevent dirt ingress and preserve moisture.
- On unpacking the furniture you may notice an odour due to this treatment; this will disappear once the furniture is unpacked and assembled after a period of time.
- This process may leave some staining on the packaging material; please take care to ensure this does not transfer to clothing or carpeted surfaces during assembly.



 We do not recommend the use of power drill/drivers for inserting screws,

as this could damage the unit. Only use hand screwdrivers.

- Parts of the assembly will be easier with 2 people.
- Dispose of all packaging carefully and responsibly.


Care and maintenance

- Use an appropriate furniture polish for natural wood furniture and a dry cloth to clean the product.
- Avoid placing the furniture in direct sunlight as this will cause the timber to prematurely age.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels

Please check you have all the panels listed below



(69.6 x 30.4cm)



Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 03456 400 800**

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A Wooden dowel x 18	B 14mm Screw x 27	30mm Screw x 8
D ☐ 35mm Screw x 18	22mm Bolt x 8	Metal dowel x 8
G Locking nut x 8	Nail x 32	Door hinge x 4
Drawer handle x 2	Door handle x 2	Clip x 2
M Plug x 2	Shelf support x 4	Metal bracket x 1
Washer x 2	Wall strap x 1	B Door spacer x 1

Tools required



Ruler - Use this ruler to help correctly identify the screws

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

Step 1

Fixing right front frame to the right side panel (Two people required for an easier assembly).

- a: Insert right side panel
- 2 into right front frame
- 7 through joints.

Note:
Before fixing blocks 19 into place it is important to ensure that the slot and groove of parts 2 and 7 are fully pushed together and lined up correctly at the top and bottom.

b: Place blocks 19 between the two marks as shown. First fix to the side panel using screws **D**.

C: Fix front frame through blocks 19 using screws **D**.


Step 2

Fixing left front frame to the left side panel (Two people required for an easier assembly).

- a: Insert left side panel
- 3 into left front frame
- 8 through joints.

Before fixing blocks 19 into place it is important to ensure that the slot and groove of parts 3 and 8 are fully pushed together and lined up correctly at the top and bottom.

b: Place blocks 19 between the two marks as shown. First fix to the side panel using screws **D**.



Step 3

Fitting Metal dowels.

Screw metal dowels finto right side panel 2, left side panel 3 and top panel 1.




Note: Insert metal dowels as far as shown.

Do not over tighten.

Step 4

Insert dowels **A** into the indicated parts.

Insert shelf supports (1) into the right side panel 2 and left side panel 3.




Step 5

Fixing side drawer runners.

a: Fit side drawer runner 18 to the right side panel 2. Fit and push dowels into the front frame first.

b: Attach side drawer runner using screw **D**.


Repeat step 5 for the left side panel 3 and side drawer runner.



Step 6


Assembling parts.

Put parts 10 and 16 together as shown in the diagram.



Step 7

Insert the assembled frame and top front frame 9 into the holes on left side panel 3.



Step 8


Fixing base panel.

With help, fit base panel 4 to the left side panel.

Insert 2 locking nuts **G** into base panel where shown.

Use a screwdriver to turn locking nuts **G** clockwise to lock.

Do not over tighten.



Step 9

Fixing right side panel.

With help, place right side panel 2 properly ensuring dowels and front frames are all fit into their holes at the same time.


Insert 2 locking nuts **G** into base panel where shown.


Use a screwdriver to turn locking nuts **G** clockwise to lock.

Do not over tighten.



Fix metal bracket o in the base panel 4 and bottom front frame 10 using screws 3 as shown.





Step **11**

Fixing top panel.


Important:
With help, carefully stand the product upright.


With help, fit top panel 1 to the cabinet.

Insert 4 locking nuts **G** into side panels where shown.

Use a screwdriver to turn locking nuts **G** clockwise to lock.

Do not over tighten.








Step **12**

Fitting hinges to doors.

Attach hinges ① in the pre marked holes on doors 15 using screws ③ as shown.




Step **13**

Hanging doors.

a: With help, centralise the doors in the opening of the cabinet using the door spacer to ensure correct spacing, as shown.

b: From inside the cabinet fix the hinges using screws **B** as shown.

Note:
To ensure the alignment of the doors is correct, centralise the doors in the opening before attaching to the cabinet.



Step 14


Hinge adjustment.

a: To move doors up or down: loosen screws shown and move doors to suit.

Once doors are aligned, re-tighten screws.

b: To move doors left or right: loosen screws shown and move doors to suit.

Re-tighten screws.



Step **15**

Fitting door lock.

a: Screw clip in place using screws.
Ensure that the 2 small wheels are flush with the edge of the base as shown in the diagram.

b: Insert plug **@** into clip **•**, ensuring they are leveled as shown in the diagram.


C: Push the door against the plug **M**. This will make 2 small marks on the door as shown in the diagram.

d: The door can then be opened and plug can be screwed into place using the 2 marks made as a guide. This will ensure that the 2 parts of the door clips are lined up correctly.

Step 16

Fitting handles to doors.

Attach handles to the doors using bolts as shown.



Step **17**


Drawer assembly.

a: Attach drawer sides **17** to the drawer front


11 using screws **G**.


b: Slide drawer bottom

14 into slots on drawer sides and position drawer back 12 in place.




d: Using bolts **(3)** attach drawer handles **(3)** to drawer front.





Step **18**

Insert drawer into unit.
With the back of the drawer past the front frames, use a hammer to tap dowels (A) in flush to drawer sides. This is a safety catch to stop drawer falling out.




Step **19**

Position shelf **5** into place. Make sure round edge is facing front.



Note: This shelf is adjustable.



Step **20**


Fixing back panels.


Important:
Cabinet MUST be 'square' when back panels are attached.


a: Attach small back panel 13 at the top first using nails **H**.


b: Position profile **6** onto back panel (just attach).

C: Carefully slot the second back panel **13** into the profile and fix it to the cabinet using nails **1**.











Step **21**

Fixing to wall.

Furniture must be fixed to a wall. Fix wall strap ② to top of furniture using washer ② and screw ③. With help, move furniture into position. **Note:** Wall plugs not supplied. The correct type of fixing must be used for your wall, seek professional advice if in doubt.





Assembly is complete.

If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400 800

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.



Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualifed tradesperson if you are unsure.


Hints:

- 1: General rule: Always use a larger screw and wall plug if you are not sure.
- **2:** Ensure you use the recommended drill bit to match the wall plug and hole size.
- **3:** Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- **4:** Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- **5:** Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.



Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.