

RELAXER



Padded Relaxer

Maximum weight loading 110kg

**IMPORTANT, RETAIN FOR FUTURE REFERENCE:
READ CAREFULLY**

We care about our quality and what you think,
If you have any comments, good and bad,
Please contact us via our website www.culcita.ie


Your statutory rights are not affected.

Produced in Ireland
Culcita Ltd.
Butlersland, New Ross, Co. Wexford.


Safety

- Occasional outdoor furniture for domestic use.
- Maximum weight loading 110kg (17.3 stone approx.).
- Always place the seat on a firm level base and ensure that the chair legs remain in contact with the ground at all times.
- Do not use without the plastic feet attached or with armrests and leg hinges in the locked position.
- Do not stand on this relaxer or sit on the arms.
- Take care when opening or adjusting; keep hands away from moving parts in order to prevent injury.
- Children using the relaxer should be closely supervised by an adult.
- Plastic bags can be dangerous. To avoid danger of suffocation keep bags away from babies and children.
- Carelessness causes fire.

Unfolding the relaxer



1. Fit the four plastic feet into the underside of the legs and ensure that the notch fits into the punched holes (figs. 1 & 3). When you unpacked the frame, the plastic feet are attached to the frame on the knee bar (see Fig. 4)
2. Place the relaxer on a flat level surface and push apart the seat and back support to open the relaxer fully (fig. 4). Ensure the hinges on the rear legs are in the fully locked position (fig. 2).
3. Fit the pocket at the top of the cushion over the backrest and slide the cushion strap under the footrest (fig. 5).
4. Secure the cushion to the chair using the ties at the side.
5. **Press down on both armrests** to fully engage the armrests before sitting on the chair.
6. To move the backrest to a more upright position, sit forward to release the pressure on the backrest, lift the armrests and pull the armrests forward. To move the backrest to a more reclined position, lift the armrests and move them backwards (fig. 6).
7. Once the backrest is in the desired position, **push down on the armrests** and ensure that both armrests are fully engaged before placing your weight on the backrest.
8. To fold the relaxer, remove the cushion and reverse the above steps.



Care and Maintenance

- Take care with sharp items in pockets and metal trims on clothing as these may damage the fabric of the relaxer cushion.
- The cover and frame can be cleaned with a damp cloth soaked in warm water and mild detergent. Never machine-wash the cushion or its cover, sponge clean only. See cushion sewn in label for further details.
- Allow the relaxer to dry completely before storing in a cool, dry location.
- Remove the cushion from the relaxer when not in use, and store in a dry location.
- The cushion of this chair complies with Furniture and Furnishings (Fire) (Safety) Regulations 1988. This cushion does not include a schedule 3 interliner. Cover and filling are cigarette resistant. All covers are match resistant. All filling and covers have been tested to ensure compliance with the relevant ignitability test.