

XRocker®

WRAITH



Multimedia Floor Rocker

User Manual Item no: 00

Need Help? Email: Service@XRockerNation.co.uk

Phone: 01274 683 109 www.XRockerNation.co.uk

IMPORTANT: You must keep your original retail receipt as proof of purchase.



Thank you for purchasing this X Rocker gaming chair. You are now close to enhancing your favourite games with **glorious audio!**

To get started, please assemble the chair using the assembly instructions on the separate leaflet and then follow the instructions in this manual to **get rocking!**



Table of Contents

About X-Rocker	2
Box contents	4
Control panel overview	5
Wired connection guide: TV (All consoles)	6
Connect by controller (PS4 only)	7
Wired connection guide: PS Vita.....	8
Troubleshooting tips	9
Health and safety information	10
Warranty Page	11


Box Contents

For technical support please visit our website: www.x-rocker.co.uk/support


A. X-Rocker Wraith




B. Control Panel




B1. 3m RCA to RCA Audio cable




B2. Power supply cable




B3. RCA female to female adapters




B4. 1m 3.5mm to 3.5mm audio cable



Control Panel Overview



Wired connection guide: TV (PS3 and PS4 systems)




1. Connect **B1** Cable to X Rocker control panel 3.5mm **INPUT** socket
2. Connect other end of the **B1** cable to the TV headphone socket.
3. Once connected to your TV, increase volume to 50% of the maximum for the best sound level.**

***N.B:** If your TV does not feature a headphone socket then you may need to purchase an additional TOSlink adapter to get connected directly to a console for audio.

******Depending on your TV you may need to Increase the headphone volume separately in the TV sound settings.

Connect by controller: (PS4™ systems only)




1. Connect the **B1** cable to the bottom of the PS4 controller via the headset socket.
2. Connect the other end of the **B1** cable to the chair via the green port.
3. With the PS4 turned on and in the main menu, **press and hold** the black PS button until the quick menu appears.
4. In this menu select **[Adjust sound and devices]**
5. Then select **[output to headphones]**
6. Change the setting from **[Chat Only]** to **[All audio]**
7. Make sure the volume in the previous menu is set to the maximum.

Wired connection guide: PS Vita

To connect:

Connect one end of the **B1** 3.5mm audio cable into the headphone socket on the chair then connect the other end to the headphone jack located on the PS Vita.



*The above steps can also be used to connect a Tablet, Phone, TV, Wireless DAC or MP3 player to the chair.
Note: compatibility not tested nor endorsed by Sony Interactive Entertainment Europe.

Troubleshooting

Issue	Troubleshooting steps
No power going to control panel	<ul style="list-style-type: none">• Make sure that the power cable is connected correctly.• Make sure that the power supply at the power source is working correctly.• With the chair turned to the ON position, give the power cable a slight wiggle in the port. If any lights flicker (or not) then please contact support (details below).
No sound	<ul style="list-style-type: none">• Connect a mobile phone to the X Rocker using the phone connection guidelines in the manual to test the chair for sound.• Confirm that the device/system is correctly configured as per previous connection guide.• Make sure that you indeed have a headphone socket on your TV. This will typically be marked with a headphone symbol or “H/P OUT”
Stereo speakers do not produce sound / sound is faint	<ul style="list-style-type: none">• Please make sure that the volume of the source device is at a higher level to strengthen the audio signal.
The cables connected to my X Rocker have been broken accidentally	<ul style="list-style-type: none">• Please contact X Rocker support (service@XRockerNation.co.uk) regarding this issue.
Don't have a headphone socket on your TV?	<ul style="list-style-type: none">• You may need to purchase a TOSlink adapter. If you are unsure as to which to purchase then please contact X Rocker at service@XRockerNation.co.uk regarding this issue.

Health and Safety

- Avoid immersing or allowing the X Rocker to come into contact with liquids.
- Please consult X Rocker Support before unscrewing any of the electrical components on the chair.
- Please be mindful of any cabling laid out between the X Rocker and power source/audio device.
- Please be mindful of cabling attached when moving/swivelling the X Rocker.
- If the cables or electrical equipment are broken then this may present a choking risk, please contact Support for replacements and dispose of these parts safely.
- Do not stand on the X Rocker or exceed the 120kg weight limit via other means.
- Do not lean back on the chair to the point in which the pedestal would lift off the ground.
- X Rocker armrests are designed for support and comfort during gameplay, please do not use these as support for getting in/out of the chair.
- Playing audio for long periods at loud volumes may contribute to difficulties in hearing.
- Please be considerate to others when playing audio through the X Rocker speakers at higher volumes.

Warranty Page

Limited Warranty:

Ace Casual warrants this product against defects in material and workmanship for a period of 1 year from the date of purchase. This warranty is enforceable only by the original purchaser. ALL DAMAGED OR MISSING PARTS MUST BE REPORTED WITHIN 14 DAYS OF PURCHASE. This warranty covers all defects in material and workmanship in this product, but DOES NOT COVER the following:

I. Damage, deterioration or malfunction resulting from:

- a. Acts of God, accident, misuse, abuse, negligence, improper installation, maintenance or operation, or failure to follow the instructions contained in this owner's manual.
 - b. Any damage in the shipment of the product. (Claims must be presented to the carrier.)
 - c. Repair, attempted repair, or modifications by anyone other than the Ace Casual Service Center.
2. Any unit which has been modified or attempted to be modified or altered in any way whatsoever.
 3. Normal wear and periodic maintenance.
 4. Any unit used for industrial or commercial purposes (including rental).
 5. Products sold AS IS or WITH ALL FAULTS, or consumables (such as fuses, batteries, etc).
 6. Customer installation, set up adjustments, or signal reception problems.
 7. Consequential loss or damage as a result of misuse of improper connections.

Ace Casual will repair or replace (at its discretion) units covered by this warranty without charge to the consumer for labor or materials. YOU ARE RESPONSIBLE FOR INITIAL SHIPPING CHARGES. However, we will pay the return shipping charges to any destination within the European Union if repairs are covered by the warranty.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. ACE BAYOU SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESSED OR IMPLIED WARRANTY ON THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE LENGTH OF THIS WARRANTY.

Operation is subject to the following two conditions:

1. This device should not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

DO NOT SHIP ANYTHING TO US WITHOUT CONTACTING US FIRST. DO NOT SHIP ANY PARTS OR WHOLE UNITS TO THIS ADDRESS FOR REPAIR WITHOUT OUR PERMISSION.



Where you see the Crossed Out Wheelie Bin symbol it means that this product can be recycled and should not be disposed of in normal household rubbish. If you are in the EU, please take it to a collection point for the disposal of Waste Electrical and Electronic Equipment (WEEE) for recycling. For all other countries please adhere to local recycling laws for electrical and electronic equipment. The recycling and processing of Waste Electrical and Electronic Equipment will make a significant contribution towards helping protect the environment by reducing landfill waste.

Manufactured by:
Ace Casual Corp.
1040 Higgs Road
Lewisburg, TN 37091
www.acecasual.com
1.866.969.2603
Made in China

Licensed for sale in Europe. For use exclusively with PlayStation(R) 3, PlayStation(R) Vita and PlayStation(R)4. "PS", "PlayStation", "PS3", "PS4", and "PSVITA" are registered trademarks of Sony Interactive Entertainment Europe. All rights reserved. MP3 player compatibility not tested nor endorsed by Sony Interactive Entertainment Inc. Please retain this packaging for future reference.

UK based customer support: **01274 683 109**
www.xrockernation.co.uk | service@xrockernation.co.uk



**Need Help? Email: Service@XRockerNation.co.uk
Phone: 01274 683 109
www.XRockerNation.co.uk**

IMPORTANT: You must keep your original retail receipt as proof of purchase.