

DISPOSAL OF ELECTRIC AND ELECTRONIC EQUIPMENT

The consumer has a significant role to play in reducing the impact of waste electrical and electronic equipment, batteries and accumulators on the environment, through re-using or recycling such articles.

Some batteries and accumulators and some of the components used in electrical and electronic equipment may contain hazardous substances that can damage the environment and present a risk to human health if not properly disposed of.

The crossed out wheelee bin symbol is to remind you that waste electrical and electronic products, batteries and accumulators should not be disposed of with household waste.



If you are unable to reuse or recycle your article it should be disposed of at a civic amenity site or a local authority recycling facility.

OPERATING INSTRUCTIONS

QUARTZ NON-DATE WATCH



- Pull crown out to position B
- Advance hands clockwise to the correct time
- Return to position A

QUARTZ DATE WATCH



- Time setting as above, but pull crown out to position C
- Date setting by pulling crown out to position B and turning clockwise or anti-clockwise.
- Return to position A

QUARTZ DAY/DATE WATCH



- Time setting as above, but pull crown out to position C
- Date setting by pulling crown out to position B and turn clockwise, return to position A.
- Day setting by pulling crown to position B and turn anti-clockwise. Return to position A.

Note: Do not wind the crown when it is in position A. If your watch has a second (sweep) hand you will notice that on pulling the crown out to position C, the second hand stops - this is normal.

WATCH GUARANTEE

INTRODUCTION TO YOUR WATCH

We would like to pass on to you some information, which we hope you will find interesting and helpful. Your watch has been produced to a high quality standard and with careful use will give you many years of satisfactory service. You can greatly assist in improving the life of your watch by following a few simple suggestions:

HANDLE WITH CARE

Although your watch is shock resistant, please do not take unnecessary risks by wearing the watch whilst carrying out rough work, etc.

PLATING

Gold, Silver and Rhodium plated cases can be damaged by hair or body sprays. Please therefore, whenever possible, place on your wrist after using such sprays – not before.

BATTERIES

The battery life should be approximately 18 months. Battery changes require special tools and expertise – particularly in water resistant watches which may have an inner seal and which could be broken whilst opening the case back. Your battery replacement should therefore be done by a qualified person. Please do not attempt to do this yourself as you may cause damage and therefore invalidate the guarantee.

WATER RESISTANCY

If your watch is not marked, usually on the back of the case, with either the words "Water Resistant" or a degree of water resistance (3ATM), then it is not water resistant. Care should be taken to avoid getting the watch wet as damage to the movement may result.

Dial/case back marking	Splashes, rain etc	Showering, washing up, etc	Swimming, bathing etc	Snorkeling, diving, wind-surfing, water skiing etc
No marking on case back	X	X	X	X
Water resistant	✓	X	X	X
30 Metres / 3 ATM water resistant	✓	✓	X	X
50 Metres / 5 ATM water resistant	✓	✓	✓	X
100 Metres / 10 ATM water resistant	✓	✓	✓	✓

Warning: please ensure the crown is fully pushed in before exposure to water, the crown or any buttons on the watch must not be operated when wet.

Your watch is guaranteed for 12 months from the date of purchase. Should your watch develop a fault during this time please send it back (well wrapped). Please enclose a cheque or postal order for £5.00 payable to PH Services, to cover postage and insurance for loss or damage in transit. All watches should be returned by registered or recorded post to:

**PH Services, Precision House, Starley Way,
Birmingham International Park, Bickenhill Lane,
Solihull, B37 7GN, UK**

The original receipt or proof of purchase should be included along with the completed enclosed form. In order to process your repair quickly, please give a brief indication of the fault. Please allow 20 days for repair and return postage.

NB, Your guarantee does not cover the following:

1. Batteries, straps or bracelets.
2. Damage caused from accidents, or mishandling to any part of the watch, including strap buckles, bracelets and watch glasses.
3. Water penetration, except in watches marked as water resistant.
4. Tarnishing of the watch bracelet or case.

The terms of this guarantee provide rights that are in addition to your statutory rights and do not affect your

Where Purchased.....

Date of Purchase.....

Owner's Name.....

Address.....

Telephone No.....

E-mail Address.....

Fault.....

Please retain this information

PH Services, Precision House, Starley Way,
Birmingham International Park, Bickenhill Lane,
Solihull, B37 7GN, UK