

Baby-G

BG-6903-4BER Specifications

- ⇒ Mineral Glass
- ⇒ 200M WR
- ⇒ 2 Alarms
- ⇒ Stopwatch
- ⇒ World Time
- ⇒ LED Light -Afterglow
- ⇒ Dual Time
- ⇒ 60 Lap Memory



Model variations may differ in appearance from the example above.

World Time	Displays the current time in major cities and specific areas	Press button C until display shows WT. Scroll through the pre-set cities using button D . The Local time will be displayed for each city on the LCD. Home and world time zones can be easily swapped by pressing buttons A and B simultaneously in this mode.
Stop Watch	Elapsed time, split time and final time are measured with 1/100 sec accuracy. The watch can measure times of up to 24 hrs.	Press button C until you reach STW mode. Start and stop stopwatch using button D , reset stopwatch using button A .
Lap Timing-Memory	Stopwatch lets you measure elapsed time, lap time, split times, and two finishes. Lap time and split times can be stored in memory.	<p>To measure elapsed time Note</p> <ul style="list-style-type: none"> You can perform the following steps starting from either the lap time screen or the split time screen. <ol style="list-style-type: none"> Press (D) to start the stopwatch. Press (D) again to stop the stopwatch. <ul style="list-style-type: none"> You can resume the measurement operation by pressing (D). Press (B) to clear the stopwatch to all zeros. <p>To measure elapsed time with lap times</p> <ol style="list-style-type: none"> When the stopwatch display shows all zeros, press (B) to display the lap time screen (indicated by LAP/▲) Press (D) to start an elapsed time measurement. <ul style="list-style-type: none"> At the time, both the upper and lower displays will show identical times. Press (B) to record the time of the first lap. <ul style="list-style-type: none"> This freezes the current lap time in the upper part of the display for about eight seconds, while measurement of total elapsed time and the next lap time continue internally. The lap number of the displayed time appears in the lower display. After eight seconds, the ongoing elapsed time measurement re-appears in the lower display. Repeat step 3 to record more lap times. Press (D) to stop the stopwatch. Press (B) to clear the stopwatch to all zeros. <ul style="list-style-type: none"> Lap numbers are incremented automatically starting from 1 whenever you press (B) in step 3 of the above procedure. The maximum lap number is 99. Recording a lap after that causes the lap number count to restart from 00.

Auto Light	The back light automatically illuminates the watch face each time the watch is tilted 40 degrees. Activate this feature by pressing and holding button B until the A-light indicator turns on.
Mineral Glass	Artificially manufactured glass with improved level of hardness and scratch resistance.
Water resistant 200M	Perfect for free diving without scuba equipment.