


**Hello**



echostudio


## Getting to know your Echo Studio



Also included: Power cord

## 1. Choose a location for your Echo Studio

Echo Studio will automatically tune its speakers based on where it is placed in the room. For optimal performance we recommend placing Echo Studio at your preferred listening height, at least 6" from the wall with clearance above and on both sides of the speaker.




## 2. Download the Amazon Alexa app

Download and install the latest version of the Alexa app from the app store.

## 3. Plug in your Echo Studio


Plug your Echo Studio into an outlet using the included power cord. A blue light ring will spin around the top. In about a minute, Alexa will greet you and let you know to complete setup in the Alexa app.



To connect an audio component such as a CD player or MP3 player, use the combination 3.5 mm/mini-optical line in on the back of your Echo Studio.

## 4. Set up your Echo Studio in the Alexa app

Open the Alexa app and follow the on-screen instructions to set up your device. If you aren't prompted to set up your device after opening the Alexa app, just tap the Devices icon in the lower right of the screen to get started.



The app helps you get more out of your Echo Studio. It's where you set up calling and messaging, and manage music, lists, settings, and news.

For help and troubleshooting, go to Help & Feedback in the Alexa app or visit [www.amazon.com/devicesupport](http://www.amazon.com/devicesupport).

For the best experience, set up your device via the Alexa app. You can also start the setup process at <https://alexa.amazon.com>.

## **Optional: Set up your compatible Zigbee smart home devices**

If you have a compatible Zigbee smart home device that you're ready to set up, simply say, "Alexa, discover my devices," or tap the Devices icon in the lower right of the Alexa app to get started.

Power on your compatible Zigbee smart home devices or put them into setup mode. For help and more information, go to the Help & Feedback section in the Alexa app.

You can also manage and rename devices in the Devices section of the Alexa app.

## **Designed to protect your privacy**

Amazon designs Alexa and Echo devices with multiple layers of privacy protection. From microphone controls to the ability to view and delete your voice recordings, you have transparency and control over your Alexa experience. To learn more about how Amazon protects your privacy, visit [amazon.com/alexaprivacy](https://amazon.com/alexaprivacy).

## **Give us your feedback**

Alexa is always getting smarter and adding new skills. To send us feedback about your experiences with Alexa, use the Alexa app or visit [www.amazon.com/devicesupport](https://www.amazon.com/devicesupport).



# Things to try with your Echo Studio

## Enjoy your favorite music and audiobooks

Alexa, play a rock music playlist.

Alexa, resume my audiobook.

## Get answers to your questions

Alexa, how many grams are in 16 ounces?

Alexa, what can you do?

## Get news, podcasts, weather, and sports

Alexa, tell me the news.

Alexa, what is the weekend weather forecast.

## Voice control your smart home

Alexa, turn off the lamp.

Alexa, set the temperature to 72 degrees.

## Stay connected

Alexa, call Mom.

Alexa, drop in on the family room.

## Stay organized and manage your home

Alexa, reorder paper towels.

Alexa, set an egg timer for 5 minutes.

*Some features may require customization in the Alexa app, a separate subscription, or an additional compatible smart home device.*

*For more examples, select Things to Try from the Alexa app menu, or visit [amazon.com/askAlexa](https://amazon.com/askAlexa).*



22-001774-02





©2019 Amazon.com, Inc. or its affiliates. Amazon, Alexa, Echo, Echo Studio, and all related logos and motion marks are trademarks of Amazon.com, Inc. or its affiliates.



# **Important information**

echo studio

## ENGLISH

### IMPORTANT PRODUCT INFORMATION

#### SAFETY INFORMATION



FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS COULD RESULT IN FIRE, ELECTRIC SHOCK, OR OTHER INJURY OR DAMAGE.

Echo Studio should be positioned in a way that provides proper ventilation. For example, do not cover the apparatus with items such as newspapers, tablecloths, or curtains and do not use this equipment on soft support such as bedding, blankets, etc.

The apparatus shall not be exposed to dropping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.

Do not expose your device or power cord to liquids. If your device or power cord gets wet, carefully unplug all cables without getting your hands wet and wait for the device and power cord to dry completely before plugging them in again. Do not attempt to dry your device or power cord with an external heat source, such as a microwave oven or a hair dryer. If the device or power cord appears damaged, discontinue use immediately. Use only included accessories to power your device. To avoid risk of electric shock, do not touch your device or any connected wires during a lightning storm.

#### CAUTION



To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. If your device gets wet, information for care instructions can be found in the Alexa app in Help & Feedback > Legal & Compliance.

The device is capable of playing at high volume, which could damage the hearing of the user. To prevent possible hearing damage, avoid listening at high volume for long periods.

Your device does not have an on/off button. If you wish to stop power from flowing into your device, unplug the power cord.

Do not expose your device to extreme heat or cold. Use your device in a location where temperatures remain within the device's operating temperature range set forth in this guide.

## **RECYCLING YOUR DEVICE PROPERLY**

In some areas, the disposal of certain electronic devices is regulated. Make sure you dispose of or recycle your device in accordance with your local laws and regulations. For information about recycling your device, go to [www.amazon.com/devicesupport](http://www.amazon.com/devicesupport).

## **PRODUCT SPECIFICATIONS**

Model Number: O2T2V3

Electrical Input Rating: 100-240 V~, 50/60Hz, 1.5 A Max.

Temperature Rating: 0-35 °C

## **FCC COMPLIANCE**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

The party responsible for FCC compliance is Amazon.com Services, Inc. 410 Terry Ave. North, Seattle, WA 98109 USA.

If you wish to contact Amazon visit [www.amazon.com/devicesupport](http://www.amazon.com/devicesupport), select United States, click Help & Troubleshooting, then scroll to the bottom of the page and under the Talk to an Associate option, click on Contact Us.

Device Name: Echo Studio

Model: O2T2V3

## **ADDITIONAL SAFETY & COMPLIANCE INFORMATION**

Safety, compliance, recycling, and other important information regarding your Echo Device can be found in the Alexa app in Help & Feedback > Legal & Compliance.

For safety, compliance, and other information regarding any device connected to your Echo Studio, please consult the user manual and other information provided by the manufacturer.

## **AMAZON TERMS & POLICIES**

Echo Studio is an Alexa-enabled device. Before using it, please read all applicable terms, rules, policies, and usage provisions found in the Alexa app in Help and Feedback > Legal & Compliance and available at [www.amazon.com/devicesupport](http://www.amazon.com/devicesupport) (collectively, the "Agreements").

By using your Echo Studio, you agree to be bound by the Agreements.

## **LIMITED WARRANTY**

Your new or Certified Refurbished Echo Studio is covered by a 1-year Limited Warranty, detailed in the Alexa app in Help & Feedback > Legal & Compliance and at [www.amazon.com/devicesupport](http://www.amazon.com/devicesupport).

©2019 Amazon.com, Inc. or its affiliates. Amazon, Alexa, Echo, Echo Studio, and all related logos and motion marks are trademarks of Amazon.com, Inc. or its affiliates.



22-001775-01

