




Overlap
Cladding



Shiplap
Cladding




Fixed
Windows




Opening
Windows




No
Windows



Solid Sheet
Floor



T&G Floor



Solid Sheet
Roof



T&G Roof

ESDXL21PT002

Double Log Store

****Protim Aquatan T5 (621)****

Your building has been treated with **Aquatan**.

Aquatan is a water-based concentrate which is diluted with water, the building as been treated by the correct application of Aquatan solution and then allowed to dry.

Aquatan is a decorative finish to colour the wood, which is applied industrially to timber fence panels and garden buildings.

Aquatan undiluted contains: boric acid, sodium hydroxide 32% solution, aqueous mixture of sodium dioctyl sulphosuccinat and alcohols: 2, 4, 6-trichlorophenol.

BEFORE YOU START PLEASE READ INSTRUCTIONS CAREFULLY

- Check the pack and make sure you have all the parts listed.
- When you are ready to start, make sure you have the right tools at hand (**not supplied**) including a Phillips screwdriver, Stanley knife, wood saw, step ladder and drill with 2mm bit.
- Ensure there is plenty of space and a clean dry area for assembly.

The images used throughout the instruction manual are generic and for illustration purposes only; they may vary dependant on your actual product. It is strongly advised they are read and understood before attempting installation.

TIMBER

As with all natural materials, timber can be affected during various weather conditions. For the duration of heavy or extended periods of rain, swelling of the wood panels may occur. Warping of the wood may also occur during excessive dry spells due to an interior moisture loss. Unfortunately, these processes cannot be avoided but can be helped. It is suggested that the outdoor building is sprayed with water during extended periods of warm sunshine and sheltered as much as possible during rain or snow. Our buildings are coated with a water based high quality colorant; this only helps to protect the product during transit and for up to 3 months against mould. To validate your guarantee and ensure longevity of the product, it is ESSENTIAL the building is treated with a wood preserver within the first three months of assembly and thereafter in accordance with the manufactures recommendations. Care must be taken to ensure the product is placed on a suitable base

BUILDING A BASE

When thinking about where the building and base is going to be constructed: Ensure that there will be access to all sides for maintenance work and annual maintenance. The base is level and is built on firm ground, to prevent distortion. Refer to diagrams for the base dimensions, The base should be slightly smaller than the external measurement of the building, i.e. The cladding should overlap the base, creating a run off for water. It is also recommended that the floor be at least 25mm above the surrounding ground level to avoid flooding.

TYPES OF BASE

- Concrete 75mm laid on top of 75mm hard-core.
- Slabs laid on 50mm of sharp sand.

Whilst all products manufactured are made to the highest standards of Safety and in the case of childrens products independently tested to EN71 level, we cannot accept responsibility for your safety whilst erecting or using this product.

Mercia Garden Products Limited, Sutton On Trent, Newark, Nottinghamshire, NG23 6QN
www.mercia garden products.co.uk

Refer to the instructions pages for your specific product code



x2

All building's should be erected by two adults



2mm Drill bit

For ease of assembly, it is advisable to pilot drill all screw holes and ensure all screw heads are countersunk.



Winter = High Moisture = Expansion
Summer = Low Moisture = Contraction



CAUTION

Every effort has been made during the manufacturing process to eliminate the prospect of splinters on rough surfaces of the timber. You are strongly advised to wear gloves when working with or handling rough sawn timber.

For Assistance Please
Contact Customer Care on
01636 880514


Overall Dimensions:

Length = 803mm
Width = 1943mm
Height = 1264mm


Base Dimensions:

Length = 740mm
Width = 1830mm


Before assembly
please make sure you have a
suitable base ready to erect your
building




Content




Floor Qty 2




Left Gable
Qty 1



Right Gable
Qty 1



Back Panel
Qty 2



Roof
Qty 1

Fixing Kit

- 6

1x Front Fascia- 7x50x1929mm
- 7

2x Side Fascia- 7x50x828mm
- 8

1x Front Support- 27x45x1050mm
- 9


Corner Bracing
Qty 3

Nail Bag

- 50mm Screw x30
- 40mm Screw x4
- 30mm Screw x12
- 20mm Screw x14


Step 1

Remove transportation blocks
from the bottom of each panel
before beginning assembly. Each
Panel should have two blocks.




Step 2

Place both floors next to each other with the floor framing facing up and fix together using 3x40mm screws.



3x40mm screws

Place the floor on a firm and level base, ensure base has suitable drainage free from areas where standing water can collect. (see front page on base requirements).




Step 3


Attach the right gable and a back panel together with 3x50mm screws.

DO NOT SECURE THE PRODUCT TO THE FLOOR UNTIL AFTER THE ROOF HAS BEEN FITTED.

- a Fix the corners with 3 x 50mm screws as in the diagram.



Position the panels so there are equal gaps between the floor and cladding




3 x 50mm screws

Step 4


Attach the left gable and the second back panel together with 50mm screws.

DO NOT SECURE THE BUILDING TO THE FLOOR UNTIL AFTER THE ROOF HAS BEEN FITTED.

- a Fix the corners with 3 x 50mm screws as in the diagram.




Position the panels so there are equal gaps between the floor and cladding



6 x 50mm screws

Step 5


Attach the roof on top of the gables and fix through the framing on the side into the gable cladding using 50mm screws.



Step 6


Attach the Front Support to the roof and floor using a corner brace at each end. Fix each corner brace using 4x20mm screws.

Attach a third corner brace to fix the roof to the back panels using 4x20mm screws.




Step 7

Fix the panels to the floor using 50mm screws as shown in the illustration.



Position the panels so there are equal gaps between the floor and cladding



Step 8

Attach the front fascia to the edge of the roof using 4x30mm screws.

Attach the side fascias using 3x30mm screws each.

Make sure the screws go through the fascia and into framing.

