


SPORTSPOWER - SKYRING

10FT ROUND TRAMPOLINE AND ENCLOSURE COMBO SET

Assembly, Installation, Care, Maintenance, and User Instructions

CUSTOMER HELP LINE NUMBER 0843 503 44 55

www.sportspowerfit4kids.com



**DO NOT ALLOW
MORE THAN ONE
PERSON ON THE
TRAMPOLINE AT A
TIME.**



WARNING

- CAREFULLY READ ALL INSTRUCTIONS IN THIS MANUAL BEFORE ASSEMBLING AND USING THIS TRAMPOLINE
- ESTIMATED ASSEMBLY TIME 2 ADULTS , 2 HOURS
- MAXIMUM WEIGHT OF THE USER SHALL NOT EXCEED 220LBS/100KG
- DO NOT ALLOW CHILDREN TO USE UNLESS SUPERVISED BY AN ADULT
- PROPERLY STORE PRODUCT AWAY DURING HEAVY WINDS
- SAVE THIS MANUAL FOR FUTURE REFERENCE
- SUITABLE FOR CHILDREN AGED ABOVE 6 YEARS
- NOT SUITABLE FOR CHILDREN UNDER 3 YEARS OLD. CHOKING HAZARD



NOTICE

SOME FOAM TUBE DEFORMATION MAY TAKE PLACE DURING TRANSPORT. IT'S NORMAL AND IT SHOULD RECOVER OVER TIME.

INTRODUCTION

Thank you for purchasing a Sportspower product! This trampoline was designed and manufactured with quality materials and craftsmanship, providing fun and exercise in the enjoyment of your own backyard.

It is very important that the owners and users of this trampoline have adequate knowledge of techniques and rules for safe use. In particular, children must be supervised at all times by a knowledgeable and mature adult while using the trampoline. Take precautions to prevent access to the trampoline by children when there is no adult supervision. Also restrict access to any unauthorized users without your consent.

To reduce risks associated with users falling off the trampoline, the trampoline enclosure netting must be properly installed and used at all times. The trampoline enclosure should be closed during use to prevent the user from falling off of the trampoline. Your trampoline enclosure netting is manufactured with UV resistant material. Exposure to harsh elements (sunlight, wind, moisture, animals, etc) will weaken the netting. Because of this the netting must be inspected prior to every use as detailed later in this User Manual.

Please also ensure proper placement of this product to avoid injuries. The best surface to place your product is over flat dirt or grass, with no obstructions beneath or around the product. The product must not be used in windy conditions as wind can cause unexpected movement of the product. The product must be properly stored away or disassembled completely during severe windy conditions. If you live in an area where there are winds strong enough to move the product, you should consult a local contractor about ways to secure the product in your location.

Read all instructions in this manual carefully before assembling or using this product. Keep this manual in a safe place for future reference.

CUSTOMER SERVICE/ SPARE PARTS – 0843 503 44 55

TABLE OF CONTENTS

	PAGE
Introduction	1
Table of Contents	2
PART A. Important Safety Instructions	3
Important Warning about Enclosure Netting and Pad	5
PART B. Assembly and Installation Instructions	
1. Location of Trampoline	7
2. Part List Used for Trampoline	8
3. Part List Used for Trampoline Enclosure	9
4. Assembling the Trampoline	10
5. Spring Loading Instructions	12
6. Frame Pad Assembly	16
7. Disassembly of Trampoline	16
8. Assembling the Trampoline Enclosure	17
9. Disassembly of Trampoline Enclosure	23
PART C. Care and Maintenance Instructions	24
1. Regular Inspection of the Trampoline	
2. Regular Inspection of the Trampoline Enclosure Net	
3. Moving the Trampoline	
4. Weather Conditions	
5. Windy Weather	
6. Limit Access	
PART D. Proper Use of the Trampoline - Warning Information	25
1. Maximum User Weight	
2. Mounting and Dismounting	
3. Use of Alcohol and Drugs	
4. Multiple Jumpers	
5. Striking the Frame or Springs	
6. Maintain Control	
7. Somersaults (Flips)	
8. Foreign Objects	
PART E. Tips to Reduce the Risk of Accidents	
1. Lesson Plan	26
2. Basic Trampoline Bounces	27
PART F. Product Warranty	29

IMPORTANT SAFETY INSTRUCTIONS

BEFORE YOU BEGIN: Review all steps before beginning assembly and read all precautions before using the trampoline. The owner and supervisors of the trampoline are responsible to make all users aware of practices specified in these instructions. Save this manual for future reference.

**PLEASE CHECK ALL PARTS BEFORE YOU BEGIN ASSEMBLY. IF ANY PARTS ARE MISISSNG
CALL CONSUMER HELP LINE 0843-503-44 55**



WARNING

Read these materials prior to assembling and using this trampoline.

WARNING – To reduce the risk of injury to persons:

- Read and understand all the instructions and inspect the equipment before using the trampoline. It is your responsibility to familiarize yourself with the proper use of this equipment and the inherent risks of jumping on a trampoline, such as falling on your head or neck, pinching, entrapment, or equipment failure. It is the responsibility of the owner to ensure that all users of the product are fully informed about the proper use of the equipment and all safety precautions.
- Use trampoline only with mature, knowledgeable supervision. Close supervision is necessary when the trampoline is used by children, or by or near invalids or disabled persons.
- Trampolines over 20 inches (51cm) tall are not recommended for use by children under six years of age.
- **DO NOT** use if you are over 220lbs (100kg).
- **DO NOT** allow more than one person to jump on the trampoline at any one time. Multiple jumpers increase the risk of **SERIOUS INJURY TO SKULL, NECK AND BACK.**
- **DO NOT SIT ON OR LEAN ON PAD COVERING SPRINGS WHEN TRAMPOLINE IS IN USE**
- **DO NOT** perform somersaults or flips. This will significantly increase your chances of landing on your head or neck and can cause serious injuries, such as paralysis or death!
- **DO NOT** jump on trampoline with snow board, skateboard, roller blades, bicycle or any other equipment not authorized by the trampoline maker.
- **DO NOT** jump off walls or building onto the trampoline. Do not use the trampoline as a springboard to jump onto other objects.
- This product is intended for outdoor non-commercial use only. **DO NOT** use indoors. **DO NOT** use in any commercial, rental, professional or stunt performance setting.
- **DO NOT** play or jump on the product during inclement weather (thunderstorms, tornadoes, hurricanes, or when it is wet or windy). High winds can lift the equipment and cause serious injury. Move the trampoline into a safe and dry storage location during severe weather conditions. If you live in an area where there are winds strong enough to move the product, you should consult a local contractor about ways to secure the product in your location.
- **DO NOT** jump on the trampoline mat with street shoes or tennis shoes. Users of the trampoline should not wear sharp or pointed objects and should not bring any sharp or pointed objects into the trampoline or the area around the trampoline. Any type of sharp or pointed objects should be removed from persons and kept off the trampoline at all times. Remove all buckles, jewelry, and other sharp or pointed objects.
- **DO NOT** allow any pets onto the mat in order to prevent the trampoline mat from being damaged.
- **DO NOT** allow any pets or children to go under the jump mat.

Customer Help Line Telephone Number: 0843-503 44 55 Monday-Friday 9:00am-4:30pm

- **DO NOT** use unauthorized Sportspower parts. This may damage the integrity of the product and will void the manufacturer's warranty.
- **ALWAYS** ensure adequate overhead clearance. Recommended overhead clearance is 26.25ft (8 meters) from ground level. Provide clearance for wires, tree limbs and other possible hazards.
- **ALWAYS** ensure the trampoline is on level ground with a minimum of 2m clear space around the sides, 8m clear height space above and that nothing is under the trampoline.
- **ALWAYS** place the trampoline on a level surface before assembly and use. This trampoline is for **OUTDOOR USE ONLY**. The best surface to place your product is over flat dirt or grass, with no obstructions beneath, above or around the product.
- **ALWAYS** maintain clear space on all sides of the trampoline. Place the trampoline away from walls, structures, fences and other play equipment. Clear any obstructions beneath or around the trampoline, for example tree limbs or trunks, wires or other possible hazards.
- **ALWAYS** inspect the trampoline before each use for worn-out mats or enclosures and loose or missing parts. Make sure the frame padding is correctly and securely positioned. Replace defective components immediately and/or keep the equipment out of use until repair.
- **ALWAYS** protect enclosure net from extreme temperatures. Extreme temperatures may damage the net and cause it to tear and cause injury.
- **ALWAYS** make sure that the trampoline enclosure netting is installed and used properly at all times. The trampoline enclosure should be closed during use to prevent the user from falling off of the trampoline.
- **ALWAYS** climb on and off the trampoline while mounting or dismounting. **DO NOT** jump on or off the trampoline as this can cause serious injuries.
- **ALWAYS** consult your physician before performing any kind of physical activity.
- **ALWAYS** use the trampoline in a well-lit area. Artificial illumination may be required.
- **ALWAYS** properly store away the trampoline and enclosure when not in use and secure from any unauthorized use. Trampoline should be taken down and stored away during harsh weather conditions including extreme heat and snow or freezing temperature. Extreme temperature may cause damages and tears to the mat and netting and cause injury.
- **ALWAYS** use the trampoline wearing comfortable clothes and socks or barefoot.
- **NEVER** use the trampoline while under the influence of alcohol or drugs.

WARNING:

ALWAYS START YOUR JUMP AT THE CENTER OF TRAMPOLINE MAT.

FAILURE TO FOLLOW INSTRUCTIONS AND WARNINGS COULD RESULT IN SERIOUS INJURY OR DEATH.

! WARNING



NO MORE THAN ONE PERSON AT A TIME ON THE TRAMPOLINE!
 MULTIPLE JUMPERS INCREASE **SERIOUS RISK** TO HEAD, NECK, LEG OR BACK.



PARALYSIS OR DEATH CAN RESULT IF YOU LAND ON YOUR HEAD OR NECK!
 DO NOT PERFORM SOMERSAULTS (FLIPS) AS THIS WILL INCREASE YOUR CHANCES OF LANDING ON OUR HEAD OR NECK!



IMPORTANT WARNING ABOUT ENCLOSURE NETTING AND PAD

TRAMPOLINE NET & PAD – MAINTENANCE REQUIREMENTS



IMPORTANT !

READ IT! Failure to follow these instructions to ensure proper operational condition of your trampoline may lead to serious injury or death. Do not allow more than one person on the trampoline at a time.

1. Maintenance of Trampoline Enclosure Net and Pad

Enclosure net and pad are prone to wear and tear like tires on a car. Gradual deterioration of the material will occur, the speed of which will depend on the level of exposure to UV rays, airborne pollution, and outdoor weather conditions such as rain and wind.

The net and pad need to be properly maintained and checked by following the Maintenance Schedule set out in these instructions. When the material shows any signs of weakness, you must stop using the trampoline immediately, properly store the trampoline and restrict access by users until a new replacement net or pad is properly installed.

2. Maintenance Requirement for Enclosure Net

Your trampoline enclosure netting is manufactured with UV resistant material. Despite this the netting is exposed to the outdoor elements including sunlight, wind, rain and wildlife.

The net surrounding the trampoline must be checked prior to each use. This includes, but is not limited to inspecting the net for cracks, excess wear, brittleness, stretching, all connections and for overall integrity. The net must be immediately replaced if it shows any signs of wear, damage, being stretched, cracked, loose, brittle or otherwise loses any integrity. The following Maintenance Schedule must be followed:


1 to 3 Months	3 to 6 Months	6 to 12 Months
Thorough inspection for UV damage and prior to every use for net.	Thorough inspection for UV damage and prior to every use for net, net hanger and straps.	Thorough inspection before every use on net, net hanger, straps, zippers, ties and strings. Replace after 12 months or earlier

IT IS RECOMMENDED THAT THE NET BE REPLACED ON A YEARLY BASIS OR EARLIER UNDER NORMAL USE, EVEN IF IT DOES NOT SHOW ANY VISIBLE SIGNS OF DAMAGE.

How to Inspect the Trampoline Net for Safe Use

Always check the enclosure netting for signs of UV damage, deterioration, brittleness, cracking, and tearing every time before using the trampoline and enclosure.

Step 1 - Inspect the enclosure netting before EACH use for wear or tear by pinching and pulling a section of the netting between fingers and pulling downward. Please see diagram below.



If it produces any tear or cracking or ripping sound, then the net is unsafe and **MUST** be taken down immediately. **STOP USING THE TRAMPOLINE ENCLOSURE IF YOU FIND ANY SIGNS OF WEAR OR TEARING ON THE NETTING.**

Step 2 - Walk around the whole perimeter of the trampoline to visually check for material deterioration or other damage.

3. SAFETY TIPS FOR TRAMPOLINE NET

- Do not attempt to jump over or crawl under the netting.
- Do not intentionally bounce off the netting.
- Do not hang from, kick, cut or climb on the netting.
- Wear clothing free of drawstrings, hooks, loops or anything that could get caught in the netting.
- Do not attach anything to the netting that is not a manufacturer-approved accessory or part of the enclosure system.
- Enter and exit the enclosure only at the enclosure door or netting opening designated for that purpose.
- A trampoline enclosure installed on a trampoline is raised off the ground. The height of the enclosure increases the risk of a fall when a jumper is entering or exiting the enclosure. Young children in particular may have difficulty getting into and out of the enclosure. To reduce the risk of falling, help young children to get into and out of the enclosure.
- Enter and exit the trampoline enclosure only through the opening of the enclosure (the opening in the netting walls). The trampoline mat and nettings walls of the enclosure are separate pieces; jumpers, particularly young children, must not exit the enclosure by going out between the mat and the netting walls. Trying to exit in this way poses a risk of strangulation from being caught between the trampoline frame and the netting walls.
- Do not attach anything to the netting that is not a Sportspower approved accessory or part of the trampoline enclosure.
- Please do not hang on the top ring, this action may cause injury.

4. Maintenance Requirement for Trampoline Pad

Walk around the whole perimeter of the trampoline to visually check for material deterioration, tears, looseness, loss of elasticity or other damage in the pad.

It is recommended to replace the trampoline enclosure net and pad every 12 months or earlier if there are any signs of wear, tear, brittleness, cracking, stretching or any other signs of weakness.

**FAILURE TO FOLLOW INSTRUCTIONS AND WARNINGS COULD RESULT IN
SERIOUS INJURY OR DEATH.**

ASSEMBLY AND INSTALLATION INSTRUCTIONS

BEFORE YOU BEGIN: Review all steps before assembly and read all precautions before using the trampoline and trampoline enclosure. To assemble this product, all you need is our special spring loading tool and wrenches provided with this product. During periods of non-use, this trampoline and trampoline enclosure can be easily disassembled and stored.

At least two people are required to assemble the trampoline and trampoline enclosure. Protective gloves should be used during assembly to avoid pinching by the springs and goggles should be worn to avoid injuries to the eyes.

LOCATION OF TRAMPOLINE

For safe use of the trampoline, please assemble the trampoline in a location that meets the following conditions:

- The minimum overhead clearance required is 26.25 feet (8 meters).
- The trampoline must be placed on a level surface, preferably grass.
- Clear any obstructions from beneath the trampoline and maintain clear space around the trampoline. Do not place the trampoline near walls, fences, other play equipment, etc.
- Make sure the trampoline is installed in a well-lit area.
- Trampoline should be placed in an area where access can be restricted from unauthorized use, for example, neighborhood children without your consent and supervision.

If you do not follow these guidelines, you increase the risk of someone getting injured.



WARNING



NO MORE THAN ONE PERSON AT A TIME ON THE TRAMPOLINE! MULTIPLE JUMPERS INCREASE **SERIOUS RISK** TO HEAD, NECK, LEG OR BACK.



PARALYSIS OR DEATH CAN RESULT IF YOU LAND ON YOUR HEAD OR NECK! DO NOT PERFORM SOMERSAULTS (FLIPS) AS THIS WILL INCREASE YOUR CHANCES OF LANDING ON YOUR HEAD OR NECK!





















FAILURE TO FOLLOW INSTRUCTIONS AND WARNINGS COULD RESULT IN SERIOUS INJURY OR DEATH.

PRIOR TO ASSEMBLING











Please refer to next page for parts descriptions and numbers. The assembly steps use these descriptions and numbers as reference for your convenience.

Make sure that you have all parts listed. If you are missing any parts, **PLEASE CALL CONSUMER HELP LINE 0843 503 44 55.**

PART LIST USED FOR TRAMPOLINE

Key Number	Diagram	Description	Quantity
1		Trampoline Mat, stitched with Triangle-Rings	1
2		Frame Pad	1
3		T-Part with Leg Sockets	8
4		Top Rail	8
5		Leg Base	4
6A		Right L-Shaped Leg	4
6B		Left L-Shaped Leg	4
7A		Long Screws (43mm)	16
7B		Long Screws (38mm)	4
8A		Screws (15mm)	8
8B		Long Screws (20mm)	4
9		Nut	20
10		Spring Washer	24
11		Large Arc Washer	8
12		Flat Washer	44
13		Galvanized Springs	56
14		Trampoline Safety Instruction Placard	1
15		Spring Loading Tool	1
16		Allen Wrench	1
17		Plastic End Cap	4

PART LIST USED FOR TRAMPOLINE ENCLOSURE

Key Number	Diagram	Description	Quantity
A		Upper Frame Tube with Foam	4
B		Lower Frame Tube With Foam	4
C		Cable Wire	12
D		Wrench	1
E		Self-Locking Screw	8
F		Cord	6
G		Enclosure Netting	1
H		Plastic Cap	4
I		Trampoline Enclosure Safety Instruction Placard	1
J		Cap	4

REMEMBER TO USE GLOVES DURING ASSEMBLY TO AVOID PINCHING.


AT LEAST 2 PEOPLE ARE REQUIRED TO ASSEMBLE THE TRAMPOLINE AND ENCLOSURE.

ALWAYS WEAR PROTECTIVE GOGGLES AND WORKING GLOVES TO PROTECT AGAINST INJURY AS TRAMPOLINE AND ENCLOSURE ARE HEAVY EQUIPMENT.

TRAMPOLINE ASSEMBLY

STEP 1 – Frame Layout

There are a total of 28 pieces of steel tubing parts required to assemble the frame.
Lay out all parts as shown in FIGURE 1.



A. Lay out all frame sections in a circle as shown.
Please pay special attention to the sequence of this assembly step.

- B. You should have the following parts:
- ① T-Part with Leg Sockets (# 3)
 - ② Top Rail (# 4)
 - ③ Leg Base (# 5)
 - ④ Right L-Shaped Leg (# 6A)
Left L-Shaped Leg (# 6B)

FIGURE 1

STEP 2 – Support Assembly

Slide all L-Shaped Leg (# 6) into the Leg Base (# 5). Align the hole on L-Shaped Leg (# 6) with leg base (# 5) secure with Screws (15mm) (# 8A) and Large Arc Washer (# 11) using Allen Wrench (# 17) as shown in FIGURE 2.




FIGURE 2



IMPORTANT


Please do not install the screws too tight at this point. Just tighten it enough to hold the tubes together. You will need to come back to this step to tighten all the screws after the trampoline frame is installed.

STEP 3 – Top Rail Assembly

To connect the parts, slide one end of Top Rail (# 4) into the T-Part with Leg Sockets (# 3); secure by using Long Bolts (# 7A), Flat Washer (# 12), Spring Washer (# 10) and Nut (# 9) as shown in the ENLARGED DIAGRAM of FIGURE 3.


Repeat the same for the other side of the Top Rail. This is called “Main Frame with Leg Socket”.

Two people will be necessary at this point to assemble the trampoline. One person lifts one end of the frame while another inserts the vertical portion of support assembly into the sockets of the T-Part with Leg Sockets (# 3). Insert the vertical portion of the support assembly to sockets of the T-Part with Leg Sockets (# 3) for all sets of support assembly.



Now, install the other Top Rails (# 4) into the gaps between the Vertical Leg Extensions (# 6) by inserting them into the slots as shown in FIGURE 4.

Secure Top Rails (# 4) by using Long Bolts (# 7), Flat Washer (# 12), Large Spring Washer (# 10) and Nut (# 9) as shown in the enlarged diagram of FIGURE 4.



STEP 4

Attach the Plastic End Cap (# 17) at the “6A” with T-Part with Leg Sockets (# 3), then secure by using Long Screw (38mm) (# 7B), Flat Washer (# 12), Spring Washer (# 10) and Nut (# 9) as shown in FIGURE 5.

Import Note:

Only tighten the T-part with the Plastic End Cap (#17) at the “6A”.

You will assemble T-part at the “6B” when assembling the enclosure as shown in FIGURE 13 under page 17.





FIGURE 5

STEP 5 – Attaching the Jumping Mat to the Frame

WARNING!!

- Failure to follow instructions may result in damaged springs or frame warping/displacement
SPRINGS SHOULD BE ATTACHED AS PER INSTRUCTIONS BELOW
- Make sure all spring hooks face down
- All warning labels must be facing upwards
- Spring hooks must be pushed properly into the frame holes

- A. Lay out the trampoline mat (#1) inside the frame with warning labels facing upwards.



SPRING LOADING INSTRUCTION

BE CAREFUL NOT TO PINCH HANDS OR FINGERS. USE GLOVES TO PREVENT PINCHING. KEEP SPRINGS DRY AS WET SPRINGS ARE VERY SLIPPERY!

1. Wear heavy duty working gloves to protect your hand.
2. Use the special spring loading tool included.
3. Select an arbitrary point on the Frame (call it Point “ZERO”).
4. Hold and align spring so the hook of the spring lines up with hole on the Top Rail.
5. Hook one end of the Spring (# 13) into the triangle-ring on the Mat (# 1). Holding the Spring Loading Tool underhand, pull the other end of the Spring towards point “ZERO” and drop the hook into the hole on the Frame as shown in Figure 6. Tap on the Spring to make sure it is securely latched into the hole.

Customer Help Line Telephone Number: 0843-503 44 55 Monday-Friday 9:00am-4:30pm




FIGURE 6

B. Next, starting from point Zero, count to hole 28 on the opposite end of the mat and attach a Spring in the same manner. For even distribution of tension and ease of assembly, springs should always be installed on opposite sides of the mat/frame in an alternating manner, i.e. Zero, then 28, followed by 14 and 42 as shown in FIGURE 7.

HINT: There are 56 Triangle-rings sewn on the mat and 56 corresponding holes on the Frame, none of which are numbered so please follow these instructions carefully to ensure proper installation. If you notice that you have miscounted a hole or Triangle-Ring, remove and re-install the springs as necessary while maintaining even distribution of tension as explained above.




FIGURE 7

C. Continue to attach Springs in the same manner, ensuring even distribution of tension by attaching springs on opposite sides of the mat/frame in an alternating manner, i.e. 7 then 35, 49 then 21, etc as shown in FIGURE 8.




FIGURE 8

D. Continue to attach a spring at every 4 hole interval, ensuring even distribution of tension by attaching springs on opposite sides of the mat/frame in an alternating manner, i.e. 4 then 40, 67 then 31, etc as shown in FIGURE 9.




FIGURE 9

E. Finally, attach the remaining 40 springs by installing in even intervals of holes and on opposite sides in an alternative manner to ensure even distribution of tension. The complete installation of the trampoline mat should look as shown in FIGURE 10.




FIGURE 10

STEP 6 – Trampoline Safety Placard Attachment

Using the tie wrap, attach the Trampoline Safety Instruction Placard (# 14) to the trampoline. The tie wrap should go around the Top Rail to ensure that it doesn't slide off the trampoline as shown in FIGURE 11.




FIGURE 11

FRAME PAD ASSEMBLY

WARNING!!

Never use the trampoline without attaching the frame pad. Properly tie down the Frame Pad before each use!! Improper assembly of the Frame Pad may lead to injury!! Improper assembly of the frame pad may lead to injury!

STEP 7

Lay the Frame Pad (#2) over the trampoline so that the springs and the top rail are covered. Please ensure that the Frame Pad covers all metal parts. **Make sure the holes on the frame pad align with T-part with Leg sockets without Plastic End Cap (#17).**

Tie the elastic straps over the frame as shown in FIGURE 12 and make sure frame pad covers the frame.




FIGURE 12

DISASSEMBLY OF TRAMPOLINE

To disassemble the trampoline, follow all the above steps in reverse order. Do not attempt to disassemble any frame components before the springs and the mat have been removed. Use gloves to protect your hands from pinch points during disassembly.

DO NOT USE TRAMPOLINE UNTIL THE ENCLOSURE HAS BEEN PROPERLY ASSEMBLED AND FITTED TO THE TRAMPOLINE.

ASSEMBLING THE TRAMPOLINE ENCLOSURE

BEFORE YOU BEGIN: Review all steps before beginning assembly and read all precautions before using the trampoline. All the tools needed are included with this package. **NOTICE: SOME FOAM TUBE DEFORMATION MAY TAKE PLACE DURING TRANSPORT. THIS IS NORMAL AND SHOULD NATURALLY RECOVER OVER TIME.**

At least two people are required to assemble the trampoline enclosure. Protective gloves should be used during assembly to avoid pinching and goggles should be worn to avoid injuries to the eyes.

STEP 8

Please have someone helping you to hold the Lower Frame Tube with Foam (# B). Be steady when you do this step. Slide the Lower Frame Tube with Foam (# B) into the T-Part with Leg Sockets which are "6B", as shown below, then secure by using Long Screw (20mm) (# 8B), Spring Washer (# 10) and Flat Washer (# 12) as shown in FIGURE 13.

Repeat this step for all Lower Frame Tube with Foam (# B).





FIGURE 13

STEP 9

Tube A - Pull the foam downward a little bit to locate the hole at the edge of the curved end of Upper Frame Tube with Foam (# A).

Attach Plastic Cap (# H) to Upper Frame Tube with Foam (# A), secure by using Self-Locking Screw (# E) and Allen Wrench (# 16) as shown in FIGURE 14. Then push the foam back to its original position.


Repeat this step for all other upper frame tubes and plastic caps



STEP 10

Connect the thread to the nut of Cable Wire (# C) by using Wrench (# D) as shown in FIGURE 15.

HINT: Please make sure every cable wire is securely and completely fastened to each other.



STEP 11



CAUTION: TWO ADULTS ARE REQUIRED.

TRAMPOLINE WITH 4 ENCLOSURE TUBES:

- A. Insert the assembled Cable Wire (# C) into sleeve on the top part of the Enclosure Netting (# G) as shown in FIGURE 16.
- B. Connect the two ends of Cable Wires (# C) together by connecting the thread to the nut using Wrench (# D) after all cable wires are inserted into the ENCLOSURE SLEEVE as shown in FIGURE 17.

Hint: When two people are doing step 11-B, it is easier to assemble if you squeeze inward at the same time.





FIGURE 16



**ENLARGED
DIAGRAM**

FIGURE 17

Now, place Cable Wires and Enclosure Netting assembled on trampoline mat for the next step.



CAUTION


For easier disassembly and safety concern, please ensure that each section of the cable wires is securely tightened together by wrench.

Failing to do so, might increase the chance of getting injury during disassembly.


STEP 12

CAUTION: TWO ADULTS ARE REQUIRED

Place the Cable Wire (# C) with Enclosure Netting (# G) to the Plastic Cap (# H) assembled on the Upper Frame Tube With Foam (# A) to make a "RING" as shown in FIGURE 18. Make sure the cable wire fits into the slot properly. Please repeat for all the cable wires and plastic caps.



Now, place the assembled "RING" (together with # A, # C and # G) onto the trampoline mat. Put Cap (# J) on the Plastic Cap (# H) as shown in FIGURE 19 for further use.



STEP 13

Attach the assembled "RING" (together with # A, # C and # G) to the Lower Frame Tube with Foam (# B) as shown in FIGURE 20.




FIGURE 20

STEP 14

Tie one end of one Cord (# F) to trampoline mat ring first, pull the CORD through net edge and trampoline mat ring until the end. Tie new CORD to the same trampoline mat ring where the previous CORD finished. Pull the CORD through net edge and trampoline mat ring. Repeat this step until you have tied all the CORDS to the trampoline mat ring as shown in FIGURE 21.




FIGURE 21

STEP 15

Then, secure Upper Frame Tube with Foam (# A) and Lower Frame Tube with Foam (# B) by using Self-Locking Screw (# E) and Allen Wrench (# 16) as shown in FIGURE 22.




FIGURE 22

STEP 16

Pull the zip of Enclosure Netting (# G) at the door of the trampoline, then snap two buckles as shown in FIGURE 23 (one may be hidden under the pad of the trampoline).




FIGURE 23

STEP 17

Use the included plastic tie to attach Trampoline Enclosure Safety Placard (# 1) to the netting near the door as shown in FIGURE 24.




FIGURE 24



IMPORTANT

Once you have finished the assembly of the trampoline, go back over all of the nuts and bolts and properly tighten all of them before using.

Read this entire manual and make sure all jumpers completely understand all of the safety rules printed in the manual and on the various warning signs. Instruct all jumpers in the basic bounces described in the manual.

CARE AND MAINTENANCE AND USE INSTRUCTIONS MUST BE READ CAREFULLY BEFORE USING THE TRAMPOLINE. ADULT SUPERVISION IS REQUIRED AT ALL TIMES.

DISASSEMBLY THE TRAMPOLINE ENCLOSURE

To disassemble the enclosure netting, simply follow the above instructions in reverse order.

DO NOT USE THE TRAMPOLINE WHEN THE ENCLOSURE IS REMOVED.

CARE AND MAINTAINANCE INSTRUCTIONS

REGULAR INSPECTION OF THE TRAMPOLINE:

Inspect the trampoline before each use and replace any worn, defective or missing parts. The following conditions could represent potential hazards:

- Missing, improperly positioned or insecurely attached frame padding
- Punctures, frays, tears or holes in the trampoline mat or frame padding
- Deterioration in the stitching or fabric of the mat or frame padding
- Ruptured or loose springs
- Bent or broken frame
- Sagging trampoline mat
- Sharp protrusions on the frame or suspension system

IF YOU FIND ANY OF THE ABOVE SIGNS OR ANYTHING OTHER INDICATIONS OF WEAKNESS IN THE INTEGRITY OF THE TRAMPOLINE, THE TRAMPOLINE SHOULD BE DISASSEMBLED OR SECURED FROM USE UNTIL THE CONDITION(S) HAS BEEN RESOLVED.

REGULAR INSPECTION OF THE TRAMPOLINE ENCLOSURE NET:

Your trampoline enclosure netting is manufactured with UV resistant material. Despite this the netting is exposed to the outdoor elements including sunlight, wind, rain and wildlife. Because of this the netting must be inspected prior to every use. Please see more details under Section "Important Warning about Enclosure Netting and Pad" contained in this manual.

MOVING THE TRAMPOLINE:

- Two or three people will be needed to move trampoline.
- Before lifting the trampoline, all connector points must be wrapped and secured with weather resistant tape, e.g. duct tape. This will keep the frame intact during the move and prevent the connector points from dislocating and separating.
- Keep the trampoline steady and horizontal to the ground during the move. Do not pick up the frame more than two inches off the ground. Picking it up too high can cause the frame to warp. If this should happen, put the trampoline back down, press down on the part that is warped and the tension of the springs should flatten the frame.
- Trampoline is not designed to be moved. However if you need to move the trampoline for any reason, you must use duct tape or heavy industry tape to tape all leg joints together. Failure to do so, may result in the leg support coming loose and may cause serious injury or death.

WEATHER CONDITIONS:

Please be aware of the weather conditions when using the trampoline. If the mat of the trampoline is wet, the jumper could slip and suffer injuries. If it is too windy, jumpers could lose control. Use the trampoline only when the jumping mat is clean and dry. A wet jumping mat is extremely slick and prevents a stable landing. Trampoline should be stored away during harsh weather conditions including extreme heat and snow or freezing temperature. Extreme temperature may cause damages and tears to the mat and netting and cause injury.

WINDY WEATHER:

The product must not be used in windy conditions as wind can cause unexpected movement of the product. The product must be properly stored away or disassembled completely during severe windy conditions. If you live in an area where there are winds strong enough to move the product, you should consult a local contractor about ways to secure the product in your location.

LIMIT ACCESS:

Always properly store away the trampoline and enclosure when not in use and secure from any unauthorized use. When the trampoline is not in use, always store the access ladder in a secure place so that unsupervised children cannot play on the trampoline.

PROPER USE INSTRUCTIONS

MAXIMUM USER WEIGHT:

This trampoline is designed for a maximum weight of 220lbs (100kg).

Trampolines over 20 inches (51 cm) tall are not recommended for use by children under 6 years of age.

MOUNTING AND DISMOUNTING:

Be very careful when getting on and off the trampoline. DO NOT mount the trampoline by grabbing the Frame Pad, stepping onto the springs or by jumping onto the mat of the trampoline from any object (i.e. a deck, roof or ladder). This will increase your chance of getting injured! DO NOT dismount by jumping off the trampoline and landing on the ground, regardless of the makeup of the ground. If small children are playing on the trampoline, they should be assisted when dismounting.

USE OF ALCOHOL AND DRUGS:

DO NOT consume any alcohol or drugs when using this trampoline! This will increase your chances of getting injured since these foreign substances impair your judgment, reaction time and overall physical coordination.

MULTIPLE JUMPERS:

No more than one person should jump on the trampoline at any one time. Multiple jumpers increase the chance of injuries being suffered, such as jumpers bumping into each other or being pushed off the trampoline or onto the springs. Generally, the lightest person on the trampoline will get injured. No more than one person at a time on the trampoline.

STRIKING THE FRAME OR SPRINGS:

When playing on the trampoline, STAY in the center of the mat. This will reduce your risk of getting injured by landing on the frame or springs. Always keep the frame pad covering the frame of the trampoline. DO NOT jump or step onto the frame pad directly since it was not intended to support the weight of a person.

MAINTAIN CONTROL:

DO NOT attempt difficult maneuvers, or any fancy moves which may cause you to lose control of your jump. If you do, you will increase your risk of getting injured by landing on the frame, springs, or falling off of the trampoline completely. A controlled jump is when you land in the same spot where you took off from. If you do lose control when you are jumping on the trampoline, bend your knees sharply when you land and this will allow you to regain control and stop your jump.

SOMERSAULTS (FLIPS):

DO NOT PERFORM somersaults of any type (backwards or forwards) on this trampoline. This can cause serious injuries, including broken neck or back and even death or paralysis.

FOREIGN OBJECTS:

DO NOT use the trampoline if there are pets, people, or any objects underneath the trampoline. Also, do not jump on the trampoline with snow board, skateboard, roller blades, bicycle or any other equipment not authorized by the manufacturer. DO NOT hold any foreign objects in your hand and DO NOT place any objects on the trampoline while anyone is playing on it. Please be aware of what is overhead when you are playing on the trampoline. Tree limbs, wires or other objects located over the trampoline will increase your chance of getting injured.

IMPORTANT! KEEP FOR FUTURE REFERENCE:

Adult assembly required.

WARNING! Keep small parts out of the reach of children under 36 months because of possible choking hazard.

Customer Help Line Telephone Number: 0843-503 44 55 Monday-Friday 9:00am-4:30pm

IMPORTANT SAFETY INSTRUCTIONS

FAILURE TO FOLLOW INSTRUCTIONS AND WARNINGS COULD RESULT IN SERIOUS INJURY OR DEATH.

All jumpers need to be supervised, regardless of skill level or age.

Jumper's role in accident prevention

The key here is to stay in control of your jumps. DO NOT move onto more complicated, more difficult maneuvers until you have mastered the basic, fundamental bounce. Read, understand, and practice all safety precautions and warnings prior to using the trampoline. A controlled jump is when you land and take off from the same location. For additional safety tips and instructions, contact a certified trampoline instructor.

Supervisor's or owner's role in accident prevention

Supervisors need to understand and enforce all safety rules and guidelines. It is the responsibility of the supervisor to provide knowledgeable advice and guidance to all jumpers of the trampoline. If supervision is unavailable or inadequate, the trampoline should be stored in a secure place, disassembled to prevent unauthorized use or covered with a heavy tarp that can be locked or secured with lock or chains. The supervisor is also responsible to ensure that the safety placard is placed on the trampoline and that jumpers are informed of these warnings and instructions.

LESSON PLAN

WARNING:

**ALWAYS START YOUR JUMP AT THE MIDDLE OF TRAMPOLINE MAT
INDICATED BY WHITE CIRCLE**

The following lessons are suggested for you to learn basic steps and bounces. Before using the trampoline, you should read and understand all safety instructions. A complete discussion and demonstration of body mechanics and trampoline guidelines should occur between the supervisor and student as well.

Lesson 1

- A. Mounting and Dismounting-Demonstration of proper techniques
- B. The Basic Bounce-Demonstration and practice
- C. Braking (Check the Bounce-Demonstration) and practice. Learn to brake on command
- D. Hands and knees-Demonstration and practice. Stress should be on four-point landing and alignment

Lesson 2

- A. Review and practice of techniques learned in Lesson 1
- B. Knees Bounce-Demonstration and practice. Learn the basic down to knee and back up before trying half twist to left and right
- C. Seat Bounce-Demonstration and practice. Learn basic seat bounce then add a knee bounce, hands and knees repeat

Lesson 3

- A. Review and practice skills and techniques learned in previous lessons
- B. Front Drop-To avoid mat burns and teach the front bounce position, all students should be requested to assume the prone position (face down on the ground) while the instructor checks for faulty positions that could cause injury

- C. Start with a hands and knees bounce and then extend body into prone position, and on the mat and return to feet
- D. Practice Routine-Hands and knees Bounce, Front Bounce, back to feet, seat bounce, back to feet, seat bounce, back to feet

Lesson 4

B. Review and practice skills and techniques learned in previous lessons

C. Half-Turn

- i. Start from front drop position and as you make contact with mat, push off with arms in either the right or left direction and turn head and shoulders in same direction
- ii. During turn, be sure to keep back parallel to mat and head up
- iii. After completing turn, land in front drop position


After completing this lesson, the student now has a basic foundation of trampoline bounces. Jumpers should be encouraged to try and develop their own routines with the emphasis on control and form..

A game that can be played in order to encourage students to try develop routines is "BOUNCE". In this game, players count off from 1 to X. Player one starts with a maneuver. Player two has to do Player one's maneuver and add on another. Player cannot do the routine properly in the correct sequence. The first person to miss, receives the letter "B". This continues until someone spells out the word "BOUNCE". The last remaining contestant is deemed the winner! Even when playing this game, it is important to perform your routines under control and not try difficult or highly skilled bounces that you have not yet mastered.

A certified trampoline instructor should be contacted to further develop your trampoline skills.


BASIC TRAMPOLINE BOUNCES

THE BASIC BOUNCE




1. Start from standing position, feet shoulder width apart and with head up and eyes on mat.
2. Swing arms forward and up and around in a circular motion.
3. Bring feet together while in mid-air and point toes downward.
4. Keep feet shoulder width apart when landing on mat.

KNEE BOUNCE




1. Start with basic bounce and keep it low.
2. Land on knees keeping back straight, body erect and use your arms to maintain balance.
3. Bounce back to basic bounce position by swinging arms up.

SEAT BOUNCE



1. Land in a flat sitting position.
2. Place hands on mat besides hips, do not lock your elbow.
3. Return to erect position by pushing with hands.

180 DEGREE BOUNCE



1. Start with front bounce position.
2. Push off with left or right hands and arms (depending on which way you wish to turn).
3. Maintain head and shoulders in the same direction and keep back parallel to mat and head up.
4. Land in prone position and return to standing position by pushing up with hands and arms



WARNING:

**ALWAYS START YOUR JUMP AT THE MIDDLE OF TRAMPOLINE MAT
INDICATED BY WHITE CIRCLE**

PRODUCT WARRANTY

All warranty coverage extends only to the original purchaser of the product and is not assignable or transferable. The original store or online purchase receipt must be kept as proof of purchase in order for the warranty to be valid. These documents must be presented in the event of making a claim under warranty.

During the warranty period, Sportspower will provide repair or replacement of defective equipment or parts thereof covered by the warranty. Any handling, transportation, delivery and other incidental charges in respect of the servicing of the equipment shall be borne by the Purchaser. If the product includes a number of accessories, only the defective part or accessory will be replaced.

The warranty will become void if any defects or damages are associated with the use of unauthorized replacement parts. All replacement parts must be obtained from Sportspower authorized agents.

All decisions made by Sportspower in respect of the servicing of the equipment (including repairs, replacements or issues relating to defects of workmanship or materials) shall be conclusive and the Purchaser agrees to be bound by such decisions. Any defective equipment or part thereof replaced shall become the property of Sportspower.

In the event of a product or accessory being replaced during the guarantee, the guarantee on the replacement will expire at the original date, i.e. 90 days from the original purchase date.

This warranty excludes defects caused by the product not being used in accordance with instructions, accidental damage, misuse or being tampered with by unauthorized persons.

The Sportspower Limited Warranty does not cover:

- (a) Products used for commercial or rental purposes.
- (b) Loss or damage to product due to: (i) abuse, repairs and/or tampering by any person other than the authorized personnel of Sportspower; (ii) negligence and/or misuse (including foreign object, accident, improper storage, exposure to sun/moisture, excessive temperature, sand, dust, dirt, other pollution or other environmental conditions and failure to follow precautions or proper operating instructions stated in the User's Manual such as improper installations); (iii) fire, flood, lightning strike, wind storm or other acts of God; (vi) freight or improper transport damages, and (v) improper usage (including use by under-age, over-weight or excessive number of users permitted as stated in the User's Manual).
- (c) Defects, damages or accidents due to the malfunction, connection to or use of non-Sportspower or unauthorized parts. In such event, Sportspower reserves the right to cancel the Limited Warranty coverage immediately.

To the extent allowed by the applicable local law, the remedies in the Limited Warranty are the Purchaser's sole and exclusive remedies.

SPORTSPOWER IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

CUSTOMER SERVICE/ SPARE PARTS 0843-503-44-55

Customer Help Line Telephone Number: 0843-503 44 55 Monday-Friday 9:00am-4:30pm