

01SBS0202-V1

Single Wheelie Bin Store

BEFORE YOU START PLEASE READ INSTRUCTIONS CAREFULLY

- Check the pack and make sure you have all the parts listed.
- When you are ready to start, make sure you have the right tools at hand (not supplied) including a Phillips screwdriver, Stanley knife, wood saw, step ladder and drill with 2mm bit.
- Ensure there is plenty of space and a clean dry area for assembly.

TIMBER

As with all natural materials, timber can be affected during various weather conditions. For the duration of heavy or extended periods of rain, swelling of the wood panels may occur. Warping of the wood may also occur during excessive dry spells due to an interior moisture loss. Unfortunately, these processes cannot be avoided but can be helped. It is suggested that the outdoor building is sprayed with water during extended periods of warm sunshine and sheltered as much as possible during rain or snow.

Our buildings are pre treated with a water based treatment**; this only helps to protect the product during transit and for upto 3 months against mould. To validate your guarantee and ensure longevity of the product, it is ESSENTIAL the building is treated with a wood preserver within the first three months of assembly and thereafter in accordance with the manufactures recommendations. Care must be taken to ensure the product is placed on a suitable base.

BUILDING A BASE

When thinking about where the building and base is going to be constructed: Ensure that there will be access to all sides for maintenance work and annual treatment.


Ensure the base is level and is built on firm ground, to prevent distortion. Refer to diagrams for the base dimensions, The base should be slightly smaller than the external measurement of the building, i.e. The cladding should overlap the base, creating a run off for water. It is also recommended that the floor be at least 25mm above the surrounding ground level to avoid flooding.

TYPES OF BASE

- Concrete 75mm laid on top of 75mm hard-core.
- Slabs laid on 50mm of sharp sand.

Whilst all products manufactured are made to the highest standards of Safety and in the case of childrens products independently tested to EN71 level, we cannot accept responsibility for your safety whilst erecting or using this product.

Refer to the instructions pages for you specific product code




x2

All building's should be erected by two adults



Winter = High Moisture = Expansion
Summer = Low Moisture = Contraction



2mm Drill bit

For ease of assembly, you **MUST** pilot drill all screw holes and ensure all screw heads are countersunk.



CAUTION
Every effort has been made during the manufacturing process to eliminate the prospect of splinters on rough surfaces of the timber. You are strongly advised to wear gloves when working with or handling rough sawn timber.

****Protim Aquatan T5 (621)****

Your building has been treated with **Aquatan**.

Aquatan is a water-based concentrate which is diluted with water, the building as been treated by the correct application of Aquatan solution and then allowed to dry.

Aquatan is a decorative finish to colour the wood, which is applied industrially to timber fence panels and garden buildings.

Aquatan *undiluted* contains: boric acid, sodium hydroxide 32% solution, aqueos mixture of sodium dioctyl sulphosuccinat and alcohols: 2, 4, 6-trichlorophenol.


For assistance please contact customer care on: 01636 880514

Mercia Garden Products Limited,
Sutton On Trent,
Newark,
Nottinghamshire,
NG23 6QN

www.merciagardenproducts.co.uk

Overall Dimensions:
Length = 840mm
Width = 750mm
Height = 1115mm




Base Dimensions:
Length = 840mm
Width = 750mm





Step 1

Rest the back panel and 1x side panel against each other (***ensuring they level & the back panel overlaps the side panel***) and secure together using 2x50mm screws.

2x50mm Screws



Nail Bag




Step 2

Following the same method outlined in step 1....

- a Rest the second side panel against the back panel (***ensuring it is level & the back panel overlaps the side panel***) and secure to the assembly using 2x50mm screws.


2x50mm Screws



Step 3


- a** Place the "U" bracket at the between the two side panels at the bottom, and fix into place with 4x20mm screws.
- b** Attach the panel frame at the front of the assembly (**ensuring the panel frame is level with the top of the assembly**) and secure using 2x50mm screws.

4x20mm Screws
2x50mm Screws



20mm
screw

50mm
screw



Step 5


Locate the door inbetween the two side panels and secure into place using 2x butt hinges and 12x30mm screws.

***Ensure to align the boards with the side panel as shown in the illustration.**

12x30mm Screws



30mm
screw




Step 4

Place the lid on top of the assembly (**ensuring it sits level and flush around all sides**) and fix into place using 2x butt hinges, securing with 6x30mm screws per hinge.

12x30mm Screws



30mm
screw



Step 6


Once the assembly is square & level around all sides, screw through the boards on the back panel into the side panel framing with 6x30mm screws.

***This helps to keep your bin store rigid.**

6x30mm Screws



30mm
screw



Step 7

Attach the turn button to the side panel framing using 1x30mm black screw.

**Do NOT screw the turn button too tight.*

6x30mm Black Screws

