

# General Instructions

Please retain product label and instructions for future reference

01VINLOG0303-V1 & 01VINSTR0303-V1

3x3 Log store and 3x3 store

## BEFORE YOU START PLEASE READ INSTRUCTIONS CAREFULLY

- Check the pack and make sure you have all the parts listed.
- When you are ready to start, make sure you have the right tools at hand (not supplied) including a Phillips screwdriver, Stanley knife, wood saw, step ladder and drill with 2mm bit.
- Ensure there is plenty of space and a clean dry area for assembly.

## TIMBER

As with all natural materials, timber can be affected during various weather conditions. For the duration of heavy or extended periods of rain, swelling of the wood panels may occur. Warping of the wood may also occur during excessive dry spells due to an interior moisture loss. Unfortunately, these processes cannot be avoided but can be helped. It is suggested that the outdoor building is sprayed with water during extended periods of warm sunshine and sheltered as much as possible during rain or snow.

Our buildings are pre treated with a water based treatment\*\*; this only helps to protect the product during transit and for upto 3 months against mould. To validate your guarantee and ensure longevity of the product, it is ESSENTIAL the building is treated with a wood preserver within the first three months of assembly and thereafter in accordance with the manufactures recommendations. Care must be taken to ensure the product is placed on a suitable base.

## BUILDING A BASE

When thinking about where the building and base is going to be constructed: Ensure that there will be access to all sides for maintenance work and annual treatment.


Ensure the base is level and is built on firm ground, to prevent distortion. Refer to diagrams for the base dimensions, The base should be slightly smaller than the external measurement of the building, i.e. The cladding should overlap the base, creating a run off for water. It is also recommended that the floor be at least 25mm above the surrounding ground level to avoid flooding.

## TYPES OF BASE

- Concrete 75mm laid on top of 75mm hard-core.
- Slabs laid on 50mm of sharp sand.

*Whilst all products manufactured are made to the highest standards of Safety and in the case of childrens products independently tested to EN71 level, we cannot accept responsibility for your safety whilst erecting or using this product.*

Refer to the instructions pages for you specific product code




x2

All building's should be erected by two adults



Winter = High Moisture = Expansion  
Summer = Low Moisture = Contraction



2mm Drill bit

For ease of assembly, you **MUST** pilot drill all screw holes and ensure all screw heads are countersunk.



**CAUTION**  
Every effort has been made during the manufacturing process to eliminate the prospect of splinters on rough surfaces of the timber. You are strongly advised to wear gloves when working with or handling rough sawn timber.

## Pressure Treated Timber

Pressure treating is a chemical process which helps to protect wood against adverse weather which could lead to rot or insect damage.

The most common chemicals used to pressure treat wood are **Alkaline Copper Quaternary (ACQ)**, **Copper Azole (CA)**, and **Micronized Copper Quaternary (MCQ)**.

**Safety:** Always wear gloves, eye protection and a dust mask when handling wood. Due to chemicals in pressure treated wood, never burn its sawdust or scraps; instead dispose in a landfill.





For assistance please contact customer care on: 01636 880514

Mercia Garden Products Limited,  
Sutton On Trent,  
Newark,  
Nottinghamshire,  
NG23 6QN

[www.merciagardenproducts.co.uk](http://www.merciagardenproducts.co.uk)


**Overall Dimensions:**  
Length = 992mm  
Width = 1003mm  
Height = 1559mm

**Base Dimensions:**  
Length = 968mm  
Width = 968mm




**Pre Assembly**

Before assembling remove the transportation  
blocks from the bottom of each panel.



**Step 1**

Place the floor onto a firm and level  
base, ensuring the base has suitable  
drainage & is free from areas where  
standing water can collect.



**Step 2**


Place the first gable, back panel and  
rear post onto the floor. Secure each  
panel to the rear post using 3x50mm  
screws per panel.

*\*Ensure the panels are flush to the  
inside edge of the post.*

Fix the panels to the floor with  
2x50mm screws per panel, making  
sure to align the screws with the  
floor bearers.

*\*Before securing to the floor ensure  
the post is flush with end of the floor.*

**10x50mm Screws**




### Step 3

Attach the second rear post to the building, screwing through the panel into the post as shown in the illustration.

**\*Ensure the panel is flush to the inside edge of the post.**




#### 3x50mm Screws



### Step 4

Following the same method outlined in steps 2 & 3 fix the second gable into position and secure the front posts in place using 50mm screws.

#### 11x50mm Screws





### Step 5

Place the roof on top of the building, aligning the roof so that it is flush with the rear. Secure the roof in place with 4x70mm screws as shown in the illustration.

**\*Ensure to screw through the roof into the posts.**



#### 4x70mm Screws



### Step 6

Attach the fascia's to the front and sides of the building, securing each fascia into place using 3x30mm screws.

#### 9x30mm Screws




**Step 7: 01VINSTR0303-V1 Only**

Place the door into the door gap and fix into place using 3x T-hinges securing each hinge with 7x30mm black screws.

*\*Ensure the door can open & close freely without restriction.*

**21x30mm Black Screws**




**Step 8: 01VINSTR0303-V1 Only**

**a** Fix the turn buttons to the top and bottom of the posts, ensuring they fasten the door, using 2x30mm black screws.

**b** Secure the hasp and staple to the post and door using 5x30mm black screws.

**7x30mm Black Screws**



*\*Please note: The door can be hinged either way depending on your needs for the product.*