



STEALTH




UK: SET-UP & INSTRUCTIONS

ATTENTION: PLEASE READ THIS BEFORE USE


CONTROLS



CHAT VOLUME





MIC MUTE - OFF/ON



PLEASE ENSURE THE VOLUME IS TURNED UP TO A SUITABLE LEVEL AND ENSURE THE MICROPHONE MUTE IS SET TO THE 'OFF' POSITION.

XBOX ONE™ SET-UP



CURRENT XBOX ONE
CONTROLLER - 3.5MM



*ORIGINAL XBOX ONE
CONTROLLER



CURRENT XBOX ONE™ CONTROLLERS HAVE A 3.5MM JACK CONNECTION SITUATED ON THE BASE OF THE CONTROLLER

1. SIMPLY PLUG THE 3.5MM JACK CABLE FROM THE HEADSET DIRECTLY INTO THE AVAILABLE PORT ON YOUR XBOX ONE™ CONTROLLER

IF YOU ARE USING AN ORIGINAL XBOX ONE™ CONTROLLER YOU WILL REQUIRE THE *XBOX ONE STEREO HEADSET ADAPTER (SOLD SEPARATELY)

2. CONNECT THE XBOX ONE™ STEREO HEADSET ADAPTER TO YOUR XBOX ONE™ CONTROLLER

3. PLUG THE 3.5MM CONNECTION FROM THE HEADSET INTO YOUR ADAPTER

THE HEADSET SHOULD NOW BE WORKING UPON CONNECTION, IF YOU ARE EXPERIENCING PROBLEMS
PLEASE FOLLOW THE INSTRUCTIONS BELOW:

- PRESS  SITUATED ON YOUR CONTROLLER AND SELECT THE 'SYSTEM' TAB (LAST ICON ALONG THE TOP ON THE RIGHT)

1. SELECT SETTINGS
2. DISPLAY & SOUND
3. AUDIO OUTPUT
4. HEADSET AUDIO
5. SELECT HEADSET FORMAT - WINDOWS SONIC FOR HEADPHONES ON XBOX ONE

CHECKING THE PARTY CHAT MIX

PLEASE FOLLOW THE STEPS BELOW IF YOUR FRIENDS CANT HEAR YOU TALK BUT YOU CAN HEAR THEM?


- PRESS  SITUATED ON YOUR CONTROLLER AND SELECT THE 'SYSTEM' TAB (LAST ICON ALONG THE TOP ON THE RIGHT)

YOU SHOULD THEN SEE THE OPTION 'AUDIO'

(IF THIS DOES NOT APPEAR PLEASE ENSURE THE HEADSET IS PLUGGED CORRECTLY INTO YOUR XBOX ONE™ CONTROLLER AND ALL SOFTWARE AND CONTROLLERS HAVE THE LATEST UPDATES. YOU CAN ALSO ESTABLISH IF THE HEADSET IS WORKING BY TESTING IN A MOBILE OR TABLET.)

PLEASE NOTE:

- 'HEADSET VOLUME' & 'MIC MONITORING' SHOULD BE TURNED UP FULL (MOVE THE SLIDER ALL THE WAY TO THE RIGHT)
- ENSURE THE HEADSET MIC IS TURNED ON



STILL NEED OUR HELP?

[STEALTH GAMING SUPPORT PAGE](#)
[SUPPORT ARTICLES](#)

**TECHNICAL SUPPORT
QUESTIONS / SET-UP / NOT WORKING?**

ONLINE: [STEALTHGAMING.NET/SUPPORT](https://stealthgaming.net/support)

EMAIL: HELP@ABPTECH.CO.UK


PHONE: **01204 369 237**

MON-THURS- 9AM-5PM

FRIDAY - 9AM TO 4PM (ALL CALLS CHARGED AT NATIONAL RATE)

TO ENSURE THAT YOUR CALL IS HANDLED QUICKLY AND EFFECTIVELY PLEASE ENSURE THAT YOU HAVE THE MODEL NUMBER, (SITUATED BY THE BARCODE ON THE BASE OF THE BOX) AND ANY OTHER RELEVANT INFORMATION REGARDING YOUR PRODUCT TO HAND WHEN YOU RING.

PLAYSTATION®4 SET-UP



INSERT THE HEADSETS 3.5MM JACK PLUG INTO YOUR DUALSHOCK®4 WIRELESS CONTROLLERS HEADPHONE CONNECTION

PS4™ SYSTEM SET-UP

IN ORDER TO HEAR THE IN-GAME AUDIO THROUGH THE HEADSET, YOU MUST MAKE SURE THAT YOUR PS4™ SYSTEM IS SET-UP AS FOLLOWS:

'SETTINGS' > 'DEVICES' > 'AUDIO DEVICES' > 'OUTPUT TO HEADPHONES' > 'CHAT AUDIO'

ADJUST THE HEADSET AUDIO LEVELS

THE VOLUME LEVEL OF THE HEADSET AND MICROPHONE CAN BE ADJUSTED WITHIN THE PS4™ SYSTEM MENU AS FOLLOWS:

HEADSET VOLUME: 'SETTINGS' > 'DEVICES' > "AUDIO DEVICES" > 'VOLUME CONTROL' (HEADPHONES)

MICROPHONE LEVEL: 'SETTINGS' > 'DEVICES' > "AUDIO DEVICES" > 'ADJUST MICROPHONE LEVEL'
(ADJUST THE MICROPHONE LEVEL UNTIL THE INDICATOR SHOWS 'GOOD')

IF ANY OF THE ABOVE OPTIONS ABOVE ARE NOT AVAILABLE TO YOU, PLEASE ENSURE THE HEADSET IS PLUGGED CORRECTLY INTO YOUR DS4 CONTROLLER.

STILL NEED OUR HELP?

[STEALTH GAMING SUPPORT PAGE](#)
[SUPPORT ARTICLES](#)

**TECHNICAL SUPPORT
QUESTIONS / SET-UP / NOT WORKING?**

ONLINE: [STEALTHGAMING.NET/SUPPORT](https://stealthgaming.net/support)
EMAIL: HELP@ABPTECH.CO.UK


PHONE: [01204 369 237](tel:01204369237)

MON-THURS- 9AM-5PM


FRIDAY - 9AM TO 4PM (ALL CALLS CHARGED AT NATIONAL RATE)

TO ENSURE THAT YOUR CALL IS HANDLED QUICKLY AND EFFECTIVELY PLEASE ENSURE THAT YOU HAVE THE MODEL NUMBER, (SITUATED BY THE BARCODE ON THE BASE OF THE BOX) AND ANY OTHER RELEVANT INFORMATION REGARDING YOUR PRODUCT TO HAND WHEN YOU RING.


NINTENDO SWITCH™ SET-UP



PC & MOBILE/TABLET SET-UP



MOST NEW PC'S HAVE A SINGLE 3.5MM JACK CONNECTION. SIMPLY PLUG THE 3.5MM JACK FROM THE HEADSET DIRECTLY INTO THE PORT ON YOUR PC. THE SAME APPLIES WHEN CONNECTING TO A MOBILE OR TABLET.



IF YOUR PC USES SEPARATE GREEN/PINK CONNECTORS YOU WILL NEED A PC SPLITTER CABLE (SOLD SEPARATELY)

CONNECT THE PC SPLITTER CABLE TO YOUR HEADSET AND PC AS FOLLOWS:

1. PLUG THE 3.5MM JACK CABLE FROM THE HEADSET INTO THE SINGLE END OF THE PC SPLITTER
2. THE HEADPHONE SOCKET IS TYPICALLY GREEN. PLUG THIS INTO THE GREEN PORT ON YOUR PC
3. THE MICROPHONE SOCKET IS TYPICALLY PINK. PLUG THIS INTO THE PINK PORT ON YOUR PC

IF YOU ARE EXPERIENCING ANY PROBLEMS REFER TO YOUR SETTINGS, PLEASE GO TO...

1. CONTROL PANEL
2. HARDWARE
3. SOUND

STILL NEED OUR HELP?

[STEALTH GAMING SUPPORT PAGE](#)
[SUPPORT ARTICLES](#)

TECHNICAL SUPPORT QUESTIONS / SET-UP / NOT WORKING?

ONLINE: [STEALTHGAMING.NET/SUPPORT](https://stealthgaming.net/support)
EMAIL: [HELP@ABPTECH.CO.UK](mailto:help@abptech.co.uk)

PHONE: [01204 369 237](tel:01204369237)

MON-THURS- 9AM-5PM

FRIDAY - 9AM TO 4PM (ALL CALLS CHARGED AT NATIONAL RATE)

TO ENSURE THAT YOUR CALL IS HANDLED QUICKLY AND EFFECTIVELY PLEASE ENSURE THAT YOU HAVE THE MODEL NUMBER, (SITUATED BY THE BARCODE ON THE BASE OF THE BOX) AND ANY OTHER RELEVANT INFORMATION REGARDING YOUR PRODUCT TO HAND WHEN YOU RING.

LEGAL INFORMATION

PLEASE KEEP THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE. IF YOU REQUIRE ANY HELP OR ASSISTANCE PLEASE CONTACT THE HELPLINE OR VISIT [STEALTHGAMING.NET/SUPPORT](https://stealthgaming.net/support)

WARRANTY

THIS PRODUCT IS GUARANTEED FOR A PERIOD OF ONE YEAR FROM THE DATE OF PURCHASE. DURING THIS PERIOD IF THERE IS A DEFECT DUE TO FAULTY MATERIALS, OR WORKMANSHIP THE RETAILER FROM WHOM YOU PURCHASED IT WILL REPLACE IT WITH THE SAME OR A SIMILAR MODEL ON PRODUCTION OF YOUR PURCHASE RECEIPT OR PROOF OF PURCHASE. THIS GUARANTEE DOES NOT COVER DEFECTS ARISING FROM ACCIDENTAL DAMAGE, MISUSE OR WEAR AND TEAR, AND IS AVAILABLE ONLY TO THE ORIGINAL PURCHASER OF THE PRODUCT. THIS DOES NOT AFFECT YOUR STATUTORY RIGHTS.



TO PREVENT POSSIBLE HEARING DAMAGE, DO NOT LISTEN AT HIGH VOLUME LEVELS FOR LONG PERIODS.

PRECAUTIONS

- ENSURE THAT THE VOLUME CONTROL IS SET TO THE MINIMUM LEVEL BEFORE CONNECTING THE HEADSET TO YOUR SYSTEM
- BEFORE WEARING THE HEADSET, SET THE VOLUME CONTROL TO ITS MINIMUM LEVEL THEN SLOWLY INCREASE UNTIL YOU REACH YOUR DESIRED VOLUME LEVEL
- LISTENING TO YOUR HEADSET AT ITS MAXIMUM LEVEL MAY CAUSE DAMAGE TO BOTH THE HEADSET AND YOUR EARS
- LONG TERM EXPOSURE TO LOUD MUSIC OR OTHER SOUNDS IN A HEADSET MAY CAUSE HEARING DAMAGE. IT IS BEST TO AVOID VERY HIGH VOLUME LEVELS WHEN USING A HEADSET, ESPECIALLY FOR EXTENDED PERIODS

IMPORTANT SAFEGUARDS & PRECAUTIONS

- NEVER EXPOSE TO DIRECT SUNLIGHT OR WET WEATHER CONDITIONS
- DO NOT EXPOSE THE UNIT TO SPLASHING, DRIPPING, RAIN OR MOISTURE. DO NOT IMMERSE IN LIQUID
- DO NOT EXPOSE TO DUST, HIGH HUMIDITY, HIGH TEMPERATURES OR MECHANICAL SHOCK
- AVOID ANY UNNECESSARY STRAIN OF THE CABLE
- DO NOT CARRY THE HEADSET BY ITS CABLE
- DO NOT USE IF THE EQUIPMENT IS DAMAGED
- DO NOT DISASSEMBLE; THERE ARE NO SERVICEABLE PARTS INSIDE
- FOR EXTERNAL CLEANING, USE A SOFT, CLEAN, DAMP CLOTH ONLY. USE OF DETERGENTS MAY DAMAGE THE CABINET FINISH AND LEAK INSIDE

RECYCLING



WHERE YOU SEE THIS SYMBOL ON ANY OF OUR ELECTRICAL PRODUCTS, BATTERIES OR PACKAGING, IT INDICATES THAT THE RELEVANT ELECTRICAL PRODUCT OR BATTERY SHOULD NOT BE DISPOSED OF AS GENERAL HOUSEHOLD WASTE IN THE EU OR TURKEY. TO ENSURE THE CORRECT WASTE TREATMENT OF THE PRODUCT AND BATTERY, PLEASE DISPOSE OF THEM IN ACCORDANCE WITH ANY APPLICABLE LOCAL LAWS OR REQUIREMENTS FOR DISPOSAL OF ELECTRICAL EQUIPMENT/BATTERIES. IN SO DOING, YOU WILL HELP TO CONSERVE NATURAL RESOURCES AND IMPROVE STANDARDS OF ENVIRONMENTAL PROTECTION IN TREATMENT AND DISPOSAL OF ELECTRICAL WASTE.

THE RECYCLING AND PROCESSING OF WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT WILL MAKE A SIGNIFICANT CONTRIBUTION TOWARDS HELPING PROTECT THE ENVIRONMENT BY REDUCING LANDFILL WASTE.

NOT RECOMMENDED FOR CHILDREN UNDER 6 YEARS OF AGE.

MADE IN CHINA

STEALTH



Not recommended for children under 6 years of age. Please retain this packaging for future reference. Due to the company's policy of constant improvement and technical refinement, the company reserve the right to alter the specification.
This product is not sponsored, endorsed or approved by Microsoft. XBOX ONE™ is a registered trademarks of Microsoft Co. Ltd.
This product is not sponsored, endorsed or approved by Sony Interactive Entertainment. PS4™ is a registered trademarks of Sony Interactive Entertainment.
This product is not sponsored, endorsed or approved by Nintendo. Nintendo Switch™ is a registered trademark of Nintendo Co. Ltd.
Manufactured by ABP Technology Ltd. Bolton, BL2 1BX. MADE IN CHINA.