


Walton - 2 Door Cupboard

Assembly Instructions - Please keep for future reference

145/0233



Dimensions

Width - 80.5cm

Depth - 59.5cm

Height - 74cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 31kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings (not supplied).

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the panels listed below



1 Left Side (D2255A)
(718 x 570mm)



2 Right Side (D2256A)
(718 x 570mm)




3 Top (D2254A)
(802 x 593mm)




4 Base (D2257A)
(767 x 567mm)



5 Shelf (D2258A)
(767 x 564mm)



6 Door (D2259A)
(678 x 396mm) x 2



7 Back (X793-708)
(793 x 708mm)













Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 8</p>	<p>B </p> <p>Metal dowel (F901) x 8</p>	<p>C </p> <p>Large locking nut (F900) x 8</p>
<p>D </p> <p>Nail (F51) x 20</p>	<p>E </p> <p>13mm Screw (F63) x 8</p>	<p>F </p> <p>Shelf stud (F110) x 4</p>
<p>G </p> <p>Hinge plate (F523) x 4</p>	<p>H </p> <p>Hinge (F518) x 4</p>	
<p>I </p> <p>Handle (FWALTON) x 2</p>	<p>J </p> <p>19mm Screw (F461) x 4</p>	

Tools required




Rule



Cross-head screwdriver



Scissors



Hammer




Eye protection (when using a hammer or drill)



Electric drill (do not use for fitting screws)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Step 1

Prepare the left side

Tap 2 wooden dowels **A** into the left side **1**.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.



Screw 2 metal dowels **B** into the left side **1**.

Note: Tighten metal dowels up fully against the panels.

Insert 2 large locking nuts **C** into the left side **1**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.

Fit 2 hinge plates **G** onto the left side **1**, making sure that the slot is facing towards the front edge.



Step 2



Prepare the right side

Tap 2 wooden dowels **A** into the right side **2**.

Screw 2 metal dowels **B** into the right side **2**.

Insert 2 large locking nuts **C** into the right side **2**.

Fit 2 hinge plates **G** onto the right side **2**, making sure that the slot is facing towards the front edge.




Assembly Instructions

Step 3

Prepare the base

Tap 4 wooden dowels **A** into the base **4**.

Insert 4 large locking nuts **C** into the base **4**.




Step 4

Join the right side and base

Push the base **4** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base **4**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Assembly Instructions


Step 5

Fit the left side

Push the left side **1** onto the base **4**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base **4**.


Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Step 6

Prepare the top

Screw 4 metal dowels **B** into the top **3**.



Assembly Instructions


Step 7

Fit the top

Push the top **3** onto the left side **1** and right side **2**.

Use a screwdriver to tighten the 4 large locking nuts **C** fitted to the left side **1** and right side **2**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Step 8

Fit the back

a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

b: Place the back **7** onto the unit.

Nail **D** around the outside edges of the back **7**.


Note: Nails should be spaced about 150mm apart.

Stand the unit up for the next step.



Warning: The unit is heavy. Lift with care.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




Assembly Instructions

Step 9

Fit the shelf studs


Insert 4 shelf studs **F** at the required height.



Step 10

Fit the shelf

Lower the shelf **5** down onto the shelf studs **F**.




Step 11

Prepare the 2 doors

Push fit 2 hinges **H** into each of the doors **7**.

Secure each hinge with 2 screws **E**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the edge of the door.



Assembly Instructions

Step 12

Fit doors and handles

Note: The easiest way to attach each door **7** is to fit the top hinge first, then align and fit the other hinge.



a: Push the hinge **H** onto the front part of the hinge plate **G**. The recess at the bottom of screw **B** goes into the slot in the hinge plate.

b: Keep the hinge **H** FLAT against the hinge plate **G** as you slide it across as far as it will go. Tighten screw **A**.

c: The hinge **H** must be flat against the hinge plate **G** prior to any adjustment.

d: The hinge **H** must NOT be AT AN ANGLE to the hinge plate **G** when assembled. This would indicate that the recess at the bottom of screw **B** had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **I** to each door **7** using 2 screws **J**.



Assembly Instructions

Step 13

Adjust the doors if needed

a: Before adjusting the doors, use a spirit level to check the base (or top) of the unit is level, front-to-back and side-to-side in the 3 positions shown. Use suitable packing pieces (not supplied) to make the unit level BEFORE making any adjustment to the hinges, as shown.

b: Height adjustment.


Loosen screws A on hinge plates and move door up or down as required. Retighten screw A.

c: Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required. Retighten screw B.

d: Sideways adjustment.

To move door 'out' loosen screw C. To move door 'in' tighten screw C.




Assembly Instructions

Step 14

Assembly is complete



Warning: The unit is heavy. Lift with care.



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW