

Cheval - Corner Mirror Robe


Assembly Instructions - Please keep for future reference

151/5556

151/2999

147/3533

152/6882



Dimensions

Width - 65cm

Depth - 65cm

Height - 200cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 51kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the bracket supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

IMPORTANT INFORMATION ABOUT THIS PRODUCT

This product complies with the requirements of BS 7449:1991 and has been manufactured by DECORATIVE PANELS FURNITURE LTD, TEESIDE INDUSTRIAL ESTATE, THORNABY-ON-TEES, CLEVELAND, TS17 9LT.

The product code for this unit and the item code(s) for the glass components are listed in the Assembly Instructions along with a description of the type of glass used. All clear/tinted glass complies with the requirements of BS 6206 Class A. All mirrors comply with the requirements of BS 6206 Class C. If the glass component contained in this unit is chipped or broken consult the furniture manufacturer, retailer, or agent with regard to obtaining a manufacturing specification and shape for replacement glass quoting the unit description and batch number or date of manufacture.

Do not place very hot or very cold items against or in close proximity to glass surface(s) unless adequately thick insulating material is used to prevent such items coming in contact with the glass.

Do not strike the glass with hard or pointed items.

Do not sit or stand upon horizontal glass surfaces.

When cleaning glass panels use a damp cloth or leather with washing up liquid or soft soap if necessary - do not use washing powders or any other substance containing abrasives since these substances scratch glass.

If stated in the instruction leaflet, it is essential that this unit is fixed to a wall.


KEEP THESE INSTRUCTIONS FOR FUTURE USE


Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels


If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the panels listed below


 The 2 triangular pieces are not used. They are for packing purposes only.




1 Left Side (D2739A)
(1981 x 400mm)




2 Right Side (D2740A)
(1981 x 400mm)




3 Mirror Door (D2741MA)
(1888 x 331mm)
(Mirror - SG24
1817 x 260mm
Safety Back SAR)




4 Top (D2745A)
(650 x 650mm)



5 Base (D2744A)
(634 x 634mm)




6 Left Back (D2748A)
(1879.5 x 330mm)



7 Right Back (D2747A)
(1879.5 x 330mm)



8 Shelf (D2746A)
(617 x 300mm)




9 Plinth (D2742A)
(86 x 344mm)



10 Support (D2743A)
(86 x 637mm)



11 Hanging Rail (FHR609)
(609mm long)



12 Back (X1900-350)
(1900 x 350mm) x 2



















Components - Fittings











If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 12</p>	<p>B </p> <p>Metal dowel (F901) x 8</p>	<p>C </p> <p>Large locking nut (F900) x 8</p>
<p>D </p> <p>Nail (F51) x 37</p>	<p>E </p> <p>40mm Screw (F910) x 12</p>	<p>F </p> <p>19mm Screw (F461) x 2</p>
<p>G </p> <p>13mm Screw (F79) x 9</p>	<p>H </p> <p>13mm Screw (F63) x 10</p>	<p>I </p> <p>Rail Holder (F891) x 2</p>
<p>J </p> <p>Bracket (F327) x 1</p>	<p>K </p> <p>Hinge plate (F322) x 3</p>	<p>L </p> <p>Hinge (F321) x 3</p>
<p>M </p> <p>Handle (F274) x 1</p>	<p>N </p> <p>Mini block (F25) x 3</p>	<p>O </p> <p>Shelf stud (F110) x 4</p>
<p>P </p> <p>Plastic Nail (F91) x 7</p>		

Tools required

<p></p> <p>Rule</p>	<p></p> <p>Spirit level</p>	<p></p> <p>Eye protection (when using a hammer or drill)</p>	<p></p> <p>Cross-head screwdriver</p>	<p></p> <p>Electric drill (only use when drilling into walls)</p>	<p></p> <p>Step ladder</p>
<p></p> <p>Square</p>	<p></p> <p>Scissors</p>	<p></p> <p>Hammer</p>	<p></p> <p>Bradawl</p>		

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

If you have damaged or missing components, call the Customer Helpline: 08456 400800 quoting the reference numbers below

Step 1

Prepare the base

Tap 4 wooden dowels **A** into the base **5**.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.


Insert 4 large locking nuts **C** into the base **5**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.


Turn the base over

Screw 4 metal dowels **B** into the base **5**.


Note: Tighten the metal dowels up fully against the panels.



Note: The base can have a plain chipboard surface.



Turn the base over




Step 2

Prepare the plinth and the support


Tap 2 wooden dowels **A** into the plinth **9**.

Tap 2 wooden dowels **A** into the support **10**.

Note: The plinth can have a plain chipboard surface.



Note: The colour of the support may differ from the main unit colour or may be plain chipboard.




Assembly Instructions

Step 3

Fit the plinth to the base

Push the plinth **9** onto the base **5** and fit it using 2 screws **E**.


Important: The plain chipboard surface must be at the back.



Step 4

Fit the support to the base

Push the support **10** onto the base **5** and fit it using 2 screws **E**.




Step 5

Prepare the right back

Insert 2 large locking nuts **C** into the right back **7**.

If required, to fit the rail holder **I**, screw through the top hole with screw **H** and into the mark hole drilled in the right back **7**. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **H** using the lower hole.

Only fit the rail holder to the right back if you want the hanging rail to go across the robe this way



Assembly Instructions


Step 6

Fit the right back

Push the right back **7** onto the 2 metal dowels fitted to the base **5**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the right back **7**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Step 7

Prepare the left back

Insert 2 large locking nuts **C** into the left back **6**.

Gently tap the 3 mini blocks **N** into the holes on the left back **6**, orientated as shown.

If required, to fit the rail holder **I**, screw through the top hole with screw **H** and into the mark hole drilled in the left back **7**. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **H** using the lower hole.



Assembly Instructions


Step 8

Fit the left back

Push the left back **6** onto the 2 metal dowels fitted to the base **5**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the left back **6**.

Tighten up the screws in the 3 mini blocks **N** into the holes in the right back **7**.



Step 9

Prepare the right side

If required, fit 3 hinge plates **K** onto the right side **2** making sure that the longer part is facing towards the finished front edge.



Screw 2 metal dowels **B** into the right side **2**.

Tap 2 wooden dowels **A** into the right side **2**.

If required, to fit the rail holder **I**, screw through the top hole with screw **H** and into the mark hole drilled in the right side **2**. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **H** using the lower hole.

Only fit the rail holder to the right side if you have fitted a rail holder to the left back

Only fit the hinges to the right side if you want your door to open this way




Assembly Instructions

Step 10

Fit the right side

Push the right side **2** onto the base **5**.


Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the bottom of the base **5**.



Step 11

Fit the top

Attach the top **4** to the right side **2**, left back **6** and right back **7** with 6 screws **E**.



Assembly Instructions

Step 12



Prepare the left side

If required, fit 3 hinge plates **K** onto the left side **1** making sure that the longer part is facing towards the finished front edge.

Screw 2 metal dowels **B** into the left side **1**.


Tap 2 wooden dowels **A** into the left side **1**.

If required, to fit the rail holder **I**, screw through the top hole with screw **H** and into the mark hole drilled in the left side **1**. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **H** using the lower hole.



Only fit the rail holder to the left side if you have fitted a rail holder to the right back

Only fit the hinges to the left side if you want your door to open this way




Step 13

Fit the left side

Push the left side **1** up into the top **4** and onto the base **5** and secure it to the top **4** with 2 screws **E**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the bottom of the base **5**.



Assembly Instructions

Step 14

Fit a back

Carefully roll the unit over, as shown.

Place a back **12** onto the unit so it is flush with the back edges of the top **4**, base **5** and left side **1**.

Using half the total quantity of nails **D**, nail the top **12** onto the back edges of the top, base and left side.


Note: Nails should be evenly spaced apart.

Secure the back **12** to the left back **6** using 4 screws **G**.

Roll the unit over



Warning: The unit is heavy. Lift with care.



Note: DO NOT nail into the left back **6**.

Step 15

Fit the other back

Carefully roll the unit over again, as shown.

Place a back **12** onto the unit so it is flush with the back edges of the top **4**, base **5** and right side **2**.

Using the rest of the nails **D**, nail into the back edges of the top, base and right side.


Note: Nails should be evenly spaced apart.

Secure the back **12** to the right back **7** using 4 screws **G**.

Roll the unit over



Warning: The unit is heavy. Lift with care.



Note: DO NOT nail into the right back **7**.

Assembly Instructions

Step 16


Fit the plastic nails

Tap 2 plastic nails **P** into the bottom edge of each of the sides **1** and **2**, 2 into the plinth **9** and 1 at the back of the support **10**, as shown.

Stand the unit up for the next step.



Warning: The unit is heavy. Lift with care.





Step 17

Fit the hanging rail

Push the hanging rail **11** into the rail holders **I**.

The diagram shows the rail being fitted to the left hand side of the unit. You may have chosen to fit it to the right hand side.



Assembly Instructions


Step 18

Fit the shelf

You can fit the shelf **8** on the left or the right of the unit.

If you have chosen the left, insert 2 shelf studs **○** into the left side **1** and 2 into the right back **7** at the required height. Insert the shelf and lower it onto the shelf studs.

If you have chosen the right, insert 2 shelf studs **○** into the right side **2** and 2 into the left back **6** at the required height. Insert the shelf and lower it onto the shelf studs.




Step 19

Prepare the door

Push fit the 3 hinges **L** into the door **3**.

Secure each hinge with 2 screws **H**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the edge of the door.



Assembly Instructions

Step 20


Fit the door and handle

Note: The easiest way to attach the door **3** is to fit the top hinge first, then align and fit the other hinges.


a: Push the slotted part of the hinge **L** over the centre screw on the hinge plate **K**. Keep the hinge **L** flat against the hinge plate as you slide it across as far as it will go.

b: When the hinge **L** has been pushed fully onto the hinge plate **K**, tighten screw **A**.

c: Attach the handle **M** to the door **3** using 2 screws **F**.



Warning:
Glass! Handle with care



Note: This shows the door being fitted to the right side. You may have chosen to fit it to the left side.

Assembly Instructions

Step 21

Adjust the door if needed

a: Before adjusting the door, use a spirit level to check the top (or base) of the unit is level, front-to-back and side-to-side in the 2 positions shown. Use suitable packing pieces (not supplied) to make the unit level BEFORE making any adjustment to the hinges, as shown.

b: Height adjustment.


Loosen screws A on hinge plates and move door up or down as required. Retighten screw A.

c: Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required. Retighten screw B.

d: Sideways adjustment.

To move door 'out' loosen screw C. To move door 'in' tighten screw C.



Assembly Instructions

Step 22

Fit the bracket

To prevent possible overbalancing, we recommend that this unit is secured to a suitable wall by use of the bracket **J** fitted to the top of the unit.

Fixings are not supplied, as they will need to suit the wall type and the length of screw will depend on the distance from the back of the unit to the wall.

Fix the bracket **J** loosely onto the top of the unit using screw **G** and mark the wall for the wall fixing.

Swivel the bracket **J** away from the wall and drill a hole in the wall using a suitable drill bit and fit your wall fixing.


Swivel the bracket **J** back and fix the bracket to the wall, then tighten screw **G**.

Note: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.





Warning: The unit is heavy. Lift with care.

Assembly is complete



Note: The bracket can be fitted on either side. This shows it being fitted to the left hand side.



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW