


OI WOW Eclipse Tall Cabinet

Assembly Instructions – Please keep for future reference

166/6890



Dimensions

Width - 35cm

Depth - 30cm

Height - 170cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800



Safety and care advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the panels, this could cause damage.
- Assemble the unit as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor.
- **Note:** Only apply the glue once you are sure of the assembly.
- The wall plugs supplied are suitable for solid walls only. It is important that the correct type of fixing is used for your wall, seek professional advice if in doubt.
- Parts of the assembly will be easier with 2 people.
- If using power tools, please follow the safety instructions supplied with the tools.



- We do not recommend the use of power drill/ drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.
- **Warning:** Before drilling, check the wall for hidden pipes and cables.
- Dispose of all packaging carefully and responsibly.

Glue safety - Take care when using glue, please follow the advice below

Skin contact: Remove contamination by washing with soap and water. This procedure should also be followed prior to eating and drinking.

Eye contact: Rinse immediately with clean water for 15 minutes and seek medical advice.

If swallowed: Seek medical advice immediately. If possible show product information or label to the medical advisor.

Care and maintenance


- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: if required the next page can be cut out and used as a reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components,
call the Customer Helpline:08456 400800


Please check you have all the panels listed below




1 Upper left side panel



2 Upper right side panel




3 Upper back panel




4 Under left side panel




5 Under right side panel




6 Under back panel




7 Top panel




8 Bottom panel




9 Shelf x 3



10 Drawer front




11 Left drawer side




12 Right drawer side




13 Drawer back




14 Drawer bottom



15 Door panel



16 Adjustable shelf

















17 Corner piece x 4

Components - Fittings

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

 <p>A Φ4 x 12mm Screw x 35</p>	 <p>B Locking Pin x 32</p>	 <p>C Ø15 X 10 mm Locking Nut x 40</p>
 <p>D Hanger Bracket x 1</p>	 <p>E Φ3 x 12mm Screw x 14</p>	 <p>F Metal Support x 4</p>
 <p>G Straight hinge x 2</p>	 <p>H 8mm Bolt x 2</p>	 <p>I Runner x 2</p>
 <p>J 30mm Screw x 5</p>	 <p>K Wall plug (for solid walls only) x 1</p>	 <p>L Pin x 4</p>
 <p>M Screw Cap x 24</p>	 <p>N Metal leg x 4</p>	

Tools required



Ruler – Use this ruler to help correctly identify the screws




Assembly Instructions

NOTE: 2 people assembly required.
This assembly will take about 1.5 hours more or less depending on your skills.


Step 1

Assembling under side panel


a:
Screw locking pins **B** into corner pieces **17** as shown.



b:
Loosen straight hinge screw as shown to separate it into **G1** & **G2**.



c:
Use $\Phi 4 \times 12$ mm screws **A** to fix straight hinge **G1** onto door panel **15**.



Continued on next page

Assembly Instructions

Step 1 - continued

Assembling under side panel

d:
Screw pins **L** into under side panel **4** **5** and make sure shorter part facing down, insert locking nuts **C** into it, tighten locking nuts to secure.

Insert locking pins **B** into under side panels.




Attach corner pieces **17** to under side panels **4** **5**, insert locking nuts **C** into it, tighten locking nuts to secure.

Use $\Phi 4 \times 12\text{mm}$ screw **A** to attach straight hinge **G2** onto under left side panel.

Stretch runner **I** as shown, use 2 pcs screw **A** to fix it on side panel, then stretch runner in opposite direction, use 1 pc screw to fix.

d:

Slide part



Assembly Instructions

Step 2

Assembling legs


a:
Unlock metal leg **(N)** by using screw driver as shown.

b:
Use $\Phi 4 \times 12\text{mm}$ screw **(A)** to fix leg plate **(N1)** on bottom panel **(8)**.

c:
Screw bolt **(N2)** on the leg plate **(N1)** by hand.

Note:
Not use screwdriver to tighten for this step, to avoid overtighten.


d:
Screw the leg body **(N3)** clockwise to lock.



Step 3

Assembling under unit

Carefully attach side panels **(4)** **(5)** to bottom panel **(8)** and middle shelf **(9)**, insert locking nuts **(C)** into it, tighten locking nuts to secure the unit.



Assembly Instructions


Step 4

Assembling upper unit

a:
Attach corner pieces to upper side panel **1** **2** and insert locking nuts **C** into it, tighten locking nuts to secure.



Screw locking pins **B** into upper side panels.

a:



b:
Carefully attach upper side panels **1** **2** to top panel **7** and shelves **9** as shown, insert locking nuts **C** into it, tighten locking nuts clockwise to secure.

b:




Assembly Instructions

Step 5

Assembling the unit

Attach upper unit to under unit as shown, insert locking nuts **C** into upper side panel **1** **2** and tighten it clockwise to secure.




Step 6

Assembling back panel

Use $\Phi 3$ x 12mm screw **E** to fix back panel **3** and **6** to the unit, please make sure the hole on upper back panel **3** match top panel.

Use $\Phi 4$ x 12mm screw **A** to fix hanger bracket **D** on top panel **7**.




Assembly Instructions

Step 7

Assembling door panel

Attach door panel **15** to the unit by fixing **G1** onto **G2** as shown, adjust the door left or right, up or down, in or out if needed.




Step 8

Assembling drawer

a:
Use 30mm screw **J** to fix drawer side panel **11** **12** onto drawer back panel **13**.

b:
Carefully slide bottom panel **14** into grooves.



Assembly Instructions

Step 9


Assembling drawer

a:
Pull out the runner, alignment to the groove on the drawer, then insert the drawer to close first.


b:
Carefully pull drawer out.

c:
Screw bolt **H** into holes as shown, try if drawer stopper function well.


a:



b:



c:



Assembly Instructions

Step 10

Fixing to the wall

Warning!

Please make sure the unit is secured to the wall before use.

Please refer to next page the Guide for Wall Mounting & Fixings.

a:

Use screw cap **M** to cover screws as shown.


Insert metal support **F** into side panels, carefully put shelf **16** on it.

b:


Use screw **J** and wall plug **K** to fix the unit on the wall via wall bracket **D**.

After above assembly, please double check and make sure all screws are tightened before us.

a:



b:



NOTE: If you have damaged or missing components, call the Customer Helpline: 08456 400800
Argos LTD, 489-499 Avebury Boulevard,
Central Milton Keynes, MK9 2NW

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.


Failure of the product due to using incorrect fixings is the responsibility of the installer.



Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


Hints:

- 1: General rule:**  Always use a larger screw and wall plug if you are not sure.
- 2:** Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3:** Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4:** Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5:** Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.