


# Newport - Chest Pack

Assembly Instructions - Please keep for future reference

245/8409

249/3842



## 2 Drawer Chest Dimensions

Width - 65.5cm

Depth - 35.5cm

Height - 57.5cm

## Bedside Chest Dimensions

Width - 35.5cm

Depth - 35.5cm

Height - 41cm



**MADE IN  
BRITAIN**

**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



# Safety and Care Advice

**Important** - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 22.5kgs. Please lift with care.
  - Check you have all the components and tools listed on pages 2 and 3.
  - Remove all fittings from the plastic bags and separate them into their groups.
  - Keep children and animals away from the work area, small parts could choke if swallowed.
  - Parts of the assembly will be easier with 2 people.
  - Make sure you have enough space to layout the parts before starting.
  - Do not stand or put weight on the product, this could cause damage.
  - Assemble the item as close to its final position (in the same room) as possible.
  - Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).
- 
- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.
  - **Safety note:** It is recommended that the 2 Drawer Chest is secured to a wall using the bracket supplied.
  - Dispose of all packaging carefully and responsibly.

## Care and maintenance


- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the panels listed below


### Drawer Panels



**1** Left Drawer Side (W320-124LH)  
(320 x 124mm) x 3



**2** Right Drawer Side (W320-124RH)  
(320 x 124mm) x 3



**3** Small Drawer Front (DF276)  
(315 x 162mm)



**4** Large Drawer Front (DF282)  
(615 x 162mm) x 2



**5** Small Drawer Back (W286-124)  
(286 x 124mm)



**6** Large Drawer Back (W586-124)  
(586 x 124mm) x 2



**7** Small Drawer Base (T297-317)  
(297 x 317mm)




**8** Large Drawer Base (T597-317)  
(597 x 317mm) x 2

# Components - Panels


If you have damaged or missing components, call the  
**Customer Helpline: 08456 400800** quoting the reference  
numbers below

Please check you have all the panels listed below


## Bedside Chest Panels




**9** Left End (DF272)  
(395 x 351mm)




**10** Right End (DF273)  
(395 x 351mm)




**11** Top (DF274)  
(355 x 352mm)



**12** Fixed Shelf (DF275)  
(319 x 325mm)




**13** Plinth (DF278)  
(319 x 65mm)




**14** Back (X345-182)  
(345 x 182mm)

## 2 Drawer Chest Panels




**15** Left End (DF420)  
(560 x 351mm)



**16** Right End (DF421)  
(560 x 351mm)




**17** Top (DF281)  
(655 x 352mm)



**18** Plinth (DF284)  
(619 x 65mm) x 2



**19** Fixed Shelf (DF422)  
(619 x 325mm)



**20** Back (X645-532)  
(645 x 532mm)














# Components - Fittings


If you have damaged or missing components, call the  
**Customer Helpline: 08456 400800** quoting the reference  
numbers below

Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<div><div>A</div><div></div></div> <div>Wooden dowel (F22) x 6</div>	<div><div>B</div><div></div></div> <div>Metal dowel (F901) x 28</div>	<div><div>C</div><div></div></div> <div>Small locking nut (F3) x 6</div>
<div><div>D</div><div></div></div> <div>Large locking nut (F900) x 22</div>	<div><div>E</div><div></div></div> <div>25mm Screw (F50) x 10</div>	<div><div>F</div><div></div></div> <div>Handle (F314) x 5</div>
<div><div>G</div><div></div></div> <div>Nail (F51) x 22</div>	<div><div>H</div><div></div></div> <div>Plastic Nail (F91) x 8</div>	<div><div>I</div><div></div></div> <div>Knock-in Peg (F171GY) x 12</div>
<div><div>J</div><div></div></div> <div>Wedgefix (F639) x 10</div>		
<div><div><div>K</div><div></div></div><div>Drawer stops (F599) x 6 Runners (F600) x 3 and (F601) x 3</div></div>		

## Tools required



Rule



Cross-head screwdriver



Scissors



Hammer




Eye protection  
(when using a hammer or drill)



Electric drill  
(do not use for fitting screws)

Ruler - Use this ruler to help correctly identify the screws





# Assembly Instructions


If you have damaged or missing components, call the  
**Customer Helpline: 08456 400800** quoting the reference  
numbers below

## Step 1

### Prepare the small drawer front

Screw 2 metal dowels **B** into the small drawer front **3**.

**Note:** Tighten the metal dowels up fully against the panels.




## Steps 1-20 will show you how to build the Bedside Chest

## Step 2

### Prepare 1 pair of drawer sides

Insert a small locking nut **C** into the hole shown on the left drawer side **1** and the right drawer side **2**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.




## Step 3

### Attach the drawer sides to the small drawer front

Push the left drawer sides **1** and right drawer sides **2** onto the back of the small drawer front **3**.

Turn the small locking nuts **C** on the left drawer side **1** and right drawer side **2**.

**Note:** Turn the locking nuts **C** clockwise to secure panels - more than 1/2 a turn.




# Assembly Instructions

## Step 4

### Fit the small drawer base

Slide the small drawer base **7** down the grooves in the drawer sides **1** and **2** and down into the groove in the small drawer front **3**.




## Step 5

### Fit the small drawer back

Fit the small drawer back **5** between the drawer sides **1** and **2**. Make sure that the small drawer base **7** fits into the groove in the small drawer back **5**.

Hold the small drawer back **5** in position and tap the knock-in pegs **1** through the holes in the drawer sides **1** and **2**.




## Step 6

### Push in drawer stops

Carefully break off 2 drawer stops (F599) from a pair of the drawer runners **K**.

Push the drawer stops fully through the drawer sides **1** and **2** from the inside.




# Assembly Instructions

## Step 7

### Attach the handle

Attach a handle **F** to the small drawer front **3** using screw **E**.



**Note: Do not overtighten the screws.**



## Step 8

### Fit the wedgfixes

Turn the drawer assemblies over and slide 2 wedgfixes **J** into the front and back grooves, as shown, and tighten up the screws.



## Step 9

### Prepare the right end

Separate the runners **K**.



Push fit a right runner **K** marked 'R' into the holes shown on the right end **10**.

**Note:** Runners must be fitted flat against the panel. If necessary gently tap into final position.

Screw 3 metal dowels **B** into the right end **10**.

Insert 2 large locking nuts **D** into the right end **10**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.




# Assembly Instructions

## Step 10

### Prepare the fixed shelf

Insert 4 large locking nuts **D** into the fixed shelf **12**.





## Step 11

### Fit the fixed shelf to the right end

Push the fixed shelf **12** onto the right end **10**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the fixed shelf **12**.

**Note:** Turn the large locking nuts **D** as far as they will go - more than 1/2 a turn.





## Step 12

### Prepare the plinth

Tap 2 wooden dowels **A** into the plinth **13**.

**Note:** Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.

Insert 2 large locking nuts **D** into the plinth **13**.




# Assembly Instructions

## Step 13

### Fit the plinth

Push the plinth **13** onto the right end **10**.

Use a screwdriver to tighten the large locking nut **D** fitted to the plinth **13**.





## Step 14

### Prepare the left end

Push fit a left runner **K** marked 'L' into the holes shown on the left end **9**.

Screw 3 metal dowels **B** into the left end **9**.

Insert 2 large locking nuts **D** into the left end **9**.




## Step 15

### Fit the left end

Push the left end **9** onto the assembly.

Use a screwdriver to tighten the 3 large locking nuts **D** fitted to the fixed shelf **12** and the plinth **13**.




# Assembly Instructions

## Step 16

### Prepare the top

Screw 2 metal dowels **B** into the top **11**.




## Step 17

### Fit the top

Push the top **11** onto the assembly.


Use a screwdriver to tighten the 4 large locking nuts **D** fitted to the left end **9** and right end **10**.



## Step 18

### Fit the 4 plastic nails

Tap 2 plastic nails **H** into the bottom edge of each of the ends **9** and **10**.



# Assembly Instructions

## Step 19

### Fit the back

**a:** Square up the unit by making sure that measurement **x** to **x** equals **y** to **y**.


**b:** Place the back **14** onto the unit.

Nail **G** around the outside edges of the back **14**.

**Note:** Nails should be spaced about 150mm apart.

**Stand the unit up for the next step.**

**a:** The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




## Step 20

### Insert the drawer

Lift the front of the drawer whilst inserting to overcome the 'stop' system.

**Note:** To ensure that your drawer runs smoothly, spray a small amount of furniture polish into the grooves.

**The bedside chest assembly is complete**




# Assembly Instructions

## Step 21

### Prepare the 2 large drawer fronts

Screw 2 metal dowels **B** into each large drawer front **4**.

**Note:** Tighten the metal dowels up fully against the panels.




Steps 21-41 will show you how to build the 2 Drawer Chest

## Step 22

### Prepare 2 pairs of drawer sides

Insert a small locking nut **C** into the hole shown on the left drawer side **1** and the right drawer side **2**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.




## Step 23

### Attach the drawer sides to the large drawer fronts

Push the left drawer sides **1** and right drawer sides **2** onto the back of the large drawer fronts **4**.

Turn the small locking nuts **C** on the left drawer side **1** and right drawer side **2**.

**Note:** Turn the locking nuts **C** clockwise to secure panels - more than 1/2 a turn.






# Assembly Instructions

## Step 24

### Fit the large drawer base

Slide the large drawer base **8** down the grooves in the drawer sides **1** and **2** and down into the groove in the large drawer front **4**.




## Step 25

### Fit the large drawer back

Fit the large drawer back **6** between the drawer sides **1** and **2**. Make sure that the large drawer base **8** fits into the groove in the large drawer back **6**.

Hold the large drawer back **6** in position and tap the knock-in pegs **1** through the holes in the drawer sides **1** and **2**.




## Step 26

### Push in drawer stops

Carefully break off the 2 drawer stops (F599) from each pair of the drawer runners **K**.

Push the drawer stops fully through the drawer sides **1** and **2** from the inside.




# Assembly Instructions

## Step 27

### Attach the handles

Attach 2 handles **F** to each large drawer front **4** using screws **E**.

**Note: Do not overtighten the screws.**




x 2

## Step 28

### Fit the wedgfixes

Turn the drawer assemblies over and slide 2 wedgfixes **J** into the front and back grooves, as shown, and tighten up the screws.



x 2

## Step 29



### Prepare the right end

Separate the runners **K**.

Push fit 2 right runners **K** marked 'R' into the holes shown on the right end **16**.

Screw 4 metal dowels **B** into the right end **16**.

Insert 2 large locking nuts **D** into the right end **16**.




# Assembly Instructions

## Step 30

### Prepare the fixed shelf

Insert 4 large locking nuts **D** into the fixed shelf **19**.




## Step 31

### Fit the fixed shelf to the right end

Push the fixed shelf **19** onto the right end **16**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the fixed shelf **19**.





## Step 32

### Prepare the left end

Push fit 2 left runners **K** marked 'L' into the holes shown on the left end **15**.

Screw 4 metal dowels **B** into the left end **15**.

Insert 2 large locking nuts **D** into the left end **15**.




# Assembly Instructions

## Step 33

### Prepare the 2 plinths

Tap 2 wooden dowels **A** into each plinth **18**.

Insert 2 large locking nuts **D** into each plinth **18**.




## Step 34

### Fit the 2 plinths

Push the 2 plinths **18** onto the right end **16**.

Use a screwdriver to tighten the large locking nut **D** fitted to each of the plinths **18**.




## Step 35

### Fit the left end

Push the left end **15** onto the assembly.

Use a screwdriver to tighten the 4 large locking nuts **D** fitted to the fixed shelf **19** and the 2 plinths **18**.




# Assembly Instructions

## Step 36

### Prepare the top

Screw 4 metal dowels **B** into the top **17**.




## Step 37

### Fit the top

Push the top **17** onto the assembly.


Use a screwdriver to tighten the 4 large locking nuts **D** fitted to the left end **15** and right end **16**.



## Step 38

### Fit the 4 plastic nails

Tap 2 plastic nails **H** into the bottom edge of each of the ends **15** and **16**.



# Assembly Instructions

## Step 39

### Fit the back

**a:** Square up the unit by making sure that measurement **x to x** equals **y to y**.

**b:** Place the back **[20]** onto the unit.

Nail **G** around the outside edges of the back **[20]**.


**Note:** Nails should be spaced about 150mm apart.

**Stand the unit up for the next step.**



**Warning:** The unit is heavy. Lift with care.

**a:** The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




## Step 40

### Insert the drawers

Lift the front of the drawers whilst inserting to overcome the 'stop' system.

**Note:** To ensure that your drawers run smoothly, spray a small amount of furniture polish into the grooves.

**The chest assembly is complete**



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW








# Newport - Chest Pack

Assembly Instructions - Please keep for future reference

245/8409

249/3842

418/3497



## 2 Drawer Chest Dimensions

Width - 65.5cm

Depth - 35.5cm

Height - 57.5cm

## Bedside Chest Dimensions

Width - 35.5cm

Depth - 35.5cm

Height - 41cm



**MADE IN  
BRITAIN**

**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**



# Safety and Care Advice

**Important** - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 22.5kgs. Please lift with care.
- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Parts of the assembly will be easier with 2 people.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



• We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

• **Safety note:** It is recommended that the 2 Drawer Chest is secured to a wall using the bracket supplied.

• Dispose of all packaging carefully and responsibly.

## Care and maintenance


- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the panels listed below


### Drawer Panels



**1** Left Drawer Side (W320-124LH)  
(320 x 124mm) x 3



**2** Right Drawer Side (W320-124RH)  
(320 x 124mm) x 3



**3** Small Drawer Front (DF276B)  
(315 x 162mm)



**4** Large Drawer Front (DF282B)  
(615 x 162mm) x 2



**5** Small Drawer Back (W286-124)  
(286 x 124mm)



**6** Large Drawer Back (W586-124)  
(586 x 124mm) x 2



**7** Small Drawer Base (T297-317)  
(297 x 317mm)




**8** Large Drawer Base (T597-317)  
(597 x 317mm) x 2

# Components - Panels


If you have damaged or missing components, call the  
**Customer Helpline: 03456 400800** quoting the reference  
numbers below

Please check you have all the panels listed below


## Bedside Chest Panels




**9** Left End (DF272)  
(395 x 351mm)




**10** Right End (DF273)  
(395 x 351mm)




**11** Top (DF274)  
(355 x 352mm)



**12** Fixed Shelf (DF275)  
(319 x 325mm)




**13** Plinth (DF278)  
(319 x 65mm)




**14** Back (X345-182)  
(345 x 182mm)


## 2 Drawer Chest Panels




**15** Left End (DF420)  
(560 x 351mm)



**16** Right End (DF421)  
(560 x 351mm)




**17** Top (DF281)  
(655 x 352mm)



**18** Plinth (DF284)  
(619 x 65mm) x 2



**19** Fixed Shelf (DF422)  
(619 x 325mm)



**20** Back (X645-532)  
(645 x 532mm)














# Components - Fittings


If you have damaged or missing components, call the  
**Customer Helpline: 03456 400800** quoting the reference  
numbers below

Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<b>A</b>  Wooden dowel (F22) x 6	<b>B</b>  Metal dowel (F901) x 28	<b>C</b>  Small locking nut (F3) x 6
<b>D</b>  Large locking nut (F900) x 22	<b>E</b>  25mm Screw (F50) x 5	<b>F</b>  Handle (F314) x 5
<b>G</b>  Nail (F51) x 22	<b>H</b>  Plastic Nail (F91) x 8	<b>I</b>  Knock-in Peg (F171GY) x 12
<b>J</b>  Wedgex (F639) x 10	<b>K</b>  Drawer stops (F599) x 6 Runners (F600) x 3 and (F601) x 3	

## Tools required



Rule



Cross-head screwdriver



Scissors



Hammer




Eye protection  
(when using a hammer or drill)



Electric drill  
(do not use for fitting screws)

Ruler - Use this ruler to help correctly identify the screws



# Assembly Instructions


If you have damaged or missing components, call the  
**Customer Helpline: 03456 400800** quoting the reference  
numbers below

## Step 1

### Prepare the small drawer front

Screw 2 metal dowels **B** into the small drawer front **3**.

**Note:** Tighten the metal dowels up fully against the panels.




## Steps 1-20 will show you how to build the Bedside Chest

## Step 2

### Prepare 1 pair of drawer sides

Insert a small locking nut **C** into the hole shown on the left drawer side **1** and the right drawer side **2**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.




## Step 3

### Attach the drawer sides to the small drawer front

Push the left drawer sides **1** and right drawer sides **2** onto the back of the small drawer front **3**.

Turn the small locking nuts **C** on the left drawer side **1** and right drawer side **2**.

**Note:** Turn the locking nuts **C** clockwise to secure panels - more than 1/2 a turn.




# Assembly Instructions

## Step 4

### Fit the small drawer base

Slide the small drawer base **7** down the grooves in the drawer sides **1** and **2** and down into the groove in the small drawer front **3**.




## Step 5

### Fit the small drawer back

Fit the small drawer back **5** between the drawer sides **1** and **2**. Make sure that the small drawer base **7** fits into the groove in the small drawer back **5**.

Hold the small drawer back **5** in position and tap the knock-in pegs **1** through the holes in the drawer sides **1** and **2**.




## Step 6

### Push in drawer stops

Carefully break off 2 drawer stops (F599) from a pair of the drawer runners **K**.

Push the drawer stops fully through the drawer sides **1** and **2** from the inside.




# Assembly Instructions

## Step 7

### Attach the handle

Attach a handle **F** to the small drawer front **3** using screw **E**.



**Note:** Do not overtighten the screws.



## Step 8

### Fit the wedgefixes

Turn the drawer assemblies over and slide 2 wedgefixes **J** into the front and back grooves, as shown, and tighten up the screws.



## Step 9

### Prepare the right end

Separate the runners **K**.



Push fit a right runner **K** marked 'R' into the holes shown on the right end **10**.

**Note:** Runners must be fitted flat against the panel. If necessary gently tap into final position.

Screw 3 metal dowels **B** into the right end **10**.

Insert 2 large locking nuts **D** into the right end **10**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.




# Assembly Instructions

## Step 10

### Prepare the fixed shelf

Insert 4 large locking nuts **D** into the fixed shelf **12**.





## Step 11

### Fit the fixed shelf to the right end

Push the fixed shelf **12** onto the right end **10**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the fixed shelf **12**.

**Note:** Turn the large locking nuts **D** as far as they will go - more than 1/2 a turn.





## Step 12

### Prepare the plinth

Tap 2 wooden dowels **A** into the plinth **13**.

**Note:** Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.

Insert 2 large locking nuts **D** into the plinth **13**.






# Assembly Instructions

## Step 13

### Fit the plinth

Push the plinth **13** onto the right end **10**.

Use a screwdriver to tighten the large locking nut **D** fitted to the plinth **13**.





## Step 14

### Prepare the left end

Push fit a left runner **K** marked 'L' into the holes shown on the left end **9**.

Screw 3 metal dowels **B** into the left end **9**.

Insert 2 large locking nuts **D** into the left end **9**.




## Step 15

### Fit the left end

Push the left end **9** onto the assembly.

Use a screwdriver to tighten the 3 large locking nuts **D** fitted to the fixed shelf **12** and the plinth **13**.




# Assembly Instructions

## Step 16

### Prepare the top

Screw 4 metal dowels **B** into the top **11**.




## Step 17

### Fit the top

Push the top **11** onto the assembly.


Use a screwdriver to tighten the 4 large locking nuts **D** fitted to the left end **9** and right end **10**.



## Step 18

### Fit the 4 plastic nails

Tap 2 plastic nails **H** into the bottom edge of each of the ends **9** and **10**.



# Assembly Instructions

## Step 19

### Fit the back

**a:** Square up the unit by making sure that measurement **x** to **x** equals **y** to **y**.


**b:** Place the back **14** onto the unit.

Nail **G** around the outside edges of the back **14**.

**Note:** Nails should be spaced about 150mm apart.

**Stand the unit up for the next step.**

**a:** The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




## Step 20

### Insert the drawer

Lift the front of the drawer whilst inserting to overcome the 'stop' system.

**Note:** To ensure that your drawer runs smoothly, spray a small amount of furniture polish into the grooves.

**The bedside chest assembly is complete**




# Assembly Instructions

## Step 21

### Prepare the 2 large drawer fronts

Screw 2 metal dowels **B** into each large drawer front **4**.

**Note:** Tighten the metal dowels up fully against the panels.




Steps 21-41 will show you how to build the 2 Drawer Chest

## Step 22

### Prepare 2 pairs of drawer sides

Insert a small locking nut **C** into the hole shown on the left drawer side **1** and the right drawer side **2**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.





## Step 23

### Attach the drawer sides to the large drawer fronts

Push the left drawer sides **1** and right drawer sides **2** onto the back of the large drawer fronts **4**.

Turn the small locking nuts **C** on the left drawer side **1** and right drawer side **2**.

**Note:** Turn the locking nuts **C** clockwise to secure panels - more than 1/2 a turn.




# Assembly Instructions

## Step 24

### Fit the large drawer base

Slide the large drawer base **8** down the grooves in the drawer sides **1** and **2** and down into the groove in the large drawer front **4**.




## Step 25

### Fit the large drawer back

Fit the large drawer back **6** between the drawer sides **1** and **2**. Make sure that the large drawer base **8** fits into the groove in the large drawer back **6**.

Hold the large drawer back **6** in position and tap the knock-in pegs **1** through the holes in the drawer sides **1** and **2**.




## Step 26

### Push in drawer stops

Carefully break off the 2 drawer stops (F599) from each pair of the drawer runners **K**.

Push the drawer stops fully through the drawer sides **1** and **2** from the inside.




# Assembly Instructions

## Step 27

### Attach the handles

Attach 2 handles **F** to each large drawer front **4** using screws **E**.

**Note: Do not overtighten the screws.**




x 2

## Step 28

### Fit the wedgfixes

Turn the drawer assemblies over and slide 2 wedgfixes **J** into the front and back grooves, as shown, and tighten up the screws.



x 2

## Step 29



### Prepare the right end

Separate the runners **K**.

Push fit 2 right runners **K** marked 'R' into the holes shown on the right end **16**.

Screw 4 metal dowels **B** into the right end **16**.

Insert 2 large locking nuts **D** into the right end **16**.




# Assembly Instructions

## Step 30

### Prepare the fixed shelf

Insert 4 large locking nuts **D** into the fixed shelf **19**.




## Step 31

### Fit the fixed shelf to the right end

Push the fixed shelf **19** onto the right end **16**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the fixed shelf **19**.





## Step 32

### Prepare the left end

Push fit 2 left runners **K** marked 'L' into the holes shown on the left end **15**.

Screw 4 metal dowels **B** into the left end **15**.

Insert 2 large locking nuts **D** into the left end **15**.




# Assembly Instructions

## Step 33

### Prepare the 2 plinths

Tap 2 wooden dowels **A** into each plinth **18**.

Insert 2 large locking nuts **D** into each plinth **18**.




## Step 34

### Fit the 2 plinths

Push the 2 plinths **18** onto the right end **16**.

Use a screwdriver to tighten the large locking nut **D** fitted to each of the plinths **18**.




## Step 35

### Fit the left end

Push the left end **15** onto the assembly.

Use a screwdriver to tighten the 4 large locking nuts **D** fitted to the fixed shelf **19** and the 2 plinths **18**.






# Assembly Instructions

## Step 36

### Prepare the top

Screw 4 metal dowels **B** into the top **17**.




## Step 37

### Fit the top

Push the top **17** onto the assembly.


Use a screwdriver to tighten the 4 large locking nuts **D** fitted to the left end **15** and right end **16**.



## Step 38

### Fit the 4 plastic nails

Tap 2 plastic nails **H** into the bottom edge of each of the ends **15** and **16**.



# Assembly Instructions

## Step 39

### Fit the back

**a:** Square up the unit by making sure that measurement **x to x** equals **y to y**.

**b:** Place the back **[20]** onto the unit.

Nail **G** around the outside edges of the back **[20]**.


**Note:** Nails should be spaced about 150mm apart.

**Stand the unit up for the next step.**



**Warning:** The unit is heavy. Lift with care.

**a:** The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




## Step 40

### Insert the drawers

Lift the front of the drawers whilst inserting to overcome the 'stop' system.

**Note:** To ensure that your drawers run smoothly, spray a small amount of furniture polish into the grooves.

**The chest assembly is complete**



If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW



