

Malibu - Cabin Bed

Assembly Instructions - Please keep for future reference

268/5038

275/4433


278/5433

275/7557

249/2032

280/3315

WARNING
NOT SUITABLE FOR CHILDREN
UNDER 4 YEARS OF AGE .



Dimensions

Width - 195cm

Depth - 95cm

Height - 53cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 66kgs. Please lift with care.
- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



• We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings (not supplied).
- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Tools required



Rule



Cross-head screwdriver



Scissors



Hammer



Eye protection (when using a hammer or drill)

IMPORTANT


On a regular basis please check that the screws and fittings have not become loose as this could present a potential choke hazard.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below


Please check you have all the panels listed below




1 Left End (D2931A)
(949 x 529mm)




2 Right End (D2936A)
(949 x 529mm)



4 Left Upright (D2937A)
(367 x 660mm)



5 Right Upright (D2929A)
(367 x 660mm)



7 Base (D2928A)
(1920 x 455.5mm) x 2



11 Front Rail (D2938A)
(1920 x 160mm)



12 Support Rail (D2939A)
(1920 x 92mm) x 2




13 Back Rail (D2926A)
(1920 x 160mm)




17 Drawer Back (W502-124)
(502 x 124mm) x 4



18 Drawer Base (T513-367)
(513 x 367mm) x 4




3 Horizontal (D2932A)
(820 x 287mm)



6 Back (D2927A)
(820 x 367mm)




8 Left Plinth (D2934A)
(535 x 60mm) x 2




9 Right Plinth (D2935A)
(535 x 60mm) x 2



10 Middle Plinth (D2933A)
(820 x 60mm)



14 Drawer front (D2930A)
(531 x 149mm) x 4



15 Left Drawer Side (W370-124LH)
(370 x 124mm) x 4



16 Right Drawer Side (W370-124RH)
(370 x 124mm) x 4



19 Shelf (D3030A)
(820 x 287mm)








Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 16</p>	<p>B </p> <p>Metal dowel (F901) x 10</p>	<p>C </p> <p>Knock-in Peg (F171GY) x 16</p>
<p>D </p> <p>Large wooden dowel (F40) x 2</p>	<p>E </p> <p>Large locking nut (F900) x 6</p>	<p>F </p> <p>Small locking nut (F3) x 8</p>
<p>G </p> <p>50mm Screw (F49) x 48</p>	<p>H </p> <p>45mm Screw (F65) x 10</p>	<p>I </p> <p>25mm Screw (F50) x 4</p>
<p>J </p> <p>13mm Screw (F79) x 5</p>	<p>K </p> <p>13mm Screw (F52) x 5</p>	<p>L </p> <p>9mm Screw (F73) x 16</p>
<p>M </p> <p>9mm Screw (F74) x 8</p>	<p>N </p> <p>Plastic Nail (F91) x 10</p>	<p>O </p> <p>Allen Key (F36) x 1</p>
<p>P </p> <p>Wedgefix (F639) x 8</p>	<p>Q </p> <p>Bracket (F327) x 5</p>	<p>R </p> <p>Handle (F631) x 4</p>
<p>S </p> <p>Drawer runner (F1004) x 8</p>		<p>T </p> <p>Double metal dowel (F566) x 2</p>
<p>U </p> <p>Shelf stud (F372) x 4</p>		

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Step 1

Prepare the 4 drawer fronts

Screw 2 metal dowels **B** into each of the 4 drawer fronts **14**.

Note: Tighten the metal dowels up fully against the panels.




Step 2

Prepare 4 pairs of drawer sides

Insert a small locking nut **F** into the hole shown on the left drawer side **15** and the right drawer side **16**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Step 3

Attach the drawer sides to the drawer fronts

Push the left drawer sides **15** and right drawer sides **16** onto the back of the 4 drawer fronts **14**.

Turn the small locking nuts **F** on the left drawer side **15** and right drawer side **16**.

Note: Turn the locking nuts **F** clockwise to secure panels - more than 1/2 a turn.




Assembly Instructions

Step 4

Fit the drawer base

Slide the drawer base **18** down the grooves in the drawer sides **15** and **16** and down into the groove in the drawer front **14**.




Step 5

Fit the drawer back

Fit the drawer back **17** between the drawer sides **15** and **16**. Make sure that the drawer base **18** fits into the groove in the drawer back **17**.

Hold the drawer back **17** in position and tap the knock-in pegs **C** through the holes in the drawer sides **15** and **16**.




Step 6

Attach the handles

Attach a handle **R** to each of the drawer fronts **14** using screw **I**.


Note: Do not overtighten the screw.



Step 7

Fit the wedgifixes

Turn the drawer assemblies over and slide 2 wedgifixes **P** into the front and back grooves, as shown, and tighten up the screws.



Assembly Instructions

Step 8




Prepare the left upright

a: Tap 2 wooden dowels **A** into the left upright **4**.

Screw a metal dowel **B** into the left upright **4**.

Place 2 runners **S** on the left upright **4** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

b: Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the left upright **4**.



Step 9




Prepare the right upright

a: Tap 2 wooden dowels **A** into the right upright **5**.

Screw a metal dowel **B** into the right upright **5**.

Place 2 runners **S** on the right upright **5** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

b: Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the right upright **5**.




Assembly Instructions

Step 10

Fit the horizontal to the right upright

Fit the horizontal **3** onto the right upright **5** using 2 screws **G** and the allen key **O**.




Step 11

Prepare the middle plinth

Insert 2 large locking nuts **E** into the middle plinth **10**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Step 12

Fit the middle plinth


a: Tap a double metal dowel **T** and a large wooden dowel **D** through the right upright **5** and into the middle plinth **10** until they "bottom out".

b: Use a screwdriver to tighten the large locking nut **E** fitted to the middle plinth **10**.

Note: Turn the large locking nuts **E** as far as they will go - more than 1/2 a turn.



Important: It is critical that the middle plinth is assembled with the large locking nuts at the top.




Assembly Instructions

Step 13

Prepare the back


Tap 2 wooden dowels **A** into the back **6**.



Step 14

Fit the back


Push the back **6** onto the right upright **5** and fix it using 2 screws **G** and the allen key **O**.



Step 15

Fit the left upright

Push the left upright **4** onto the assembly and fix it using 4 screws **G** and the allen key **O**.




Assembly Instructions

Step 16

Secure the middle plinth to the left upright

a: Tap a double metal dowel **T** and a large wooden dowel **D** through the left upright **4** and into the middle plinth **10** until they "bottom out".

b: Use a screwdriver to tighten the large locking nut **E** fitted to the middle plinth **10**.




Step 17

Fit the 4 plastic nails

Tap 2 plastic nails **N** into the bottom edge of each of the uprights **4** and **5**.

Carefully stand the assembly up.




Step 18

Prepare the 2 left plinths

Tap a wooden dowel **A** into just 1 of the 2 left plinths **8**.

Insert a large locking nut **E** into each of the 2 left plinths **8**.




Assembly Instructions

Step 19

Fit the left plinths to the left upright

Push the left plinths **8** onto the left upright **4**.

Use a screwdriver to tighten the large locking nuts **E** fitted to the left plinths **8**.




Step 20

Prepare the 2 right plinths

Tap a wooden dowel **A** into just 1 of the 2 right plinths **9**.

Insert a large locking nut **E** into each of the 2 right plinths **9**.




Step 21

Fit the right plinths to the right upright

Push the right plinths **9** onto the right upright **5**.

Use a screwdriver to tighten the large locking nuts **E** fitted to the right plinths **9**.




Assembly Instructions

Step 22

Prepare the 2 bases


Tap 2 wooden dowels **A** into each of the 2 bases **7**.



Step 23

Fit a base

Fit a base **7** down onto the 2 uprights **4** and **5** using 4 screws **G** and the allen key **O**.




Assembly Instructions

Step 24

Fit the other base

2 people are needed to assemble this part

Fit the other base **7** down onto the 2 uprights **4** and **5** using 4 screws **G** and the allen key **O**.






Step 25

Prepare the right end

a: Place 2 runners **S** on the right end **2** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

b: Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the right end **2**.

Tap 3 plastic nails **N** into the bottom edge of each of the right end **2**.



Assembly Instructions




Step 26

Prepare the left end

a: Place 2 runners **S** on the left end **1** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

b: Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the left end **1**.


Tap 3 plastic nails **N** into the bottom edge of each of the left end **1**.



Step 27

Fit the left end

Fit the left end **1** onto the assembly using 8 screws **G** and the allen key **O**.




Assembly Instructions

Step 28

Fit the 2 support rails

Fit the 2 support rails **12** to the left end **1** using 2 screws **G** for each rail and the allen key **O**.

Note: Use 2 people for this step and support the 2 support rails until the right end has been fitted.




Step 29

Prepare the front rail and back rail

Tap 2 wooden dowels **A** into the front rail **11**.

Tap 2 wooden dowels **A** into the back rail **13**.



Assembly Instructions


Step 30

Fit the front rail and back rail

Fit the front rail **11** to the left end **1** using 2 screws **G** and the allen key **O**.

Fit the back rail **13** to the left end **1** using 2 screws **G** and the allen key **O**.

Note: Support the front and back rail until the right end has been fitted.




Assembly Instructions

Step 31

Fit the right end


Fit the right end **2** onto the assembly using 16 screws **G** and the allen key **O**.



Step 32

Secure the rear support rail

Screw through the 5 holes in the base **7** and into the top edge of the support rail **12** using 5 screws **H**.




Important: Make sure that the screws go into the centre of the top edge of the support rail.

Assembly Instructions

Step 33

Secure the back rail


Fix the back rail **13** to the back edge of the base **7** using 5 screws **H**.



Step 34

Secure the front rail

Loosely fix the 5 brackets **Q** to the holes in the base **7** using screws **K**.



Slide the brackets up against the mark holes in the front rail **11** and fix them using screws **J**.

Tighten up the screws **K**.

Assembly Instructions



Step 35

Fit the drawers

Starting with the bottom drawers, slide both the runners **S** forward and locate the drawer sides **15** and **16** between them, lining up the holes in the drawer wrap with the 2nd 'threaded' holes in the runners **S**.

Working from the inside of the drawer, insert 2 screws **M** through the drawer sides and out into the 2nd threaded hole in the runner.

Note: Do not overtighten the screws.
If they catch on the runner you may need to loosen them slightly.




Assembly Instructions

Step 36

Fit the shelf studs

Insert 4 shelf studs **U** at the required height into the uprights **4** and **5**.


Note: The fitting of the shelf is optional so please ignore steps 36 and 37 if it is not required.



Step 37

Fit the shelf

Lower the shelf **19** down onto the shelf studs **U** and tighten their screws.



IMPORTANT

On a regular basis please check that the screws and fittings have not become loose as this could present a potential choke hazard.

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800 and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

Malibu - Cabin Bed

Assembly Instructions - Please keep for future reference

268/5038

275/4433


278/5433

275/7557

249/2032

280/3315

WARNING
NOT SUITABLE FOR CHILDREN
UNDER 4 YEARS OF AGE .



Dimensions

Width - 195cm

Depth - 95cm

Height - 53cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 66kgs. Please lift with care.
- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



• We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings (not supplied).
- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Tools required



Rule



Cross-head screwdriver



Scissors



Hammer



Eye protection
(when using a hammer or drill)

IMPORTANT


On a regular basis please check that the screws and fittings have not become loose as this could present a potential choke hazard.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below


Please check you have all the panels listed below




1 Left End (D2931B)
(949 x 529mm)




2 Right End (D2936B)
(949 x 529mm)



4 Left Upright (D2937B)
(367 x 660mm)



5 Right Upright (D2929B)
(367 x 660mm)



7 Base (D2928A)
(1920 x 455.5mm) x 2




11 Front Rail (D2938A)
(1920 x 160mm)




12 Support Rail (D2939A)
(1920 x 92mm) x 2



13 Back Rail (D2926A)
(1920 x 160mm)




17 Drawer Back (W502-124)
(502 x 124mm) x 4



18 Drawer Base (T513-367)
(513 x 367mm) x 4




3 Horizontal (D2932A)
(820 x 287mm)



6 Back (D2927A)
(820 x 367mm)




8 Left Plinth (D2934A)
(535 x 60mm) x 2




9 Right Plinth (D2935A)
(535 x 60mm) x 2



10 Middle Plinth (D2933A)
(820 x 60mm)



14 Drawer Front (D2930B)
(531 x 157mm) x 4



15 Left Drawer Side (W370-124LH)
(370 x 124mm) x 4



16 Right Drawer Side (W370-124RH)
(370 x 124mm) x 4



19 Shelf (D3030A)
(820 x 287mm)








Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 16</p>	<p>B </p> <p>Metal dowel (F901) x 10</p>	<p>C </p> <p>Knock-in Peg (F171GY) x 16</p>
<p>D </p> <p>Large wooden dowel (F40) x 2</p>	<p>E </p> <p>Large locking nut (F900) x 6</p>	<p>F </p> <p>Small locking nut (F3) x 8</p>
<p>G </p> <p>50mm Screw (F49) x 48</p>	<p>H </p> <p>45mm Screw (F65) x 10</p>	<p>I </p> <p>25mm Screw (F50) x 4</p>
<p>J </p> <p>13mm Screw (F79) x 5</p>	<p>K </p> <p>13mm Screw (F52) x 5</p>	<p>L </p> <p>9mm Screw (F73) x 16</p>
<p>M </p> <p>9mm Screw (F74) x 8</p>	<p>N </p> <p>Plastic Nail (F91) x 10</p>	<p>O </p> <p>Allen Key (F36) x 1</p>
<p>P </p> <p>Wedgefix (F639) x 8</p>	<p>Q </p> <p>Bracket (F327) x 5</p>	<p>R </p> <p>Handle (F631) x 4</p>
<p>S </p> <p>Drawer runner (F1004) x 8</p>		<p>T </p> <p>Double metal dowel (F566) x 2</p>
<p>U </p> <p>Shelf stud (F372) x 4</p>		

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Step 1

Prepare the 4 drawer fronts

Screw 2 metal dowels **B** into each of the 4 drawer fronts **14**.

Note: Tighten the metal dowels up fully against the panels.




Step 2

Prepare 4 pairs of drawer sides

Insert a small locking nut **F** into the hole shown on the left drawer side **15** and the right drawer side **16**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Step 3

Attach the drawer sides to the drawer fronts

Push the left drawer sides **15** and right drawer sides **16** onto the back of the 4 drawer fronts **14**.

Turn the small locking nuts **F** on the left drawer side **15** and right drawer side **16**.

Note: Turn the locking nuts **F** clockwise to secure panels - more than 1/2 a turn.




Assembly Instructions

Step 4

Fit the drawer base

Slide the drawer base **18** down the grooves in the drawer sides **15** and **16** and down into the groove in the drawer front **14**.




Step 5

Fit the drawer back

Fit the drawer back **17** between the drawer sides **15** and **16**. Make sure that the drawer base **18** fits into the groove in the drawer back **17**.

Hold the drawer back **17** in position and tap the knock-in pegs **C** through the holes in the drawer sides **15** and **16**.




Step 6

Attach the handles

Attach a handle **R** to each of the drawer fronts **14** using screw **I**.


Note: Do not overtighten the screw.



Step 7

Fit the wedgifixes

Turn the drawer assemblies over and slide 2 wedgifixes **P** into the front and back grooves, as shown, and tighten up the screws.



Assembly Instructions

Step 8




Prepare the left upright

a: Tap 2 wooden dowels **A** into the left upright **4**.

Screw a metal dowel **B** into the left upright **4**.

Place 2 runners **S** on the left upright **4** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

b: Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the left upright **4**.



Step 9




Prepare the right upright

a: Tap 2 wooden dowels **A** into the right upright **5**.

Screw a metal dowel **B** into the right upright **5**.

Place 2 runners **S** on the right upright **5** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

b: Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the right upright **5**.




Assembly Instructions

Step 10

Fit the horizontal to the right upright

Fit the horizontal **3** onto the right upright **5** using 2 screws **G** and the allen key **O**.




Step 11

Prepare the middle plinth

Insert 2 large locking nuts **E** into the middle plinth **10**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Step 12

Fit the middle plinth


a: Tap a double metal dowel **T** and a large wooden dowel **D** through the right upright **5** and into the middle plinth **10** until they "bottom out".

b: Use a screwdriver to tighten the large locking nut **E** fitted to the middle plinth **10**.

Note: Turn the large locking nuts **E** as far as they will go - more than 1/2 a turn.



Important: It is critical that the middle plinth is assembled with the large locking nuts at the top.




Assembly Instructions

Step 13

Prepare the back


Tap 2 wooden dowels **A** into the back **6**.



Step 14

Fit the back


Push the back **6** onto the right upright **5** and fix it using 2 screws **G** and the allen key **O**.



Step 15

Fit the left upright

Push the left upright **4** onto the assembly and fix it using 4 screws **G** and the allen key **O**.




Assembly Instructions

Step 19

Fit the left plinths to the left upright

Push the left plinths **8** onto the left upright **4**.

Use a screwdriver to tighten the large locking nuts **E** fitted to the left plinths **8**.




Step 20

Prepare the 2 right plinths

Tap a wooden dowel **A** into just 1 of the 2 right plinths **9**.

Insert a large locking nut **E** into each of the 2 right plinths **9**.




Step 21

Fit the right plinths to the right upright

Push the right plinths **9** onto the right upright **5**.

Use a screwdriver to tighten the large locking nuts **E** fitted to the right plinths **9**.




Assembly Instructions

Step 22

Prepare the 2 bases


Tap 2 wooden dowels **A** into each of the 2 bases **7**.



Step 23

Fit a base

Fit a base **7** down onto the 2 uprights **4** and **5** using 4 screws **G** and the allen key **O**.




Assembly Instructions

Step 24

Fit the other base

2 people are needed to assemble this part

Fit the other base **7** down onto the 2 uprights **4** and **5** using 4 screws **G** and the allen key **O**.



This is the back of the bed


Step 25

Prepare the right end


a: Place 2 runners **S** on the right end **2** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

b: Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the right end **2**.


Tap 3 plastic nails **N** into the bottom edge of each of the right end **2**.



a:



b:



Assembly Instructions




Step 26

Prepare the left end

a: Place 2 runners **S** on the left end **1** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

b: Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the left end **1**.


Tap 3 plastic nails **N** into the bottom edge of each of the left end **1**.



Step 27

Fit the left end

Fit the left end **1** onto the assembly using 8 screws **G** and the allen key **O**.




Assembly Instructions

Step 28

Fit the 2 support rails

Fit the 2 support rails **12** to the left end **1** using 2 screws **G** for each rail and the allen key **O**.

Note: Use 2 people for this step and support the 2 support rails until the right end has been fitted.




Step 29

Prepare the front rail and back rail

Tap 2 wooden dowels **A** into the front rail **11**.

Tap 2 wooden dowels **A** into the back rail **13**.



Assembly Instructions


Step 30

Fit the front rail and back rail

Fit the front rail **11** to the left end **1** using 2 screws **G** and the allen key **O**.

Fit the back rail **13** to the left end **1** using 2 screws **G** and the allen key **O**.

Note: Support the front and back rail until the right end has been fitted.




Assembly Instructions

Step 31

Fit the right end


Fit the right end **2** onto the assembly using 16 screws **G** and the allen key **O**.



Step 32

Secure the rear support rail

Screw through the 5 holes in the base **7** and into the top edge of the support rail **12** using 5 screws **H**.




Important: Make sure that the screws go into the centre of the top edge of the support rail.

Assembly Instructions

Step 33

Secure the back rail


Fix the back rail **13** to the back edge of the base **7** using 5 screws **H**.



Step 34

Secure the front rail

Loosely fix the 5 brackets **Q** to the holes in the base **7** using screws **K**.



Slide the brackets up against the mark holes in the front rail **11** and fix them using screws **J**.

Tighten up the screws **K**.

Assembly Instructions



Step 35

Fit the drawers

Starting with the bottom drawers, slide both the runners **S** forward and locate the drawer sides **15** and **16** between them, lining up the holes in the drawer wrap with the 2nd 'threaded' holes in the runners **S**.

Working from the inside of the drawer, insert 2 screws **M** through the drawer sides and out into the 2nd threaded hole in the runner.

Note: Do not overtighten the screws.
If they catch on the runner you may need to loosen them slightly.




Assembly Instructions

Step 36

Fit the shelf studs

Insert 4 shelf studs **U** at the required height into the uprights **4** and **5**.


Note: The fitting of the shelf is optional so please ignore steps 36 and 37 if it is not required.



Step 37

Fit the shelf

Lower the shelf **19** down onto the shelf studs **U** and tighten their screws.



IMPORTANT

On a regular basis please check that the screws and fittings have not become loose as this could present a potential choke hazard.

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800 and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

Malibu - Cabin Bed

Assembly Instructions - Please keep for future reference

268/5038

275/4433


278/5433

275/7557

249/2032

280/3315

WARNING
NOT SUITABLE FOR CHILDREN
UNDER 4 YEARS OF AGE .



Dimensions

Width - 195cm

Depth - 95cm

Height - 53cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 66kgs. Please lift with care.
- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



• We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

• **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings (not supplied).

• Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Tools required



Rule



Cross-head screwdriver



Scissors



Hammer



Eye protection (when using a hammer or drill)

IMPORTANT


On a regular basis please check that the screws and fittings have not become loose as this could present a potential choke hazard.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 03456 400800** quoting the reference numbers below


Please check you have all the panels listed below




1 Left End (D2931B)
(949 x 529mm)




2 Right End (D2936B)
(949 x 529mm)



4 Left Upright (D2937B)
(367 x 660mm)



5 Right Upright (D2929B)
(367 x 660mm)



7 Base (D2928B)
(1920 x 455.5mm) x 2




11 Front Rail (D2938A)
(1920 x 160mm)



12 Support Rail (D2939A)
(1920 x 92mm) x 2



13 Back Rail (D2926A)
(1920 x 160mm)




17 Drawer Back (W502-124)
(502 x 124mm) x 4



18 Drawer Base (T513-367)
(513 x 367mm) x 4




3 Horizontal (D2932A)
(820 x 287mm)



6 Back (D2927A)
(820 x 367mm)




8 Left Plinth (D2934A)
(535 x 60mm) x 2




9 Right Plinth (D2935A)
(535 x 60mm) x 2



10 Middle Plinth (D2933A)
(820 x 60mm)



14 Drawer Front (D2930B)
(531 x 157mm) x 4



15 Left Drawer Side (W370-124LH)
(370 x 124mm) x 4



16 Right Drawer Side (W370-124RH)
(370 x 124mm) x 4



19 Shelf (D3030A)
(820 x 287mm)







Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 03456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 16</p>	<p>B </p> <p>Metal dowel (F901) x 10</p>	<p>C </p> <p>Knock-in Peg (F171GY) x 16</p>
<p>D </p> <p>Large wooden dowel (F40) x 2</p>	<p>E </p> <p>Large locking nut (F900) x 6</p>	<p>F </p> <p>Small locking nut (F3) x 8</p>
<p>G </p> <p>50mm Screw (F49) x 48</p>	<p>H </p> <p>45mm Screw (F65) x 10</p>	<p>I </p> <p>25mm Screw (F50) x 4</p>
<p>J </p> <p>13mm Screw (F79) x 5</p>	<p>K </p> <p>13mm Screw (F52) x 5</p>	<p>L </p> <p>9mm Screw (F73) x 16</p>
<p>M </p> <p>9mm Screw (F74) x 8</p>	<p>N </p> <p>Plastic Nail (F91) x 10</p>	<p>O </p> <p>Allen Key (F36) x 1</p>
<p>P </p> <p>Wedgefix (F639) x 8</p>	<p>Q </p> <p>Bracket (F327) x 5</p>	<p>R </p> <p>Handle (F631) x 4</p>
<p>S </p> <p>Drawer runner (F1004) x 8</p>		<p>T </p> <p>Double metal dowel (F566) x 2</p>
<p>U </p> <p>Shelf stud (F372) x 4</p>		

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


If you have damaged or missing components, call the
Customer Helpline: 03456 400800 quoting the reference
numbers below

Step 1

Prepare the 4 drawer fronts

Screw 2 metal dowels **B** into each of the 4 drawer fronts **14**.

Note: Tighten the metal dowels up fully against the panels.




Step 2

Prepare 4 pairs of drawer sides

Insert a small locking nut **F** into the hole shown on the left drawer side **15** and the right drawer side **16**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Step 3

Attach the drawer sides to the drawer fronts

Push the left drawer sides **15** and right drawer sides **16** onto the back of the 4 drawer fronts **14**.

Turn the small locking nuts **F** on the left drawer side **15** and right drawer side **16**.

Note: Turn the locking nuts **F** clockwise to secure panels - more than 1/2 a turn.




Assembly Instructions

Step 4

Fit the drawer base

Slide the drawer base **18** down the grooves in the drawer sides **15** and **16** and down into the groove in the drawer front **14**.




Step 5

Fit the drawer back

Fit the drawer back **17** between the drawer sides **15** and **16**. Make sure that the drawer base **18** fits into the groove in the drawer back **17**.

Hold the drawer back **17** in position and tap the knock-in pegs **C** through the holes in the drawer sides **15** and **16**.




Step 6

Attach the handles

Attach a handle **R** to each of the drawer fronts **14** using screw **I**.


Note: Do not overtighten the screw.



Step 7

Fit the wedgifixes

Turn the drawer assemblies over and slide 2 wedgifixes **P** into the front and back grooves, as shown, and tighten up the screws.



Assembly Instructions

Step 8




Prepare the left upright

a: Tap 2 wooden dowels **A** into the left upright **4**.

Screw a metal dowel **B** into the left upright **4**.

Place 2 runners **S** on the left upright **4** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

b: Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the left upright **4**.



Step 9




Prepare the right upright

a: Tap 2 wooden dowels **A** into the right upright **5**.

Screw a metal dowel **B** into the right upright **5**.

Place 2 runners **S** on the right upright **5** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

b: Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the right upright **5**.




Assembly Instructions

Step 10

Fit the horizontal to the right upright

Fit the horizontal **3** onto the right upright **5** using 2 screws **G** and the allen key **O**.




Step 11

Prepare the middle plinth

Insert 2 large locking nuts **E** into the middle plinth **10**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Step 12

Fit the middle plinth


a: Tap a double metal dowel **T** and a large wooden dowel **D** through the right upright **5** and into the middle plinth **10** until they "bottom out".

b: Use a screwdriver to tighten the large locking nut **E** fitted to the middle plinth **10**.

Note: Turn the large locking nuts **E** as far as they will go - more than 1/2 a turn.



Important: It is critical that the middle plinth is assembled with the large locking nuts at the top.




Assembly Instructions

Step 13

Prepare the back


Tap 2 wooden dowels **A** into the back **6**.



Step 14

Fit the back


Push the back **6** onto the right upright **5** and fix it using 2 screws **G** and the allen key **O**.



Step 15

Fit the left upright

Push the left upright **4** onto the assembly and fix it using 4 screws **G** and the allen key **O**.




Assembly Instructions

Step 16

Secure the middle plinth to the left upright

a: Tap a double metal dowel **T** and a large wooden dowel **D** through the left upright **4** and into the middle plinth **10** until they "bottom out".

b: Use a screwdriver to tighten the large locking nut **E** fitted to the middle plinth **10**.




Step 17

Fit the 4 plastic nails

Tap 2 plastic nails **N** into the bottom edge of each of the uprights **4** and **5**.

Carefully stand the assembly up.




Step 18

Prepare the 2 left plinths

Tap a wooden dowel **A** into just 1 of the 2 left plinths **8**.

Insert a large locking nut **E** into each of the 2 left plinths **8**.




Assembly Instructions

Step 19

Fit the left plinths to the left upright

Push the left plinths **8** onto the left upright **4**.

Use a screwdriver to tighten the large locking nuts **E** fitted to the left plinths **8**.




Step 20

Prepare the 2 right plinths

Tap a wooden dowel **A** into just 1 of the 2 right plinths **9**.

Insert a large locking nut **E** into each of the 2 right plinths **9**.




Step 21

Fit the right plinths to the right upright

Push the right plinths **9** onto the right upright **5**.

Use a screwdriver to tighten the large locking nuts **E** fitted to the right plinths **9**.




Assembly Instructions

Step 22

Prepare the 2 bases


Tap 2 wooden dowels **A** into each of the 2 bases **7**.



Step 23

Fit a base

Fit a base **7** down onto the 2 uprights **4** and **5** using 4 screws **G** and the allen key **O**.




Assembly Instructions

Step 24

Fit the other base

2 people are needed to assemble this part

Fit the other base **7** down onto the 2 uprights **4** and **5** using 4 screws **G** and the allen key **O**.






Step 25

Prepare the right end

a: Place 2 runners **S** on the right end **2** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

b: Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the right end **2**.

Tap 3 plastic nails **N** into the bottom edge of each of the right end **2**.



Assembly Instructions




Step 26

Prepare the left end

a: Place 2 runners **S** on the left end **1** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

b: Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the left end **1**.


Tap 3 plastic nails **N** into the bottom edge of each of the left end **1**.



Step 27

Fit the left end

Fit the left end **1** onto the assembly using 8 screws **G** and the allen key **O**.




Assembly Instructions

Step 28

Fit the 2 support rails

Fit the 2 support rails **12** to the left end **1** using 2 screws **G** for each rail and the allen key **O**.

Note: Use 2 people for this step and support the 2 support rails until the right end has been fitted.




Step 29

Prepare the front rail and back rail

Tap 2 wooden dowels **A** into the front rail **11**.

Tap 2 wooden dowels **A** into the back rail **13**.



Assembly Instructions


Step 30

Fit the front rail and back rail

Fit the front rail **11** to the left end **1** using 2 screws **G** and the allen key **O**.

Fit the back rail **13** to the left end **1** using 2 screws **G** and the allen key **O**.

Note: Support the front and back rail until the right end has been fitted.




Assembly Instructions

Step 31

Fit the right end


Fit the right end **2** onto the assembly using 16 screws **G** and the allen key **O**.



Step 32

Secure the rear support rail

Screw through the 5 holes in the base **7** and into the top edge of the support rail **12** using 5 screws **H**.




Important: Make sure that the screws go into the centre of the top edge of the support rail.

Assembly Instructions

Step 33

Secure the back rail


Fix the back rail **13** to the back edge of the base **7** using 5 screws **H**.



Step 34

Secure the front rail

Loosely fix the 5 brackets **Q** to the holes in the base **7** using screws **K**.



Slide the brackets up against the mark holes in the front rail **11** and fix them using screws **J**.

Tighten up the screws **K**.

Assembly Instructions



Step 35

Fit the drawers

Starting with the bottom drawers, slide both the runners **S** forward and locate the drawer sides **15** and **16** between them, lining up the holes in the drawer wrap with the 2nd 'threaded' holes in the runners **S**.

Working from the inside of the drawer, insert 2 screws **M** through the drawer sides and out into the 2nd threaded hole in the runner.

Note: Do not overtighten the screws.
If they catch on the runner you may need to loosen them slightly.




Assembly Instructions

Step 36

Fit the shelf studs

Insert 4 shelf studs **U** at the required height into the uprights **4** and **5**.


Note: The fitting of the shelf is optional so please ignore steps 36 and 37 if it is not required.



Step 37

Fit the shelf

Lower the shelf **19** down onto the shelf studs **U** and tighten their screws.



IMPORTANT

On a regular basis please check that the screws and fittings have not become loose as this could present a potential choke hazard.

If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400800 and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW