

# Malibu - Cabin Bed

Assembly Instructions - Please keep for future reference

268/5038

275/4433


278/5433

275/7557

249/2032

280/3315

**WARNING**  
**NOT SUITABLE FOR CHILDREN**  
**UNDER 4 YEARS OF AGE .**



## Dimensions

Width - 195cm

Depth - 95cm

Height - 53cm



**MADE IN  
BRITAIN**

**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

# Safety and Care Advice


**Important** - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 66kgs. Please lift with care.
  - Check you have all the components and tools listed on pages 2 and 3.
  - Remove all fittings from the plastic bags and separate them into their groups.
  - Keep children and animals away from the work area, small parts could choke if swallowed.
  - Parts of the assembly will be easier with 2 people.
  - Make sure you have enough space to layout the parts before starting.
  - Do not stand or put weight on the product, this could cause damage.
  - Assemble the item as close to its final position (in the same room) as possible.
  - Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).
- 
- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.
  - **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings (not supplied).
  - Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Tools required



Rule



Cross-head screwdriver



Scissors



Hammer



Eye protection  
(when using a hammer or drill)

### IMPORTANT


**On a regular basis please check that the screws and fittings have not become loose as this could present a potential choke hazard.**

**Note:** If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


# Components - Panels

If you have damaged or missing components, call the  
**Customer Helpline: 08456 400800** quoting the reference  
numbers below


Please check you have all the panels listed below




**1** Left End (D2931A)  
(949 x 529mm)



**2** Right End (D2936A)  
(949 x 529mm)




**4** Left Upright (D2937A)  
(367 x 660mm)




**5** Right Upright (D2929A)  
(367 x 660mm)




**7** Base (D2928A)  
(1920 x 455.5mm) x 2



**11** Front Rail (D2938A)  
(1920 x 160mm)



**12** Support Rail (D2939A)  
(1920 x 92mm) x 2




**13** Back Rail (D2926A)  
(1920 x 160mm)




**17** Drawer Back (W502-124)  
(502 x 124mm) x 4




**18** Drawer Base (T513-367)  
(513 x 367mm) x 4



**3** Horizontal (D2932A)  
(820 x 287mm)



**6** Back (D2927A)  
(820 x 367mm)




**8** Left Plinth (D2934A)  
(535 x 60mm) x 2




**9** Right Plinth (D2935A)  
(535 x 60mm) x 2



**10** Middle Plinth (D2933A)  
(820 x 60mm)



**14** Drawer front (D2930A)  
(531 x 149mm) x 4



**15** Left Drawer Side (W370-124LH)  
(370 x 124mm) x 4



**16** Right Drawer Side (W370-124RH)  
(370 x 124mm) x 4



**19** Shelf (D3030A)  
(820 x 287mm)
























# Components - Fittings


If you have damaged or missing components, call the  
**Customer Helpline: 08456 400800** quoting the reference  
numbers below

Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<b>A</b>  Wooden dowel (F22) x 16	<b>B</b>  Metal dowel (F901) x 10	<b>C</b>  Knock-in Peg (F171GY) x 16
<b>D</b>  Large wooden dowel (F40) x 2	<b>E</b>  Large locking nut (F900) x 6	<b>F</b>  Small locking nut (F3) x 8
<b>G</b>  50mm Screw (F49) x 48	<b>H</b>  45mm Screw (F65) x 10	<b>I</b>  25mm Screw (F50) x 4
<b>J</b>  13mm Screw (F79) x 5	<b>K</b>  13mm Screw (F52) x 5	<b>L</b>  9mm Screw (F73) x 16
<b>M</b>  9mm Screw (F74) x 8	<b>N</b>  Plastic Nail (F91) x 10	<b>O</b>  Allen Key (F36) x 1
<b>P</b>  Wedgefix (F639) x 8	<b>Q</b>  Bracket (F327) x 5	<b>R</b>  Handle (F631) x 4
<b>S</b>  Drawer runner (F1004) x 8		<b>T</b>  Double metal dowel (F566) x 2
<b>U</b>  Shelf stud (F372) x 4		

Ruler - Use this ruler to help correctly identify the screws





# Assembly Instructions


If you have damaged or missing components, call the  
**Customer Helpline: 08456 400800** quoting the reference  
numbers below

## Step 1

### Prepare the 4 drawer fronts

Screw 2 metal dowels **B** into each of the 4 drawer fronts **14**.

**Note:** Tighten the metal dowels up fully against the panels.




## Step 2

### Prepare 4 pairs of drawer sides

Insert a small locking nut **F** into the hole shown on the left drawer side **15** and the right drawer side **16**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.




## Step 3

### Attach the drawer sides to the drawer fronts

Push the left drawer sides **15** and right drawer sides **16** onto the back of the 4 drawer fronts **14**.

Turn the small locking nuts **F** on the left drawer side **15** and right drawer side **16**.

**Note:** Turn the locking nuts **F** clockwise to secure panels - more than 1/2 a turn.




# Assembly Instructions

## Step 4

### Fit the drawer base

Slide the drawer base **18** down the grooves in the drawer sides **15** and **16** and down into the groove in the drawer front **14**.




## Step 5

### Fit the drawer back

Fit the drawer back **17** between the drawer sides **15** and **16**. Make sure that the drawer base **18** fits into the groove in the drawer back **17**.

Hold the drawer back **17** in position and tap the knock-in pegs **C** through the holes in the drawer sides **15** and **16**.




## Step 6

### Attach the handles

Attach a handle **R** to each of the drawer fronts **14** using screw **I**.



**Note: Do not overtighten the screw.**



## Step 7

### Fit the wedgifixes

Turn the drawer assemblies over and slide 2 wedgifixes **P** into the front and back grooves, as shown, and tighten up the screws.



x 4

# Assembly Instructions

## Step 8


### Prepare the left upright

**a:** Tap 2 wooden dowels **A** into the left upright **4**.

Screw a metal dowel **B** into the left upright **4**.

Place 2 runners **S** on the left upright **4** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

**b:** Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the left upright **4**.



## Step 9


### Prepare the right upright

**a:** Tap 2 wooden dowels **A** into the right upright **5**.

Screw a metal dowel **B** into the right upright **5**.

Place 2 runners **S** on the right upright **5** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

**b:** Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the right upright **5**.




# Assembly Instructions

## Step 10

### Fit the horizontal to the right upright

Fit the horizontal **3** onto the right upright **5** using 2 screws **G** and the allen key **O**.




## Step 11

### Prepare the middle plinth

Insert 2 large locking nuts **E** into the middle plinth **10**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.




## Step 12

### Fit the middle plinth


**a:** Tap a double metal dowel **T** and a large wooden dowel **D** through the right upright **5** and into the middle plinth **10** until they "bottom out".

**b:** Use a screwdriver to tighten the large locking nut **E** fitted to the middle plinth **10**.

**Note:** Turn the large locking nuts **E** as far as they will go - more than 1/2 a turn.



**Important:** It is critical that the middle plinth is assembled with the large locking nuts at the top.




# Assembly Instructions

## Step 13

### Prepare the back


Tap 2 wooden dowels **A** into the back **6**.



## Step 14

### Fit the back


Push the back **6** onto the right upright **5** and fix it using 2 screws **G** and the allen key **O**.



## Step 15

### Fit the left upright

Push the left upright **4** onto the assembly and fix it using 4 screws **G** and the allen key **O**.




# Assembly Instructions

## Step 16

### Secure the middle plinth to the left upright

**a:** Tap a double metal dowel **T** and a large wooden dowel **D** through the left upright **4** and into the middle plinth **10** until they "bottom out".

**b:** Use a screwdriver to tighten the large locking nut **E** fitted to the middle plinth **10**.




## Step 17

### Fit the 4 plastic nails

Tap 2 plastic nails **N** into the bottom edge of each of the uprights **4** and **5**.

**Carefully stand the assembly up.**




## Step 18

### Prepare the 2 left plinths

Tap a wooden dowel **A** into just 1 of the 2 left plinths **8**.

Insert a large locking nut **E** into each of the 2 left plinths **8**.




# Assembly Instructions

## Step 19

### Fit the left plinths to the left upright

Push the left plinths **8** onto the left upright **4**.

Use a screwdriver to tighten the large locking nuts **E** fitted to the left plinths **8**.




## Step 20

### Prepare the 2 right plinths

Tap a wooden dowel **A** into just 1 of the 2 right plinths **9**.

Insert a large locking nut **E** into each of the 2 right plinths **9**.




## Step 21

### Fit the right plinths to the right upright

Push the right plinths **9** onto the right upright **5**.

Use a screwdriver to tighten the large locking nuts **E** fitted to the right plinths **9**.




# Assembly Instructions

## Step 22

### Prepare the 2 bases


Tap 2 wooden dowels **A** into each of the 2 bases **7**.



## Step 23

### Fit a base

Fit a base **7** down onto the 2 uprights **4** and **5** using 4 screws **G** and the allen key **O**.






# Assembly Instructions

## Step 24

### Fit the other base

*2 people are needed to assemble this part*

Fit the other base **7** down onto the 2 uprights **4** and **5** using 4 screws **G** and the allen key **O**.




## Step 25

### Prepare the right end


**a:** Place 2 runners **S** on the right end **2** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

**b:** Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the right end **2**.


Tap 3 plastic nails **N** into the bottom edge of each of the right end **2**.



**a:**



**b:**



# Assembly Instructions




## Step 26

### Prepare the left end

**a:** Place 2 runners **S** on the left end **1** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

**b:** Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the left end **1**.


Tap 3 plastic nails **N** into the bottom edge of each of the left end **1**.



## Step 27

### Fit the left end

Fit the left end **1** onto the assembly using 8 screws **G** and the allen key **O**.




# Assembly Instructions

## Step 28

### Fit the 2 support rails

Fit the 2 support rails **12** to the left end **1** using 2 screws **G** for each rail and the allen key **O**.

**Note:** Use 2 people for this step and support the 2 support rails until the right end has been fitted.




## Step 29

### Prepare the front rail and back rail

Tap 2 wooden dowels **A** into the front rail **11**.

Tap 2 wooden dowels **A** into the back rail **13**.



# Assembly Instructions


## Step 30

### Fit the front rail and back rail

Fit the front rail **11** to the left end **1** using 2 screws **G** and the allen key **O**.

Fit the back rail **13** to the left end **1** using 2 screws **G** and the allen key **O**.

**Note:** Support the front and back rail until the right end has been fitted.




# Assembly Instructions

## Step 31

### Fit the right end


Fit the right end **2** onto the assembly using 16 screws **G** and the allen key **O**.



## Step 32

### Secure the rear support rail

Screw through the 5 holes in the base **7** and into the top edge of the support rail **12** using 5 screws **H**.




**Important:** Make sure that the screws go into the centre of the top edge of the support rail.

# Assembly Instructions

## Step 33

### Secure the back rail


Fix the back rail **13** to the back edge of the base **7** using 5 screws **H**.



## Step 34

### Secure the front rail

Loosely fix the 5 brackets **Q** to the holes in the base **7** using screws **K**.



Slide the brackets up against the mark holes in the front rail **11** and fix them using screws **J**.

Tighten up the screws **K**.



# Assembly Instructions

## Step 35

### Fit the drawers

Starting with the bottom drawers, slide both the runners **S** forward and locate the drawer sides **15** and **16** between them, lining up the holes in the drawer wrap with the 2nd 'threaded' holes in the runners **S**.

Working from the inside of the drawer, insert 2 screws **M** through the drawer sides and out into the 2nd threaded hole in the runner.



**Note:** Do not overtighten the screws.  
If they catch on the runner you may need to loosen them slightly.


# Assembly Instructions

## Step 36

### Fit the shelf studs

Insert 4 shelf studs **U** at the required height into the uprights **4** and **5**.


**Note:** The fitting of the shelf is optional so please ignore steps 36 and 37 if it is not required.



## Step 37

### Fit the shelf

Lower the shelf **19** down onto the shelf studs **U** and tighten their screws.



### IMPORTANT

**On a regular basis please check that the screws and fittings have not become loose as this could present a potential choke hazard.**

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800 and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW



# Malibu - Cabin Bed

Assembly Instructions - Please keep for future reference

268/5038

275/4433


278/5433

275/7557

249/2032

280/3315

**WARNING**  
**NOT SUITABLE FOR CHILDREN**  
**UNDER 4 YEARS OF AGE .**



## Dimensions

Width - 195cm

Depth - 95cm

Height - 53cm




**MADE IN  
BRITAIN**

**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

# Safety and Care Advice


**Important** - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 66kgs. Please lift with care.
  - Check you have all the components and tools listed on pages 2 and 3.
  - Remove all fittings from the plastic bags and separate them into their groups.
  - Keep children and animals away from the work area, small parts could choke if swallowed.
  - Parts of the assembly will be easier with 2 people.
  - Make sure you have enough space to layout the parts before starting.
  - Do not stand or put weight on the product, this could cause damage.
  - Assemble the item as close to its final position (in the same room) as possible.
  - Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).
- 
- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.
  - **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings (not supplied).
  - Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Tools required



Rule



Cross-head screwdriver



Scissors



Hammer



Eye protection  
(when using a hammer or drill)

### IMPORTANT


**On a regular basis please check that the screws and fittings have not become loose as this could present a potential choke hazard.**

**Note:** If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


# Components - Panels

If you have damaged or missing components, call the  
**Customer Helpline: 08456 400800** quoting the reference  
numbers below


Please check you have all the panels listed below




**1** Left End (D2931B)  
(949 x 529mm)



**2** Right End (D2936B)  
(949 x 529mm)




**4** Left Upright (D2937B)  
(367 x 660mm)




**5** Right Upright (D2929B)  
(367 x 660mm)




**7** Base (D2928A)  
(1920 x 455.5mm) x 2



**11** Front Rail (D2938A)  
(1920 x 160mm)



**12** Support Rail (D2939A)  
(1920 x 92mm) x 2




**13** Back Rail (D2926A)  
(1920 x 160mm)




**17** Drawer Back (W502-124)  
(502 x 124mm) x 4




**18** Drawer Base (T513-367)  
(513 x 367mm) x 4



**3** Horizontal (D2932A)  
(820 x 287mm)



**6** Back (D2927A)  
(820 x 367mm)




**8** Left Plinth (D2934A)  
(535 x 60mm) x 2



**9** Right Plinth (D2935A)  
(535 x 60mm) x 2



**10** Middle Plinth (D2933A)  
(820 x 60mm)



**14** Drawer Front (D2930B)  
(531 x 157mm) x 4



**15** Left Drawer Side (W370-124LH)  
(370 x 124mm) x 4



**16** Right Drawer Side (W370-124RH)  
(370 x 124mm) x 4



**19** Shelf (D3030A)  
(820 x 287mm)
























# Components - Fittings


If you have damaged or missing components, call the  
**Customer Helpline: 08456 400800** quoting the reference  
numbers below

Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<b>A</b>  Wooden dowel (F22) x 16	<b>B</b>  Metal dowel (F901) x 10	<b>C</b>  Knock-in Peg (F171GY) x 16
<b>D</b>  Large wooden dowel (F40) x 2	<b>E</b>  Large locking nut (F900) x 6	<b>F</b>  Small locking nut (F3) x 8
<b>G</b>  50mm Screw (F49) x 48	<b>H</b>  45mm Screw (F65) x 10	<b>I</b>  25mm Screw (F50) x 4
<b>J</b>  13mm Screw (F79) x 5	<b>K</b>  13mm Screw (F52) x 5	<b>L</b>  9mm Screw (F73) x 16
<b>M</b>  9mm Screw (F74) x 8	<b>N</b>  Plastic Nail (F91) x 10	<b>O</b>  Allen Key (F36) x 1
<b>P</b>  Wedgefix (F639) x 8	<b>Q</b>  Bracket (F327) x 5	<b>R</b>  Handle (F631) x 4
<b>S</b>  Drawer runner (F1004) x 8		<b>T</b>  Double metal dowel (F566) x 2
<b>U</b>  Shelf stud (F372) x 4		

Ruler - Use this ruler to help correctly identify the screws



# Assembly Instructions


If you have damaged or missing components, call the  
**Customer Helpline: 08456 400800** quoting the reference  
numbers below

## Step 1

### Prepare the 4 drawer fronts

Screw 2 metal dowels **B** into each of the 4 drawer fronts **14**.

**Note:** Tighten the metal dowels up fully against the panels.




## Step 2

### Prepare 4 pairs of drawer sides

Insert a small locking nut **F** into the hole shown on the left drawer side **15** and the right drawer side **16**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.




## Step 3

### Attach the drawer sides to the drawer fronts

Push the left drawer sides **15** and right drawer sides **16** onto the back of the 4 drawer fronts **14**.

Turn the small locking nuts **F** on the left drawer side **15** and right drawer side **16**.

**Note:** Turn the locking nuts **F** clockwise to secure panels - more than 1/2 a turn.




# Assembly Instructions

## Step 4

### Fit the drawer base

Slide the drawer base **18** down the grooves in the drawer sides **15** and **16** and down into the groove in the drawer front **14**.




## Step 5

### Fit the drawer back

Fit the drawer back **17** between the drawer sides **15** and **16**. Make sure that the drawer base **18** fits into the groove in the drawer back **17**.

Hold the drawer back **17** in position and tap the knock-in pegs **C** through the holes in the drawer sides **15** and **16**.




## Step 6

### Attach the handles

Attach a handle **R** to each of the drawer fronts **14** using screw **I**.



**Note: Do not overtighten the screw.**



## Step 7

### Fit the wedgifixes

Turn the drawer assemblies over and slide 2 wedgifixes **P** into the front and back grooves, as shown, and tighten up the screws.



x 4

# Assembly Instructions

## Step 8


### Prepare the left upright

**a:** Tap 2 wooden dowels **A** into the left upright **4**.

Screw a metal dowel **B** into the left upright **4**.

Place 2 runners **S** on the left upright **4** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

**b:** Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the left upright **4**.



## Step 9


### Prepare the right upright

**a:** Tap 2 wooden dowels **A** into the right upright **5**.

Screw a metal dowel **B** into the right upright **5**.

Place 2 runners **S** on the right upright **5** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

**b:** Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the right upright **5**.




# Assembly Instructions

## Step 10

### Fit the horizontal to the right upright

Fit the horizontal **3** onto the right upright **5** using 2 screws **G** and the allen key **O**.




## Step 11

### Prepare the middle plinth

Insert 2 large locking nuts **E** into the middle plinth **10**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.




## Step 12

### Fit the middle plinth


**a:** Tap a double metal dowel **T** and a large wooden dowel **D** through the right upright **5** and into the middle plinth **10** until they "bottom out".

**b:** Use a screwdriver to tighten the large locking nut **E** fitted to the middle plinth **10**.

**Note:** Turn the large locking nuts **E** as far as they will go - more than 1/2 a turn.



**Important:** It is critical that the middle plinth is assembled with the large locking nuts at the top.






# Assembly Instructions

## Step 13

### Prepare the back


Tap 2 wooden dowels **A** into the back **6**.



## Step 14

### Fit the back


Push the back **6** onto the right upright **5** and fix it using 2 screws **G** and the allen key **O**.



## Step 15

### Fit the left upright

Push the left upright **4** onto the assembly and fix it using 4 screws **G** and the allen key **O**.




# Assembly Instructions

## Step 16

### Secure the middle plinth to the left upright

**a:** Tap a double metal dowel **T** and a large wooden dowel **D** through the left upright **4** and into the middle plinth **10** until they "bottom out".

**b:** Use a screwdriver to tighten the large locking nut **E** fitted to the middle plinth **10**.




## Step 17

### Fit the 4 plastic nails

Tap 2 plastic nails **N** into the bottom edge of each of the uprights **4** and **5**.

**Carefully stand the assembly up.**




## Step 18

### Prepare the 2 left plinths

Tap a wooden dowel **A** into just 1 of the 2 left plinths **8**.

Insert a large locking nut **E** into each of the 2 left plinths **8**.




# Assembly Instructions

## Step 19

### Fit the left plinths to the left upright

Push the left plinths **8** onto the left upright **4**.

Use a screwdriver to tighten the large locking nuts **E** fitted to the left plinths **8**.




## Step 20

### Prepare the 2 right plinths

Tap a wooden dowel **A** into just 1 of the 2 right plinths **9**.

Insert a large locking nut **E** into each of the 2 right plinths **9**.




## Step 21

### Fit the right plinths to the right upright

Push the right plinths **9** onto the right upright **5**.

Use a screwdriver to tighten the large locking nuts **E** fitted to the right plinths **9**.




# Assembly Instructions

## Step 22

### Prepare the 2 bases


Tap 2 wooden dowels **A** into each of the 2 bases **7**.



## Step 23

### Fit a base

Fit a base **7** down onto the 2 uprights **4** and **5** using 4 screws **G** and the allen key **O**.




# Assembly Instructions

## Step 24

### Fit the other base

*2 people are needed to assemble this part*

Fit the other base **7** down onto the 2 uprights **4** and **5** using 4 screws **G** and the allen key **O**.




## Step 25

### Prepare the right end


**a:** Place 2 runners **S** on the right end **2** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

**b:** Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the right end **2**.


Tap 3 plastic nails **N** into the bottom edge of each of the right end **2**.



**a:**



**b:**



# Assembly Instructions




## Step 26

### Prepare the left end

**a:** Place 2 runners **S** on the left end **1** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

**b:** Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the left end **1**.


Tap 3 plastic nails **N** into the bottom edge of each of the left end **1**.



## Step 27

### Fit the left end

Fit the left end **1** onto the assembly using 8 screws **G** and the allen key **O**.




# Assembly Instructions

## Step 28

### Fit the 2 support rails

Fit the 2 support rails **12** to the left end **1** using 2 screws **G** for each rail and the allen key **O**.

**Note:** Use 2 people for this step and support the 2 support rails until the right end has been fitted.




## Step 29

### Prepare the front rail and back rail

Tap 2 wooden dowels **A** into the front rail **11**.

Tap 2 wooden dowels **A** into the back rail **13**.



# Assembly Instructions


## Step 30

### Fit the front rail and back rail

Fit the front rail **11** to the left end **1** using 2 screws **G** and the allen key **O**.

Fit the back rail **13** to the left end **1** using 2 screws **G** and the allen key **O**.

**Note:** Support the front and back rail until the right end has been fitted.






# Assembly Instructions

## Step 31

### Fit the right end


Fit the right end **2** onto the assembly using 16 screws **G** and the allen key **O**.



## Step 32

### Secure the rear support rail

Screw through the 5 holes in the base **7** and into the top edge of the support rail **12** using 5 screws **H**.




**Important:** Make sure that the screws go into the centre of the top edge of the support rail.

# Assembly Instructions

## Step 33

### Secure the back rail


Fix the back rail **13** to the back edge of the base **7** using 5 screws **H**.



## Step 34

### Secure the front rail

Loosely fix the 5 brackets **Q** to the holes in the base **7** using screws **K**.



Slide the brackets up against the mark holes in the front rail **11** and fix them using screws **J**.

Tighten up the screws **K**.



# Assembly Instructions

## Step 35

### Fit the drawers

Starting with the bottom drawers, slide both the runners **S** forward and locate the drawer sides **15** and **16** between them, lining up the holes in the drawer wrap with the 2nd 'threaded' holes in the runners **S**.

Working from the inside of the drawer, insert 2 screws **M** through the drawer sides and out into the 2nd threaded hole in the runner.



**Note:** Do not overtighten the screws.  
If they catch on the runner you may need to loosen them slightly.


# Assembly Instructions

## Step 36

### Fit the shelf studs

Insert 4 shelf studs **U** at the required height into the uprights **4** and **5**.


**Note:** The fitting of the shelf is optional so please ignore steps 36 and 37 if it is not required.



## Step 37

### Fit the shelf

Lower the shelf **19** down onto the shelf studs **U** and tighten their screws.



### IMPORTANT

**On a regular basis please check that the screws and fittings have not become loose as this could present a potential choke hazard.**

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800 and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

# Malibu - Cabin Bed

Assembly Instructions - Please keep for future reference

268/5038

275/4433


278/5433

275/7557

249/2032

280/3315

**WARNING**  
**NOT SUITABLE FOR CHILDREN**  
**UNDER 4 YEARS OF AGE .**



## Dimensions

Width - 195cm

Depth - 95cm

Height - 53cm



**MADE IN  
BRITAIN**

**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**

# Safety and Care Advice


**Important** - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 66kgs. Please lift with care.
  - Check you have all the components and tools listed on pages 2 and 3.
  - Remove all fittings from the plastic bags and separate them into their groups.
  - Keep children and animals away from the work area, small parts could choke if swallowed.
  - Parts of the assembly will be easier with 2 people.
  - Make sure you have enough space to layout the parts before starting.
  - Do not stand or put weight on the product, this could cause damage.
  - Assemble the item as close to its final position (in the same room) as possible.
  - Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).
- 
- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.
  - **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings (not supplied).
  - Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Tools required



Rule



Cross-head screwdriver



Scissors



Hammer



Eye protection  
(when using a hammer or drill)

### IMPORTANT


**On a regular basis please check that the screws and fittings have not become loose as this could present a potential choke hazard.**

**Note:** If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


# Components - Panels

If you have damaged or missing components, call the  
**Customer Helpline: 03456 400800** quoting the reference  
numbers below


Please check you have all the panels listed below




**1** Left End (D2931B)  
(949 x 529mm)



**2** Right End (D2936B)  
(949 x 529mm)




**4** Left Upright (D2937B)  
(367 x 660mm)




**5** Right Upright (D2929B)  
(367 x 660mm)




**7** Base (D2928B)  
(1920 x 455.5mm) x 2



**11** Front Rail (D2938A)  
(1920 x 160mm)




**12** Support Rail (D2939A)  
(1920 x 92mm) x 2



**13** Back Rail (D2926A)  
(1920 x 160mm)




**17** Drawer Back (W502-124)  
(502 x 124mm) x 4




**18** Drawer Base (T513-367)  
(513 x 367mm) x 4



**3** Horizontal (D2932A)  
(820 x 287mm)



**6** Back (D2927A)  
(820 x 367mm)




**8** Left Plinth (D2934A)  
(535 x 60mm) x 2



**9** Right Plinth (D2935A)  
(535 x 60mm) x 2



**10** Middle Plinth (D2933A)  
(820 x 60mm)



**14** Drawer Front (D2930B)  
(531 x 157mm) x 4



**15** Left Drawer Side (W370-124LH)  
(370 x 124mm) x 4



**16** Right Drawer Side (W370-124RH)  
(370 x 124mm) x 4



**19** Shelf (D3030A)  
(820 x 287mm)
























# Components - Fittings


If you have damaged or missing components, call the  
**Customer Helpline: 03456 400800** quoting the reference  
numbers below

Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<b>A</b>  Wooden dowel (F22) x 16	<b>B</b>  Metal dowel (F901) x 10	<b>C</b>  Knock-in Peg (F171GY) x 16
<b>D</b>  Large wooden dowel (F40) x 2	<b>E</b>  Large locking nut (F900) x 6	<b>F</b>  Small locking nut (F3) x 8
<b>G</b>  50mm Screw (F49) x 48	<b>H</b>  45mm Screw (F65) x 10	<b>I</b>  25mm Screw (F50) x 4
<b>J</b>  13mm Screw (F79) x 5	<b>K</b>  13mm Screw (F52) x 5	<b>L</b>  9mm Screw (F73) x 16
<b>M</b>  9mm Screw (F74) x 8	<b>N</b>  Plastic Nail (F91) x 10	<b>O</b>  Allen Key (F36) x 1
<b>P</b>  Wedgefix (F639) x 8	<b>Q</b>  Bracket (F327) x 5	<b>R</b>  Handle (F631) x 4
<b>S</b>  Drawer runner (F1004) x 8		<b>T</b>  Double metal dowel (F566) x 2
<b>U</b>  Shelf stud (F372) x 4		

Ruler - Use this ruler to help correctly identify the screws





# Assembly Instructions


If you have damaged or missing components, call the  
**Customer Helpline: 03456 400800** quoting the reference  
numbers below

## Step 1

### Prepare the 4 drawer fronts

Screw 2 metal dowels **B** into each of the 4 drawer fronts **14**.

**Note:** Tighten the metal dowels up fully against the panels.




## Step 2

### Prepare 4 pairs of drawer sides

Insert a small locking nut **F** into the hole shown on the left drawer side **15** and the right drawer side **16**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.




## Step 3

### Attach the drawer sides to the drawer fronts

Push the left drawer sides **15** and right drawer sides **16** onto the back of the 4 drawer fronts **14**.

Turn the small locking nuts **F** on the left drawer side **15** and right drawer side **16**.

**Note:** Turn the locking nuts **F** clockwise to secure panels - more than 1/2 a turn.




# Assembly Instructions

## Step 4

### Fit the drawer base

Slide the drawer base **18** down the grooves in the drawer sides **15** and **16** and down into the groove in the drawer front **14**.




## Step 5

### Fit the drawer back

Fit the drawer back **17** between the drawer sides **15** and **16**. Make sure that the drawer base **18** fits into the groove in the drawer back **17**.

Hold the drawer back **17** in position and tap the knock-in pegs **C** through the holes in the drawer sides **15** and **16**.




## Step 6

### Attach the handles

Attach a handle **R** to each of the drawer fronts **14** using screw **I**.



**Note: Do not overtighten the screw.**



## Step 7

### Fit the wedgfixes

Turn the drawer assemblies over and slide 2 wedgfixes **P** into the front and back grooves, as shown, and tighten up the screws.



x 4

# Assembly Instructions

## Step 8


### Prepare the left upright

**a:** Tap 2 wooden dowels **A** into the left upright **4**.

Screw a metal dowel **B** into the left upright **4**.

Place 2 runners **S** on the left upright **4** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

**b:** Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the left upright **4**.



## Step 9


### Prepare the right upright

**a:** Tap 2 wooden dowels **A** into the right upright **5**.

Screw a metal dowel **B** into the right upright **5**.

Place 2 runners **S** on the right upright **5** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

**b:** Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the right upright **5**.




# Assembly Instructions

## Step 10

### Fit the horizontal to the right upright

Fit the horizontal **3** onto the right upright **5** using 2 screws **G** and the allen key **O**.




## Step 11

### Prepare the middle plinth

Insert 2 large locking nuts **E** into the middle plinth **10**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.




## Step 12

### Fit the middle plinth


**a:** Tap a double metal dowel **T** and a large wooden dowel **D** through the right upright **5** and into the middle plinth **10** until they "bottom out".

**b:** Use a screwdriver to tighten the large locking nut **E** fitted to the middle plinth **10**.

**Note:** Turn the large locking nuts **E** as far as they will go - more than 1/2 a turn.



**Important:** It is critical that the middle plinth is assembled with the large locking nuts at the top.




# Assembly Instructions

## Step 13

### Prepare the back


Tap 2 wooden dowels **A** into the back **6**.



## Step 14

### Fit the back


Push the back **6** onto the right upright **5** and fix it using 2 screws **G** and the allen key **O**.



## Step 15

### Fit the left upright

Push the left upright **4** onto the assembly and fix it using 4 screws **G** and the allen key **O**.




# Assembly Instructions

## Step 16

### Secure the middle plinth to the left upright

**a:** Tap a double metal dowel **T** and a large wooden dowel **D** through the left upright **4** and into the middle plinth **10** until they "bottom out".

**b:** Use a screwdriver to tighten the large locking nut **E** fitted to the middle plinth **10**.




## Step 17

### Fit the 4 plastic nails

Tap 2 plastic nails **N** into the bottom edge of each of the uprights **4** and **5**.

**Carefully stand the assembly up.**




## Step 18

### Prepare the 2 left plinths

Tap a wooden dowel **A** into just 1 of the 2 left plinths **8**.

Insert a large locking nut **E** into each of the 2 left plinths **8**.




# Assembly Instructions

## Step 19

### Fit the left plinths to the left upright

Push the left plinths **8** onto the left upright **4**.

Use a screwdriver to tighten the large locking nuts **E** fitted to the left plinths **8**.




## Step 20

### Prepare the 2 right plinths

Tap a wooden dowel **A** into just 1 of the 2 right plinths **9**.

Insert a large locking nut **E** into each of the 2 right plinths **9**.




## Step 21

### Fit the right plinths to the right upright

Push the right plinths **9** onto the right upright **5**.

Use a screwdriver to tighten the large locking nuts **E** fitted to the right plinths **9**.




# Assembly Instructions

## Step 22

### Prepare the 2 bases


Tap 2 wooden dowels **A** into each of the 2 bases **7**.



## Step 23

### Fit a base

Fit a base **7** down onto the 2 uprights **4** and **5** using 4 screws **G** and the allen key **O**.






# Assembly Instructions

## Step 24

### Fit the other base

*2 people are needed to assemble this part*

Fit the other base **7** down onto the 2 uprights **4** and **5** using 4 screws **G** and the allen key **O**.




## Step 25

### Prepare the right end


**a:** Place 2 runners **S** on the right end **2** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

**b:** Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the right end **2**.


Tap 3 plastic nails **N** into the bottom edge of each of the right end **2**.



**a:**



**b:**



# Assembly Instructions




## Step 26

### Prepare the left end

**a:** Place 2 runners **S** on the left end **1** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **L**.

**b:** Slide the runner **S** back the other way and fit the 2nd screw **L** into the corresponding hole in the left end **1**.


Tap 3 plastic nails **N** into the bottom edge of each of the left end **1**.



## Step 27

### Fit the left end

Fit the left end **1** onto the assembly using 8 screws **G** and the allen key **O**.




# Assembly Instructions

## Step 28

### Fit the 2 support rails

Fit the 2 support rails **12** to the left end **1** using 2 screws **G** for each rail and the allen key **O**.

**Note:** Use 2 people for this step and support the 2 support rails until the right end has been fitted.




## Step 29

### Prepare the front rail and back rail

Tap 2 wooden dowels **A** into the front rail **11**.

Tap 2 wooden dowels **A** into the back rail **13**.



# Assembly Instructions

## Step 30


### Fit the front rail and back rail

Fit the front rail **11** to the left end **1** using 2 screws **G** and the allen key **O**.

Fit the back rail **13** to the left end **1** using 2 screws **G** and the allen key **O**.

**Note:** Support the front and back rail until the right end has been fitted.

This is the back of the bed




# Assembly Instructions

## Step 31

### Fit the right end


Fit the right end **2** onto the assembly using 16 screws **G** and the allen key **O**.



## Step 32

### Secure the rear support rail

Screw through the 5 holes in the base **7** and into the top edge of the support rail **12** using 5 screws **H**.




**Important:** Make sure that the screws go into the centre of the top edge of the support rail.

# Assembly Instructions

## Step 33

### Secure the back rail


Fix the back rail **13** to the back edge of the base **7** using 5 screws **H**.



## Step 34

### Secure the front rail

Loosely fix the 5 brackets **Q** to the holes in the base **7** using screws **K**.



Slide the brackets up against the mark holes in the front rail **11** and fix them using screws **J**.

Tighten up the screws **K**.



# Assembly Instructions

## Step 35

### Fit the drawers

Starting with the bottom drawers, slide both the runners **S** forward and locate the drawer sides **15** and **16** between them, lining up the holes in the drawer wrap with the 2nd 'threaded' holes in the runners **S**.

Working from the inside of the drawer, insert 2 screws **M** through the drawer sides and out into the 2nd threaded hole in the runner.



**Note:** Do not overtighten the screws.  
If they catch on the runner you may need to loosen them slightly.


# Assembly Instructions

## Step 36

### Fit the shelf studs

Insert 4 shelf studs **U** at the required height into the uprights **4** and **5**.


**Note:** The fitting of the shelf is optional so please ignore steps 36 and 37 if it is not required.



## Step 37

### Fit the shelf

Lower the shelf **19** down onto the shelf studs **U** and tighten their screws.



### IMPORTANT

**On a regular basis please check that the screws and fittings have not become loose as this could present a potential choke hazard.**

If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400800 and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW