


# Puerto Rico - 3 Door Wardrobe

**Assembly Instructions** - Please keep for future reference

332/6901

338/7012



## Dimensions

Width - 158.8cm

Depth - 57cm

Height - 188cm

**Important – Please read these instructions fully before starting assembly**

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400 800**



# Safety and Care Advice

**Important – Please read these instructions fully before starting assembly**

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.

• This product has been produced from natural timber; you may notice some variation in the grain and colour of different component parts which is normal for furniture produced using natural wood and is not the result of any manufacturing fault.

• The product has been treated with a wax and oil finish to prevent dirt ingress and preserve moisture.

• On unpacking the furniture you may notice an odour due to this treatment; this will disappear once the furniture is unpacked and assembled after a period of time.

• This process may leave some staining on the packaging material; please take care to ensure this does not transfer to clothing or carpeted surfaces during assembly.



as this could damage the unit. Only use hand screwdrivers.

• We do not recommend the use of power drill/drivers **for inserting screws**,

• Parts of the assembly will be easier with 2 people.

• Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Use an appropriate furniture polish for natural wood furniture and a dry cloth to clean the product.
- Avoid placing the furniture in direct sunlight as this will cause the timber to prematurely age.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

**Note:** If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

# Components - Panels

Please check you have all the panels listed below




**1** Right side panel (177.3 x 53cm)



**2** Left side panel (177.3 x 53cm)




**3** Middle wall panel (164.5 x 52.5cm)



**4** Top panel (152.8 x 50cm)



**5** Base panel (149.3 x 51.4cm)



**6** Back panel right (167 x 48.8cm)



**7** Back panel left x 2 (167 x 50.8cm)




**8** Right front frame (178 x 6.5cm)




**9** Left front frame (178 x 6.5cm)



**10** Right middle front frame (167 x 6.5cm)




**11** Left middle front frame (167 x 6.5cm)



**12** Horizontal front frame (140 x 6.5cm)



**13** Larger H profile (137 x 2cm)




**14** Curved top rail (149 x 21cm)




**15** Curved top moulding (158.8 x 12.6cm)




**16** Front plinth (158.8 x 11.2cm)




**17** Right door (166.6 x 41.6cm)




**18** Middle door (166.6 x 41.6cm)



**19** Left door (166.6 x 41.6cm)



**20** Left shelf (100.5 x 51.5cm)



**21** Right fixed shelf (47 x 51.5cm)



**22** Right shelf x 2 (47 x 51.5cm)



**23** Hanging rail (100 x 2.8cm)



**24** Side top moulding x 2 (54 x 2.8cm)



**25** Side plinth x 2 (54 x 11.2cm)



**26** Smaller H profile (25 x 2cm)



**27** Bottom Support (20 x 10.3cm)



**28** Blocks x 2 (20 x 2.5cm)



**29** Blocks x 11 (10 x 2cm)



**30** Hanging rail support x 2 (7 x 6.5cm)












# Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 03456 400 800**

Please check you have all the fittings listed below


**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<b>A</b>  Wooden dowel x 34	<b>B</b>  14mm Screw x 70	<b>C</b>  25mm Screw x 12
<b>D</b>  35mm Screw x 26	<b>E</b>  35mm Screw x 49	<b>F</b>  50mm Screw x 8
<b>G</b>  Metal dowel x 12	<b>H</b>  Locking nut x 12	<b>J</b>  19mm Bolt x 3
<b>K</b>  Door handle x 3	<b>L</b>  Door hinge x 9	<b>M</b>  Clip x 6
<b>N</b>  Plug x 6	<b>O</b>  Shelf support x 8	<b>P</b>  Metal stud x 2
<b>Q</b>  Nail x 64	<b>R</b>  Washer x 2	<b>S</b>  Wall strap x 1
<b>T</b>  Door spacer x 1		


## Tools required



Phillips screwdriver  
(medium & large)



Ruler/tape  
measure



Small  
hammer



Eye protection  
(when using a  
hammer or glue)

**Ruler** - Use this ruler to help correctly identify the screws



# Assembly Instructions

## Step 1


**Fixing right front frame.**  
(Two people required for an easier assembly).

**a:** Insert right side panel **1** into right front frame **8** through joints.

**Note:** Before fixing the blocks **29** into place it is important to ensure that the slot and groove of parts **1** and **8** are fully pushed together and lined up correctly at the top and bottom.

**b:** Place blocks **29** between the two marks on the front frame as shown. First fix to the side panel using screws **E**.

**c:** Fix front frame through blocks **29** using screws **E**.



## Step 2


**Fixing left front frame.**  
(Two people required for an easier assembly).

**a:** Insert left side panel **2** into left front frame **9** through joints.

**Note:** Before fixing the blocks **29** into place it is important to ensure that the slot and groove of parts **2** and **9** are fully pushed together and lined up correctly at the top and bottom.

**b:** Place blocks **29** between the two marks on the front frame as shown. First fix to the side panel using screws **E**.

**c:** Fix front frame through blocks **29** using screws **E**.






# Assembly Instructions

## Step 3

### Fixing middle front frame.

(Two people required for an easier assembly).


**a:** Insert middle wall panel **3** into right middle front frame **10** through joints.



**Attention!** Ensure to leave **9mm** of middle front frame out before fixing.


**b:** Place blocks **29** between the two marks on the front frame as shown. First fix to the middle wall panel using screws **E**.

**c:** Fix middle front frame through blocks **29** using screws **E**.



## Step 4

Insert shelf supports **O** into the right side panel **1** and middle wall panel **3**.




# Assembly Instructions

## Step 5

Insert dowels **A** into the indicated parts.

Fix hanging rail supports **30** in the pre marked holes on left side panel **2** and middle wall panel **3** using screws **E**, as shown.



# Assembly Instructions

## Step 6




### Fitting Metal dowels.

Screw metal dowels **G** into right side panel **1** and left side panel **2**.



**Note:** Insert metal dowels as far as shown.

**Do not over tighten.**



## Step 7




### Fitting Metal dowels.

Screw metal dowels **G** into both sides of middle wall panel **3**.



**Note:** Insert metal dowels as far as shown.

**Do not over tighten.**



# Assembly Instructions


## Step 8

### Fixing base panel.

Fit base panel **5** to the middle wall panel **3** then fix it using screws **F**.



**Attention!**  
Round edge on base panel must be facing front.



## Step 9

### Fixing shelves.

With help, fit shelf **20** and fixed shelf **21** to middle wall panel **3**.

Insert 4 locking nuts **H** into shelf and fixed shelf where shown.

Use a screwdriver to turn locking nuts **H** clockwise to lock.







**Do not over tighten.**



**Attention!**  
Round edge on shelves must be facing front.

Insert horizontal front frame **12** into the right middle front frame **10**.

**Attention!**



# Assembly Instructions

## Step 10

### Fixing right side panel.


Two people are required for an easier assembly.

With help, place right side panel **1** properly ensuring dowels are all fit into their holes at the same time.

Insert 4 locking nuts **H** into base panel and fixed shelf where shown.

Use a screwdriver to turn locking nuts **H** clockwise to lock.

**Do not over tighten.**



## Step 11

### Fixing left side panel.



Two people are required for an easier assembly.

With help, place left side panel **2** properly ensuring dowels are all fit into their holes at the same time.

Insert 4 locking nuts **H** into base panel and shelf where shown.

Use a screwdriver to turn locking nuts **H** clockwise to lock.

**Do not over tighten.**




# Assembly Instructions

## Step 12

Place left middle front frame **11** properly ensuring dowels are all located into their holes. Attach left middle front frame to left shelf **20** using screw **E**.


Attach the block **28** in base panel **5** and to the horizontal front frame **12** using screws **D**.



## Step 13

Fix curved top rail **14** to the right front frame **8** and left front frame **9** using screws **C**.

Fix curved top rail **14** to the left middle front frame **11** using screws **C**.




# Assembly Instructions

## Step 14

Fix side top mouldings **24** to the sides using screws **D**.



**Attention:** Ensure top mouldings are fixed in the correct position in a height of **7mm** from the top edge of the side panels.




## Step 15

Fix curved top moulding **15** to the curved top rail using screws **F**.



**Note:** Make sure top moulding is aligned to the top rail and to the side mouldings.



# Assembly Instructions

## Step 16


### Fixing top panel.

Attach top panel **4** to the cabinet using screws **C** and middle wall panel using screws **D**.

Do not over tighten screws.




**Attention:** Make sure top panel is completely pushed against the top moulding before fixing.



## Step 17

Attach the block **28** in top panel **4** and curved top rail **14** using screws **D**.



# Assembly Instructions

## Step 18

**a:** Fix side plinths **25** to the side panels using screws **D**.



**Note:**


Make sure side plinths **25** are aligned to the bottom and front edges of the side panels.

**b:** Fix front plinth **16** to the bottom front frame using screws **D**.  
Chamfered edges to be facing up!



**Note:**

Make sure front plinth **16** is aligned to the bottom edge of the side panels and in line to the side plinths.




## Step 19

Fix metal studs **P** into the pre drilled holes in the front plinth.



**Important:**


After fixing the metal studs, with help, carefully stand the product upright.



# Assembly Instructions

## Step 20


Attach bottom support **27** to the base panel **5** using screws **F**.



## Step 21

Fitting hinges to the doors.

Attach hinges **L** to the pre drilled holes in the doors using screws **B**.



# Assembly Instructions

## Step 22

### Hanging doors.


**a:** With help, centralise the door in the opening of the cabinet using the door spacer **T** to ensure correct spacing, as shown.

**b:** Fix hinges using screws **B** as shown.




**Note:**


To ensure the alignment of the doors is correct, centralise the doors in the opening before attaching to the cabinet.



**a:**




**b:**



## Step 23

Attach handles **K** to the doors using bolts **J**.



# Assembly Instructions

## Step 24


### Hinge adjustment.

**a:** To move doors up or down: loosen screws shown and move doors to suit.


Once doors are aligned, re-tighten screws.

**b:** To move doors left or right: loosen screws shown and move doors to suit.


Re-tighten screws.



**a:**





**b:**



## Step 25

Insert hanging rail **23** into the supports.

Position shelves **22** into place. These are adjustable.




# Assembly Instructions

## Step 26

### Fitting door locks.


**a:** Screw clips **M** in place using screws **B**. Ensure that the 2 small wheels are flush with the edge of the base as shown in the diagram.



**b:** Insert plugs **N** into clips **M**, ensuring they are leveled as shown in the diagram.

**c:** Push the door against the plug **N**. This will make 2 small marks on the door as shown in the diagram.

**d:** The doors can then be opened and plugs **N** can be screwed into place using the 2 marks made as a guide. This will ensure that the 2 parts of the door clips are lined up correctly.



# Assembly Instructions

## Step 27

### Fixing back panels.


**Important:** Cabinet **MUST** be 'square' when back panels are attached. Make sure back panels are in flush with the edge of the top panel prior to fixing.

**a:** Attach the left back panel **7** first using nails **Q**.

**b:** Position profiles **13** and **26** onto back panel (just attach).

**c:** Carefully slot the second back panel **7** into the profile and fix it to the cabinet using nails **Q**.

**d:** Attach right back panel **6** using nails **Q**.





## Step 28

### Fixing to wall.

Furniture must be fixed to a wall. Fix wall strap **S** to top of furniture using washer **R** and screw **B**. With help, move furniture into position.

**Assembly is complete.**

**Note:** Wall plugs not supplied. The correct type of fixing must be used for your wall, seek professional advice if in doubt.



If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400 800**

# A Guide to - Wall Mounting & Fixings

## Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.



**Important:** When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


## Hints:

- 1: **General rule:**  Always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

## Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

### No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

### No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

### No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

### No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

### No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

### No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



## Care & Maintenance

**Safety:** Always check the fitting and location to ensure your safety in and around the home.

**Fitting:** From time to time check the fitting to ensure the wall plugs or screws do not become loose.