


San Diego - Slimline Console Table

Assembly Instructions - Please keep for future reference

343/7058



Dimensions

Width - 67cm

Depth - 29cm

Height - 80cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 13kgs. Please lift with care.
 - Check you have all the components and tools listed on pages 2 and 3.
 - Remove all fittings from the plastic bags and separate them into their groups.
 - Keep children and animals away from the work area, small parts could choke if swallowed.
 - Parts of the assembly will be easier with 2 people.
 - Make sure you have enough space to layout the parts before starting.
 - Do not stand or put weight on the product, this could cause damage.
 - Assemble the item as close to its final position (in the same room) as possible.
 - Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).
-
- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.
 - **Safety note:** It is recommended that this unit is secured to a wall using the overbalance kit supplied.
 - Dispose of all packaging carefully and responsibly.

Care and maintenance


- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Please check you have all the panels listed below




1 Left Side (DF2101)
(797 x 289mm)



2 Right Side (DF2102)
(797 x 289mm)




3 Top (DF2100)
(597 x 265mm)




4 Base (D2620A)
(597 x 280mm) x 2




5 Rail (D2621A)
(597 x 78mm) x 2



6 Drawer Front (DF2103)
(593 x 162mm)




7 Left Drawer Side (W260-124LH)
(260 x 124mm)




8 Right Drawer Side (W260-124RH)
(260 x 124mm)



9 Drawer Back (W564-124)
(564 x 124mm)



10 Drawer Base (T575-257)
(575 x 257mm)



11 Back (X663-156)
(663 x 156mm)
















Components - Fittings


If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Wooden dowel (F22) x 4	B  Metal dowel (F901) x 18	C  Small locking nut (F3) x 2
D  Large locking nut (F900) x 16	E  9mm Screw (F74) x 2	F  9mm Screw (F73) x 4
G  Knock-in Peg (F171) x 4	H  Nail (F51) x 10	I  Wedgefix (F639) x 4
J  Drawer runner (F307) x 2		K   Screw  Washer x 2 Overbalance protector kit (F269) x 1

Tools required



Rule



Cross-head screwdriver



Scissors



Hammer




Eye protection
(when using a
hammer or drill)



Electric drill
(only use when
drilling into walls)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Step 1

Prepare the drawer front

Screw 2 metal dowels **B** into the drawer front **6**.

Note: Tighten the metal dowels up fully against the panels.




Step 2

Prepare the drawer sides

Insert a small locking nut **C** into the hole shown on the left drawer side **7** and the right drawer side **8**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Step 3

Attach the drawer sides to the drawer front

Push the left drawer side **7** and right drawer side **8** onto the back of the drawer front **6**.

Turn the small locking nuts **C** on the left drawer side **7** and right drawer side **8**.

Note: Turn the locking nuts **C** clockwise to secure panels - more than 1/2 a turn.




Assembly Instructions

Step 4

Fit the drawer base

Slide the drawer base **10** down the grooves in the drawer sides **7** and **8** and down into the groove in the drawer front **6**.




Step 5

Fit the drawer back

Fit the drawer back **9** between the drawer sides **7** and **8**.

Make sure that the drawer base **10** fits into the groove in the drawer back **9**.



Hold the drawer back **9** in position and tap the knock-in pegs **G** through the holes in the drawer sides **7** and **8**.



Step 6

Fit the wedgifixes

Turn the drawer assembly over and slide 4 wedgifixes **I** into the front and back grooves, as shown, and tighten up the screws.



Assembly Instructions




Step 7

Prepare the left side

a: Screw 8 metal dowels **B** into the left side **1**.

a: Place a runner **J** on the left side **1**. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **F**.

c: Slide the runner **J** back the other way and fit the 2nd screw **F** into the corresponding hole in the left side **1**.



Assembly Instructions




Step 8

Prepare the right side

a: Screw 8 metal dowels **B** into the right side **2**.

a: Place a runner **J** on the right side **2**. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **F**.

c: Slide the runner **J** back the other way and fit the 2nd screw **F** into the corresponding hole in the right side **2**.




Assembly Instructions

Step 9

Prepare the 2 base panels

Insert 4 large locking nuts **D** into each of the 2 bases **4**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Step 10

Fit the 2 base panels to the right side

Push the 2 bases **4** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to each base **4**.


Note: Turn the large locking nuts **D** as far as they will go - more than 1/2 a turn.



Step 11

Prepare the top

Insert 4 large locking nuts **D** into the top **3**.




Assembly Instructions

Step 12

Fit the top

Push the top **3** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the top **3**.




Step 13

Prepare the 2 rails

Tap 2 wooden dowels **A** into each rail **5**.

Insert 2 large locking nuts **D** into each rail **5**.




Step 14

Fit the 2 rails

Push the rails **5** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the rails **5**.




Assembly Instructions

Step 15

Fit the left side

Push the left side **1** onto the assembly.

Use a screwdriver to tighten the 8 large locking nuts **D** fitted to the top **3**, the 2 bases **4** and the 2 rails **5**.



Step 16

Fit the back


a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

b: Place the back **11** onto the unit.

Nail **H** along the top and bottom edges of the back **11**.

Stand the unit up for the next step.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y



Warning: The unit is heavy. Lift with care.

Assembly Instructions

Step 17

Fit the drawer and the overbalance protector

Slide both the runners **J** forward and locate the drawer sides **8** and **9** between them, lining up the holes in the drawer wrap with the 2nd 'threaded' holes in the runners **J**.

Working from the inside of the drawer, insert 2 screws **E** through the drawer sides and out into the 2nd threaded hole in the runner.



To prevent possible overbalancing we recommend that this unit is secured to a suitable wall by use of the overbalance protector kit **K** fitted to the unit or, an alternative fixing method of your choice.

Wall fixings are not supplied as they will need to suit the wall type.

Note: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.

Assembly is complete

Example



If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800 and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW