
Sandford 3 Drawers Floor Cabinet

Assembly Instructions – Please keep for future reference

362/8726





Dimensions

Width - 35cm

Depth - 30cm

Height - 85.3cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800



Safety and care advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the panels, this could cause damage.
- Assemble the unit as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor.
- **Note:** Only apply the glue once you are sure of the assembly.
- The wall plugs supplied are suitable for solid walls only. It is important that the correct type of fixing is used for your wall, seek professional advice if in doubt.
- Parts of the assembly will be easier with 2 people.
- If using power tools, please follow the safety instructions supplied with the tools.



• We do not recommend the use of power drill/ drivers for inserting screws, as this could damage

the unit. Only use hand screwdrivers.

- *Warning:* Before drilling, check the wall for hidden pipes and cables.
- Dispose of all packaging carefully and responsibly.

Glue safety - Take care when using glue, please follow the advice below

Skin contact: Remove contamination by washing with soap and water. This procedure should also be followed prior to eating and drinking.

Eye contact: Rinse immediately with clean water for 15 minutes and seek medical advice.


If swallowed: Seek medical advice immediately. If possible show product information or label to the medical advisor.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: if required the next page can be cut out and used as a reference throughout the assembly. Keep this page with these instructions for future reference.

Please check you have all the panels listed below



14 Rail x 6

13 Drawer bottom x 3


Components - Fittings

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly . In some cases more fittings may be supplied than are required.

	B	(i.98)
Locking Pin x 32	Locking Nut x 32	Runner x 6
Ф4 x 12mm Screw x 24	Ф3 x 12mm Screw x 13	Ф4 x 30mm Screw x 12
	0	
Ф4 x 35mm Screw x 1	Wooden handle x 3	Ф4 x 25mm Screw x 6
0	R O Freeze	
Wall strap x 1	Wall plug(olny for solid wall)x 1	Screw cap x 6
Ф4 x 25mm Screw x 12		

Tools required



Phillips screwdriver (medium & large)



Flatblade screwdriver (medium)



6mm Suitable drill bit (for use with wall plug)



Hammer Drill (Only for dril hole on the wall)



Small hammer



Ruler/tape measure



Eye protection (when using a hammer or glue)

Ruler - Use this ruler to help correctly identify the screws

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

Step 1

Assembling side panels

a:

Screw locking pin (a) into left front leg 1 and left back leg 2.

Screw locking pin (A) into left side panel [5].

Attach left front leg and left back leg onto left side panel, Insert locking nut **B** into left side panel, and tighten the locking nut to secure the unit.


Repeat the above shep a to assembly other side unit as shown.


b:
Use 25mm screw


to fix rails


14

onto the left and right unit as shown.









Step 2

Assembling bottom panel

a:


Push the plastic tripper to separate the runner **©** to **©** & **©** as shown.

b:

Use 12mm screws **①** to fix runner **②** to the side panel **⑤**.

c: Attach left side panel and right side panel to bottom panle 8 .

Insert locking nut **B** into bottom panel **8** and tighten it to secure the unit.



Step 3

Assembling top panel


a:


Screw locking pin **A** onto top panel **7**, and fix wall strap **1** with 12mm screw **E** as shown.

b:

Carefully place the top panel 7 onto the unit.Insert locking nut **B** into left side panel and right side panel.

Tighten the locking nut to secure the unit.






Step 4

Assembling back panel

NOTE:It would be useful to ask someone to help you at this stage.

Use 12mm screws to fix back panels onto the unit as shown.

Pls make sure the wall strap go through the hole of back panel as shown.



Step 5

Assembling drawers

a:

Attach the drawer back panel 10 to drawer side panel 11 12 , fix it by 30mm screw .

b:

Carefully slide the drawer bottom 13 into the groove of the drawer sides.


Fix the wooden handle 1 to drawer front 9 by 25mm screw 1. Screw locking pin A into drawer front, attach the drawer front to the unit.


Insert locking nut **B** into drawer side panels as shown, tighten locking nuts clockwise to secure it.


C.

Use 12mm screw **①** to fix runner **⑥** to the drawer side panel 11 12 as shown.

Repeat the above sheps to assembly other drawers.







Step 6

Assembling drawers

NOTE:It would be useful to ask someone to help you at this stage.

Align the runner to to as shown carefully put the drawers into the unit.

Use screw caps **①** to cover the visible screws

NOTE:If you want to pull out the drawers, please push the left and right platice tripper at the same time as shown.


Step 7

Fix to wall

NOTE:It would be useful to ask someone to help you at this stage.

Use 35mm screw **(G)** and wall plug **(B)** to fix the unit on the wall via strap **(J)** as shown.

After above assembly, please double check and make sure all screws are firmly fixed before use.



NOTE:If you have damaged or missing components, call the Customer Helpline:08456 400800 Argos LTD,489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.



Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


Hints:

- 1: General rule: Always use a larger screw and wall plug if you are not sure.
- **2:** Ensure you use the recommended drill bit to match the wall plug and hole size.
- **3:** Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- **4:** Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- **5:** Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.



Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.