


# Sparkle - Dressing Table and Stool

Assembly Instructions - Please keep for future reference

406/9803

397/8689

424/1470



## Dimensions

Width - 100cm

Depth - 39.6cm

Height - 73.6cm



**MADE IN  
BRITAIN**

**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**



# Safety and Care Advice

**Important - Please read these instructions fully before starting assembly**

- **Warning:** This unit weighs approximately 30kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the overbalance protector kit supplied or, an alternative fixing method of your choice.

- Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


**Note:** If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

# Components - Panels


If you have damaged or missing components, call the **Customer Helpline: 03456 400800** quoting the reference numbers below

Please check you have all the panels listed below

## Dressing Table



**1** Left Side (DF3819)  
(72.1 x 37.2cm)



**2** Right Side (DF3820)  
(72.1 x 37.2cm)




**3** Divider (DF3826)  
(12.5 x 35.6cm) x 2



**5** Left Fascia (DF3824)  
(24.2 x 12.5cm)



**4** Rail (DF3828)  
(50.3 x 7.8cm)




**6** Right Fascia (DF3825)  
(24.2 x 12.5cm)




**7** Top (DF3821)  
(100 x 39.6cm)




**8** Modesty (DF3822)  
(96.6 x 24.4cm) x 2




**9** Drawer Front (DF3823)  
(49.6 x 12.2cm)



**10** Left Drawer Side (W350-95LH)  
(35 x 9.5cm)



**11** Right Drawer Side (W350-95RH)  
(35 x 9.5cm)




**12** Drawer Back (W469-95)  
(46.9 x 9.5cm)




**13** Drawer Base (T480-347)  
(48 x 34.7cm)


## Stool



**14** Stool Left Side (DF342A)  
(39.5 x 32.8mm)



**15** Stool Right Side (DF343A)  
(39.5 x 32.8mm)




**16** Stool Top (DF344A)  
(51 x 35.2mm)




**17** Stool Base (DF347A)  
(47.8 x 30.6mm)



**18** Stool Rail (DF346A)  
(47.8 x 16mm) x 2



**19** Stool Drawer Front (DF3833)  
(49.7 x 15.7mm)



**20** Stool Left Drawer Side (W300-124LH)  
(30 x 12.4mm)



**21** Stool Right Drawer Side (W300-124RH)  
(30 x 12.4mm)



**22** Stool Drawer Back (W445-124)  
(44.5 x 12.4mm)



**23** Stool Seat Pad (FHALPAD)  
(45.8 x 30mm)



**24** Stool Drawer Base (T456-297)  
(45.6 x 29.7mm)








# Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 03456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

|  |  |   |
|--|--|---|
| <p><b>A</b> </p> <p>Wooden dowel (F22) x 18</p>   | <p><b>B</b> </p> <p>Metal dowel (F901) x 38</p>   | <p><b>C</b> </p> <p>Small locking nut (F3) x 4</p> |
| <p><b>D</b> </p> <p>Large locking nut (F900) x 34</p>   | <p><b>E</b> </p> <p>Knock-in Peg (F171GY) x 8</p> | <p><b>F</b> </p> <p>Mini block (F25) x 4</p>       |
| <p><b>G</b> </p> <p>9mm Screw (F74) x 4</p>   | <p><b>H</b> </p> <p>9mm Screw (F73) x 8</p>       | <p><b>I</b> </p> <p>25mm Screw (F50) x 6</p>       |
| <p><b>J</b> </p> <p>Drawer runner (F1004) x 4</p>  |  | <p><b>K</b> </p> <p>Wedgefix (F639) x 4</p>       |
| <p><b>L</b> </p> <p>Plastic Nail (F91) x 8</p>  | <p><b>M</b> </p> <p>Handle (F437) x 1</p>       |   |
| <p><b>N</b>   Screw  Washer x 2</p> <p>Overbalance protector kit (F269) x 1</p> |  |   |

## Tools required



Rule



Cross-head screwdriver



Scissors



Hammer




Eye protection (when using a hammer or drill)



Electric drill (only use when drilling into walls)

Ruler - Use this ruler to help correctly identify the screws



# Assembly Instructions


If you have damaged or missing components, call the  
Customer Helpline: 03456 400800 quoting the reference  
numbers below

## Step 1

### Prepare the drawer front

Screw 2 metal dowels **B** into the drawer front **9**.

**Note:** Tighten the metal dowels up fully against the panels.




## The Dressing Table will be built 1st

## Step 2

### Prepare the drawer sides

Insert a small locking nut **C** into the hole shown on the left drawer side **10** and the right drawer side **11**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.




## Step 3

### Attach the drawer sides to the drawer front

Push the left drawer side **10** and right drawer side **11** onto the back of the drawer front **9**.

Turn the small locking nuts **C** on the left drawer side **10** and right drawer side **11**.

**Note:** Turn the locking nuts **C** clockwise to secure panels - more than 1/2 a turn.




# Assembly Instructions

## Step 4

### Fit the drawer base

Slide the drawer base **13** down the grooves in the drawer sides **10** and **11** and down into the groove in the drawer front **9**.




## Step 5

### Fit the drawer back

Fit the drawer back **12** between the drawer sides **10** and **11**. Make sure that the drawer base **13** fits into the groove in the drawer back **12**.

Hold the drawer back **12** in position and tap the knock-in pegs **E** through the holes in the drawer sides **10** and **11**.




## Step 6

### Attach the handle

Attach the handle **M** to the drawer front **9** using 2 screws **I**.



**Note: Do not overtighten the screw.**



## Step 7

### Fit the wedgifixes

Turn the drawer assembly over and slide 2 wedgifixes **K** into the front and back grooves, as shown, and tighten up the screws.



# Assembly Instructions

## Step 8

### Prepare the left side

Tap 2 wooden dowels **A** into the left side **1**.

**Note:** Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.


Screw 4 metal dowels **B** into the left side **1**.

**Note:** Tighten the metal dowels up fully against the panels.

Insert 2 large locking nuts **D** into the left side **1**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.

Gently tap a mini block **F** into the left side **1**, orientated as shown.



## Step 9


### Prepare the right side

Tap 2 wooden dowels **A** into the right side **2**.

Screw 4 metal dowels **B** into the right side **2**.

Insert 2 large locking nuts **D** into the right side **2**.

Gently tap a mini block **F** into the right side **2**, orientated as shown.




# Assembly Instructions

## Step 10

### Prepare the 2 modesty panels

Tap 4 wooden dowels **A** into each of the modesty panels **8**.

Insert 4 large locking nuts **D** into each of the modesty panels **8**.




## Step 11

### Join the 2 modesty panels to the left side

Push the 2 modesty panels **8** onto the left side **1**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to each modesty **8**.

**Note:** Turn the large locking nuts **D** as far as they will go - more than 1/2 a turn.



**Important:**  
The finished edges on the modesty panels must be facing each other


# Assembly Instructions

## Step 12

### Fit the right side

Push the right side **2** onto the 2 modesty panels **8**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to each modesty **8**.




## Step 13

### Prepare the rail

Insert 2 large locking nuts **D** into the rail **4**.

Tap 2 wooden dowels **A** into the rail **4**.



# Assembly Instructions

## Step 14

### Prepare the left divider

**a:** Place a runner **J** on 1 of the dividers **3**, as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **H**.

**b:** Slide the runner **J** back the other way and fit the 2nd screw **H** into the corresponding hole in the divider **3**.

**c:** Tap 2 wooden dowels **A** into the divider **3**.





Screw a metal dowel **B** into the divider **3**.

### Turn the divider over


**d:** Insert 2 large locking nuts **D** into the divider **3**.

**Note:** Due to the manufacturing process, the 2 holes for the large locking nuts can be on either surface of the divider.

Gently tap a mini block **F** into the divider **3**, orientated as shown.



**Turn the divider over**



# Assembly Instructions

## Step 15

### Prepare the right divider

**a:** Place a runner **J** on the divider **3** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **H**.

**b:** Slide the runner **J** back the other way and fit the 2nd screw **H** into the corresponding hole in the divider **3**.

**c:** Tap 2 wooden dowels **A** into the divider **3**.






Screw a metal dowel **B** into the divider **3**.

Insert 2 large locking nuts **D** into the divider **3**.

**Note:** Due to the manufacturing process, the 2 holes for the large locking nuts can be on either surface of the divider.

### Turn the divider over

**d:** Gently tap a mini block **F** into the divider **3**, orientated as shown.




# Assembly Instructions

## Step 16

### Join the rail to the dividers

Push the 2 dividers **3** onto the rail **4**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the rail **4**.




**Important:** The runners must be on the inside surface of the dividers.

**Remember:** The large locking nuts can be on either surface of the 2 dividers.

## Step 17

### Prepare the top

Screw 8 metal dowels **B** into the top **7**.




## Step 18

### Fit the dividers to the top

Lower the dividers **3** down onto the top **7**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted each divider **3**.



**Remember:** The large locking nuts can be on either surface of the 2 dividers.


# Assembly Instructions

## Step 19

### Fit the sides to the top

Lower the left side **1** and right side **2** down onto the top **7**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the left side **1** and right side **2**.




## Step 20

### Fit the fascia panels

Position the holes on the back surface of the left fascia **5** and right fascia **6** over the screws on the mini blocks **F**.

Tighten up the screws in the 4 mini blocks **F** into the holes in the fascia panels **5** and **6**.



**Note:** The right fascia has a shallow identification hole on its back surface.

# Assembly Instructions

## Step 21


### Fit the 4 plastic nails

Tap 2 plastic nails **L** into the bottom edge of each of the sides **1** and **2**.

**Carefully stand the unit up for the next step.**



**Warning:** The unit is heavy. Lift with care.



## Step 22

### Fit the drawer


Slide both the runners **J** forward and locate the drawer sides **10** and **11** between them, lining up the holes in the drawer wrap with the 2nd 'threaded' holes in the runners **J**.

Working from the inside of the drawer, insert 2 screws **G** through the drawer sides and out into the 2nd threaded hole in the runner.

**Note:** Do not overtighten the screws **G**.

If they catch on the runner you may need to loosen them slightly.

**The dressing table assembly is complete**




# Assembly Instructions

## Step 23

### Prepare the stool drawer front

Screw 2 metal dowels **B** into the stool drawer front **19**.




## Step 24

### Prepare the stool drawer sides

Insert a small locking nut **C** into the hole shown on the stool left drawer side **20** and stool right drawer side **21**.

**Note:** Arrow on locking nut **must** point towards hole in edge of panel.




## Step 25

### Attach the stool drawer sides to the stool drawer front

Push the stool left drawer side **20** and stool right drawer side **21** onto the back of the stool drawer front **19**.

Turn the small locking nuts **C** on the stool left drawer side **20** and stool right drawer side **21**.




# Assembly Instructions

## Step 26

### Fit the stool drawer base

Slide the stool drawer base **24** down the grooves in the stool drawer sides **20** and **21** and down into the groove in the stool drawer front **19**.




## Step 27

### Fit the stool drawer back

Fit the stool drawer back **22** down onto the stool drawer base **24**.

Make sure that the stool drawer base **24** fits into the groove in the stool drawer back **22**.



Hold the stool drawer back **22** in position and tap the knock-in pegs **E** through the holes in the stool drawer sides **20** and **21**.



## Step 28

### Fit the wedgexes

Turn the drawer assembly over and slide 2 wedgexes **K** into the front and back grooves, as shown, and tighten up the screws.




# Assembly Instructions

## Step 29

### Prepare the stool rails

Insert 4 large locking nuts **D** into each of the stool rails **18**.



## Step 30






### Prepare the stool left side

**a:** Place a runner **J** onto the stool left side **14**. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **H**.

**b:** Slide the runner **J** back the other way and fit the 2nd screw **H** into the corresponding hole in the stool left side **14**.

**c:** Screw 6 metal dowels **B** into the stool left side **14**.

**d:** Insert 2 large locking nuts **D** into the stool left side **14**.



# Assembly Instructions

## Step 31

### Prepare the stool right side


**a:** Place a runner **J** onto the stool right side **15**. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **H**.

**b:** Slide the runner **J** back the other way and fit the 2nd screw **H** into the corresponding hole in the stool right side **15**.


**c:** Screw 6 metal dowels **B** into the stool right side **15**.

**d:** Insert 2 large locking nuts **D** into the stool right side **15**.


**a:**




**b:**



**c:**



**d:**




# Assembly Instructions

## Step 32

### Fit a stool rail to the stool left side

Push a stool rail **18** onto the stool left side **14**.


Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the stool rail **18**.



## Step 33

### Prepare the stool base

Insert 4 large locking nuts **D** into the stool base **17**.




## Step 34

### Fit the stool base

Push the stool base **17** onto the stool left side **14**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the stool base **17**.




# Assembly Instructions

## Step 35

### Fit the other stool rail

Push the other stool rail **18** onto the stool left side **14**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the stool rail **18**.




## Step 36

### Fit the stool right side

Push the stool right side **15** onto the stool base **17** and the 2 stool rails **18**.


Use a screwdriver to tighten the 2 large locking nuts **D** fitted to each of the stool rails **18**.



## Step 37

### Secure the stool base

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the stool base **17**.




# Assembly Instructions

## Step 38

### Fit the 4 plastic nails

Tap 2 plastic nails **L** into the bottom edge of each of the stool sides **14** and **15**.


**Stand the stool up for the next step.**



## Step 39

### Prepare the stool top

Screw 4 metal dowels **B** into the stool top **16**.




## Step 40

### Fit the stool seat pad

Fit the stool seat pad **23** to the stool top **16** using 4 screws **I**.

**Note:** Make sure that it is fitted centrally and you screw into the hard surface of the stool seat pad.




# Assembly Instructions

## Step 41

### Fit the stool top

Lower the stool top **16** down onto the assembly.

Use a screwdriver to tighten the 4 large locking nuts **D** fitted to the stool left side **14** and stool right side **15**.





## Step 42

### Fit the stool drawer

Slide both the runners **J** forward and locate the drawer sides **20** and **21** between them, lining up the holes in the drawer sides with the 2nd 'threaded' holes in the runners **J**.

Working from the inside of the drawer, insert 2 screws **G** through the drawer sides and out into the 2nd threaded hole in the runner.

**Note:** Do not overtighten the screws **G**. If they catch on the runner you may need to loosen them slightly.



# Assembly Instructions

## Step 43

### Fit the overbalance protector



To prevent possible overbalancing we recommend that the dressing table is secured to a suitable wall by use of the overbalance protector kit **N** fitted to the unit or, an alternative fixing method of your choice.

Wall fixings are not supplied as they will need to suit the wall type.

**Note:** Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.

**Assembly is complete**

### Example



If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400800 and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

