


Sparkle - 1 Drawer 3 Door Robe

Assembly Instructions - Please keep for future reference

408/5935

425/5954

397/9468



Dimensions

Width - 105.1cm

Depth - 51.6cm

Height - 182.3cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• **Warning:** This unit weighs approximately 72kgs. Please lift with care.

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Parts of the assembly will be easier with 2 people.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



• We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

• **Safety note:** It is recommended that this unit is secured to a wall using the overbalance protector kit supplied or, an alternative fixing method of your choice.

• Dispose of all packaging carefully and responsibly.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Components - Panels

If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)


Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020


Please check you have all the panels listed below




1 Drawer Front (DF3872)
(69.3 x 16.2cm)



2 Left Drawer Side (W370-124LH)
(37 x 12.4cm)




3 Right Drawer Side (W370-124RH)
(37 x 12.4cm)




4 Drawer Back (W636-124)
(63.6 x 12.4cm)



5 Drawer Base (T647-367)
(64.7 x 36.7cm)



6 Top (DF3844)
(105.1 x 51.6cm)



7 Base (DF3846)
(101.7 x 49.3cm)


Components - Panels

If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)


Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020

Please check you have all the panels listed below



8 Left Side (DF4402)
(180.8 x 49.4cm)



9 Right Side (DF3838)
(180.8 x 49.4cm)



10 Divider (DF4401)
(171.25 x 49.2cm)



11 Horizontal (DF3871)
(66.9 x 49.1cm)



12 Shelf (DF3848)
(33.3 x 45cm) x 3



13 Large Rail (DF3840)
(66.9 x 8cm)




14 Plinth (DF3845)
(101.7 x 8cm)




15 Small Rail (DF4400)
(33.3 x 8cm)




16 Hanging Rail (FHR663)
(66.3cm long)




17 Left Door
(DF3870)
(155.9 x 34.5cm)




18 Middle Door
(DF4456)
(155.9 x 34.5cm)



19 Right Door
(DF3842)
(172.4 x 34.5cm)



20 Small Back
(X1739-352)
(173.9 x 35.2cm)



21 Large Back
(X1739-688)
(173.9 x 68.8cm)



Components - Fittings

























If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020


Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Metal dowel (F901) x 20	B  Large locking nut (F900) x 20	C  Small locking nut (F3) x 2
D  40mm Screw (F910) x 2	E  25mm Screw (F50) x 12	F  13mm Screw (F63) x 24
G  9mm Screw (F74) x 2	H  9mm Screw (F73) x 4	I  Wooden dowel (F22) x 20
J  Knock-in Peg (F171GY) x 4	K  Plastic Nail (F91) x 4	L  Nail (F51) x 40
M  Large wooden dowel (F40) x 1	N  Double metal dowel (F566) x 1	O  Rail Holder (F891) x 2
P  Nail screw (F277) x 5	Q  Back holder (F276) x 5 *These can also be round	R  Shelf stud (F110) x 12
S  Wedgefix (F639) x 4	T  Hinge plate (F523) x 10	U  Hinge (F522) x 10
V  Drawer runner (F1004) x 2	W  Handle (F569) x 4	X  Strap Screw Washer x 2
Tools required Eye protection / Electric drill / Step ladder Scissors / Rule / Square / Spirit level / Hammer / Cross-head screwdriver		Overbalance protector kit (F269) x 1

Assembly Instructions

Ruler - Use this ruler to help correctly identify the screws




Step 1

Prepare the drawer front

Screw 2 metal dowels **A** into the drawer front **1**.

Note: Tighten the metal dowels up fully against the panels.




Step 2

Prepare the drawer sides

Insert a small locking nut **C** into the hole shown on the left drawer side **2** and the right drawer side **3**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Step 3


Attach the drawer sides to the drawer front

Push the left drawer side **2** and right drawer side **3** onto the back of the drawer front **1**.

Turn the small locking nuts **C** on the left drawer side **2** and right drawer side **3**.



Note: Turn the locking nuts clockwise to secure panels - more than 1/2 a turn.




Assembly Instructions

Step 4

Fit the drawer base

Slide the drawer base **5** down the grooves in the drawer sides **2** and **3** and down into the groove in the drawer front **1**.




Step 5

Fit the drawer back

Fit the drawer back **4** between the drawer sides **2** and **3**. Make sure that the drawer base **5** fits into the groove in the drawer back **4**.

Hold the drawer back **4** in position and tap the knock-in pegs **J** through the holes in the drawer sides **2** and **3**.




Step 6

Attach the handles

Attach a handle **W** to the drawer front **1** using 3 screws **E**.



Note: Do not overtighten the screw.



Step 7

Fit the wedgifixes

Turn the drawer assembly over and slide 4 wedgifixes **S** into the front and back grooves, as shown, and tighten up the screws.






Assembly Instructions

Step 8

Prepare the left side

a: Place a runner **V** on the left side **8** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **H**.

b: Slide the runner **V** back the other way and fit the 2nd screw **H** into the corresponding hole in the left side **8**.



Assembly Instructions

Step 9

Finish preparing the left side

a: Screw 6 metal dowels **A** into the left side **8**.

Note: Tighten the metal dowels up fully against the panels.

Insert 2 large locking nuts **B** into the left side **8**.








Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.

Tap 2 wooden dowels **I** into the left side **8**.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.

b: To fit the rail holder **O** screw through the top hole with screw **F** and into the mark hole drilled in the left side **8**. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **F** using the lower hole.

Fit 3 hinge plates **T** onto the left side **8**, making sure that the slot is facing towards the finished front edge.



Assembly Instructions

Step 10



Prepare the right side

a: Screw 4 metal dowels **A** into the right side **9**.

Insert 2 large locking nuts **B** into the right side **9**.

Tap 2 wooden dowels **I** into the right side **9**.

b: Fit 4 hinge plates **T** onto the right side **9**, making sure that the slot is facing towards the finished front edge.




Step 11

Prepare the base

Insert 4 large locking nuts **B** into the base **7**.

Tap 4 wooden dowels **I** into the base **7**.



Assembly Instructions


Step 12

Fit the base to the right side

Push the base **7** onto the right side **9**.

Use a screwdriver to tighten the 2 large locking nuts **B** fitted to the base **7**.

Note: Turn the large locking nuts **B** as far as they will go - more than 1/2 a turn.




Step 13


Prepare the divider

a: Place a runner **V** on the divider **10** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **H**.


b: Slide the runner **V** back the other way and fit the 2nd screw **H** into the corresponding hole in the divider **10**.



a:



b:



Assembly Instructions

Step 14

Finish preparing the divider


Screw 2 metal dowels **A** into the divider **10**.

Insert 2 large locking nuts **B** into the divider **10**.

Tap 4 wooden dowels **I** into the divider **10**.

To fit the rail holder **O** screw through the top hole with screw **F** and into the mark hole drilled in the divider **10**. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **F** using the lower hole.

Fit 3 hinge plates **T** onto the divider **10**, making sure that the slot is facing towards the finished front edge.




Step 15

Prepare the horizontal

Insert 4 large locking nuts **B** into the horizontal **11**.

Tap 4 wooden dowels **I** into the horizontal **11**.




Assembly Instructions

Step 16

Fit the horizontal to the divider

Push the horizontal **11** onto the divider **10**.

Use a screwdriver to tighten the 2 large locking nuts **B** fitted to the horizontal **11**.




Step 17

Prepare the small rail

Insert 2 large locking nuts **B** into the small rail **15**.

Tap a wooden dowel **I** into the small rail **15**.




Step 18

Fit the small rail

Push the small rail **15** onto the right side **9**.

Use a screwdriver to tighten the large locking nut **B** fitted to the small rail **15**.



Note: Support the small rail until the divider has been fitted in the next step.

Assembly Instructions

Step 19


Fit the divider

a: Push the divider **10** onto the base **7** and attach it using 2 screws **D**.

b: Tap a double metal dowel **N** through the divider **10** and into the small rail **15** until it "bottoms out".

Tap a large wooden dowel **M** through the divider **10** and into the small rail **15** until it "bottoms out".

c: Use a screwdriver to tighten the large locking nut **B** fitted to the small rail **15**.




Step 20

Prepare the plinth

Insert 2 large locking nuts **B** into the plinth **14**.

Tap 2 wooden dowels **I** into the plinth **14**.




Assembly Instructions

Step 21

Fit the plinth

Push the plinth **14** onto the right side **9**.

Use a screwdriver to tighten the large locking nut **B** fitted to the plinth **14**.




Step 22

Prepare the large rail

Insert 2 large locking nuts **B** into the large rail **13**.

Tap a wooden dowel **I** into the large rail **13**.




Step 23

Fit the large rail

Push the large rail **13** onto the divider **10**.

Use a screwdriver to tighten the large locking nut **B** fitted to the large rail **13**.



Note: Support the large rail until the left side has been fitted in the next step.


Assembly Instructions

Step 24

Fit the left side

Push the left side **8** onto the assembly.


Use a screwdriver to tighten the 6 large locking nuts **B** fitted to the base **7**, the horizontal **11**, the plinth **14** and the large rail **13**.



Step 25

Prepare the top

Screw 6 metal dowels **A** into the top **6**.



Assembly Instructions


Step 26

Fit the top

Note: To make it easier to fit the top, place polystyrene blocks from the packaging underneath the side and divider panels to raise the assembly.

Push the top **6** onto the assembly.


Use a screwdriver to tighten the 2 large locking nuts **B** fitted to the left side **8**, the right side **9** and the divider **10**.



Step 27

Fit the 4 plastic nails

Tap 2 plastic nails **K** into the bottom edge of each of the sides **8** and **9**.



Assembly Instructions

Step 28

Fit the 2 back panels

a: Square up the unit by making sure that measurement **x:x** equals **y:y**.

Place the small back **[20]** and large back **[21]**, coloured surface facing down, onto the unit as shown.

Make sure that the 2 backs are pushed up tight against each other and that they meet in the centre of the divider's back edge.

b: Nail **[L]** around the outside edges of the 2 backs.


Note: Do not nail where the 2 backs meet.

c: Push the nail screws **[P]** through the back holders **[Q]** and tap them down between the small back **[20]** and large back **[21]** and into the back edge of the divider **[10]**.

Keep tapping the nail screws **[P]** in until the back holders **[Q]** dig into the small and large back.


Stand the unit up for the next step.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y



Warning: The unit is heavy. Lift with care.

Note: If ever you need to take the backs off to dismantle the unit, the nail screws can be taken out using a screwdriver.



Assembly Instructions


Step 29

Fit the hanging rail and shelves

Push the hanging rail **16** into the rail holders **O** fitted to the side panels.

For each of the 3 shelves **12**, insert 4 shelf studs **R**.

Lower the 3 shelves **12** down onto the shelf studs **R**.




Step 30

Fit the drawers

Slide both the runners **V** forward and locate the drawer sides **2** and **3** between them, lining up the holes in the drawer wrap with the 2nd 'threaded' holes in the runners **V**.

Working from the inside of the drawer, insert 2 screws **G** through the drawer sides and out into the 2nd threaded hole in the runner.

Note: Do not overtighten the screws **G**. If they catch on the runner you may need to loosen them slightly.



Assembly Instructions


Step 31

Prepare the right door

Push fit 4 hinges **U** into the right door **19**.

Secure each hinge with 2 screws **F**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the edge of the door.




Step 32

Prepare the left door and middle door

Push fit 3 hinges **U** into the left door **17** and middle door **18**.

Secure each hinge with 2 screws **F**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the edge of the door.



Assembly Instructions

Step 33

Fit doors and handles

Note: The easiest way to attach each door **17**, **18** and **19** is to fit the top hinge first, then align and fit the other hinges.


a: Push the hinge **U** onto the front part of the hinge plate **T**.
The recess at the bottom of screw B goes into the slot in the hinge plate.

b: Keep the hinge **U** FLAT against the hinge plate **T** as you slide it across as far as it will go. Tighten screw A.


c: The hinge **U** must be flat against the hinge plate **T** prior to any adjustment.

d: The hinge **U** must NOT be AT AN ANGLE to the hinge plate **T** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **W** to each door **17**, **18** and **19** using 3 screws **E**.



Note: The middle door has a small identification hole.



Assembly Instructions

Step 34

Adjust the doors if needed

a: Before adjusting the doors, use a spirit level to check the base (or top) of the unit is level, front-to-back and side-to-side in the 3 positions shown. Use suitable packing pieces (not supplied) to make the unit level BEFORE making any adjustment to the hinges, as shown.

b: Height adjustment.


Loosen screws A on hinge plates and move door up or down as required. Retighten screw A.

c: Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required. Retighten screw B.

d: Sideways adjustment.

To move door 'out' loosen screw C. To move door 'in' tighten screw C.



Assembly Instructions

Step 35


Fit the overbalance protector

To prevent possible overbalancing we recommend that this unit is secured to a suitable wall by fitting of the overbalance protector kit **(X)** to the unit, or an alternative fixing method of your choice.

Wall fixings are not supplied as they will need to suit the wall type.

Note: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.

Assembly is complete



If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)
Alternatively, call the Spares Helpline on: 0370 112 1928.
For any other queries please contact the Customer Helpline on: 0345 640 2020

