


Winchester - Coffee Table

Assembly Instructions - Please keep for future reference

408/5571



Dimensions

Width - 99.6cm

Depth - 49.5cm

Height - 46.6cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 29kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings (not supplied).

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)


Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020


Please check you have all the panels listed below



1 Left Side (DF2796)
(44.4 x 45.5cm)




2 Right Side (DF2797)
(44.4 x 45.5cm)



3 Divider (DF2799)
(19.8 x 45.1cm)




4 Top (DF3356)
(99.6 x 49.5cm)



5 Shelf (DF2798)
(92.6 x 45.3cm)




6 Rail (DF2791)
(92.6 x 9cm) x 4




7 Front Plinth (DF2792)
(98.8 x 9.2cm) x 2



8 Side Plinth (DF2800)
(45.5 x 9.1cm) x 2



9 Back (DF2801)
(45.55 x 19.8cm) x 2



10 Drawer Front (DF2787)
(44.9 x 19cm) x 2



11 Left Drawer Side (W370-124LH)
(37 x 12.4cm) x 2



12 Right Drawer Side (W370-124RH)
(37 x 12.4cm) x 2



13 Drawer Back (W370-124)
(42.3 x 12.4cm) x 2



14 Drawer Base (T434-367)
(43.4 x 36.7cm) x 2



Components - Fittings















If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.


For any other queries please contact the Customer Helpline on: 0345 640 2020

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Metal dowel (F901) x 26</p>	<p>B </p> <p>Large locking nut (F900) x 22</p>	<p>C </p> <p>Small locking nut (F3) x 4</p>
<p>D </p> <p>Wooden dowel (F22) x 26</p>	<p>E </p> <p>Large wooden dowel (F40) x 2</p>	<p>F </p> <p>Wedgefix (F639) x 4</p>
<p>G </p> <p>38mm Screw (F81) x 2</p>	<p>H </p> <p>25mm Screw (F50) x 8</p>	<p>I </p> <p>9mm Screw (F74) x 4</p>
<p>J </p> <p>9mm Screw (F73) x 8</p>	<p>K </p> <p>Knock-in Peg (F171GY) x 8</p>	<p>L </p> <p>Plastic Nail (F91) x 4</p>
<p>M </p> <p>Drawer runner (F1004) x 4</p>		<p>N </p> <p>Handle (F463) x 2</p>

Tools required



Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Prepare the 2 drawer fronts

Screw 2 metal dowels **A** into each of the drawer fronts **10**.

Note: Tighten the metal dowels up fully against the panels.




Step 2

Prepare the drawer sides

Insert a small locking nut **C** into the hole shown on the left drawer side **11** and the right drawer side **12**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Step 3

Attach the drawer sides to the drawer fronts

Push the left drawer sides **11** and right drawer sides **12** onto the back of the drawer fronts **10**.

Turn the small locking nuts **C** on the left drawer side **11** and right drawer side **12**.

Note: Turn the locking nuts **C** clockwise to secure panels - more than 1/2 a turn.




Assembly Instructions

Step 4

Fit the drawer base

Slide the drawer base **14** down the grooves in the drawer sides **11** and **12** and down into the groove in the drawer front **10**.




Step 5

Fit the drawer back

Fit the drawer back **13** between the drawer sides **11** and **12**. Make sure that the drawer base **14** fits into the groove in the drawer back **13**.

Hold the drawer back **13** in position and tap the knock-in pegs **K** through the holes in the drawer sides **11** and **12**.




Step 6

Attach the handles

Attach a handle **N** to each of the drawer fronts **10** using screw **G**.


Note: Do not overtighten the screw.



Step 7

Fit the wedgifixes

Turn the drawer assemblies over and slide 2 wedgifixes **F** into the front and back grooves, as shown, and tighten up the screws.



Assembly Instructions

Step 8

Prepare the left side

a: Place a runner **M** on the left side **1** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **J**.

b: Slide the runner **M** back the other way and fit the 2nd screw **J** into the corresponding hole in the left side **1**.





c: Screw 6 metal dowels **A** into the left side **1**.

Insert 2 large locking nuts **B** into the left side **1**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.

Tap 2 wooden dowels **D** into the left side **1**.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.



Assembly Instructions

Step 9

Prepare the right side





a: Place a runner **M** on the right side **2** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **J**.

b: Slide the runner **M** back the other way and fit the 2nd screw **J** into the corresponding hole in the right side **2**.

c: Screw 6 metal dowels **A** into the right side **2**.

Insert 2 large locking nuts **B** into the right side **2**.

Tap 2 wooden dowels **D** into the right side **2**.



Assembly Instructions


Step 10

Prepare the shelf

Screw 2 metal dowels **A** into the shelf **5**.

Insert 4 large locking nuts **B** into the shelf **5**.

Tap 4 wooden dowels **D** into the shelf **5**.




Step 11

Fit the shelf

Push the shelf **5** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **B** fitted to the shelf **5**.

Note: Turn the large locking nuts **B** as far as they will go - more than 1/2 a turn.



Assembly Instructions

Step 12

Prepare the divider

a: Place a runner **M** on the divider **3** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **J**.

b: Slide the runner **M** back the other way and fit the 2nd screw **J** into the corresponding hole in the divider **3**.




Tap 2 wooden dowels **D** into the divider **3**.

Turn the divider over


c: Place a runner **M** on the divider **3** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **J**.

b: Slide the runner **M** back the other way and fit the 2nd screw **J** into the corresponding hole in the divider **3**.



Insert 2 large locking nuts **B** into the divider **3**.



Note: Due to the manufacturing process, the 2 holes for the large locking nut can be on either surface of the divider.



Turn the divider over




Step 13

Fit the divider

Push the divider **3** onto the shelf **5**.

Use a screwdriver to tighten the large locking nut **B** fitted to the divider **3**.




Note: The 2 large locking nuts can be on either surface of the divider.

Assembly Instructions

Step 14

Prepare 1 back

Tap 2 wooden dowels **D** into a back **9**.




Step 15

Fit the back

Push the back **9** onto the right side **2**.


Note: Support the back until it is secured in the next step.



Step 16

Secure the back


Gently tap 2 long wooden dowels **E** through the divider **3** and into the back **9** until they "bottom out".



Step 17

Prepare the other back

Tap 2 wooden dowels **D** into the back **9**.




Assembly Instructions

Step 18

Prepare the 4 rails

Insert 2 large locking nuts **B** into each of the rails **6**.

Tap 2 wooden dowels **D** into each of the rails **6**.




Step 19

Fit the back

Push the back **9** onto the divider **3**.

Note: Support the back until the left side has been fitted.




Step 20

Fit the 4 rails

Push the rails **6** onto the right side **2**.

Use a screwdriver to tighten the 4 large locking nuts **B** fitted to the rails **6**.

Note: Support the rails until the left side has been fitted.




Assembly Instructions

Step 15

Fit the left side

Push the left side **1** onto the assembly.


Use a screwdriver to tighten the 6 large locking nuts **B** fitted to the shelf **5** and the 4 rails **6**.



Step 18

Prepare the top

Screw 4 metal dowels **A** into the top **4**.




Step 18

Fit the top

Note: To make it easier to fit the top and plinths, place polystyrene blocks from the packaging underneath the side panels to raise the assembly.

Push the top **4** onto the assembly.

Use a screwdriver to tighten the 4 large locking nuts **B** fitted to the sides **1** and **2**.



Warning: The unit is heavy. Lift with care.


Assembly Instructions

Step 24

Prepare the 2 side plinths

Insert 2 large locking nuts **B** into each of the 2 side plinths **8**.


Tap 2 wooden dowels **D** into each of the 2 side plinths **8**.



Step 25

Prepare the 2 front plinths

Screw 2 metal dowels **A** into each of the 2 front plinths **7**.




Step 26

Fit the plinths together

Push the 2 side plinths **8** onto the 2 front plinths **7**.

Use a screwdriver to tighten the 4 large locking nuts **B** fitted to the 2 side plinths **8**.




Assembly Instructions

Step 27

Fit the plinths

Position the 4 plinths over the assembly ensuring that the bottom edge of the plinths are flush with the bottom edge of the sides, as shown.


Secure the 2 side plinths **8** through the left end **1** and right end **2** using 4 screws **H**.



Step 28

Secure the 2 front plinths

Secure the 2 front plinths **7** through the 2 rails **6** using 4 screws **H**.



Step 29


Fit the 4 plastic nails

Tap 2 plastic nails **L** into the bottom edge of each of the sides **1** and **2**.

Carefully stand the unit up for the next step.



Warning: The unit is heavy. Lift with care.



Assembly Instructions

Step 30

Fit the drawers



Slide both the runners **M** forward and locate the drawer sides **11** and **12** between them, lining up the holes in the drawer wrap with the 2nd 'threaded' holes in the runners **M**.

Working from the inside of the drawer, insert 2 screws **I** through the drawer sides and out into the 2nd threaded hole in the runner.

Note: Do not overtighten the screws **I**.

If they catch on the runner you may need to loosen them slightly.

Assembly is complete



If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)
Alternatively, call the Spares Helpline on: 0370 112 1928.
For any other queries please contact the Customer Helpline on: 0345 640 2020