


Eden - Small Side Table

Assembly Instructions - Please keep for future reference

414/1594

414/4962



Dimensions

Width - 47.5cm

Depth - 38cm

Height - 51cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 10kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings (not supplied).

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the
Customer Helpline: 03456 400800 quoting the reference
numbers below


Please check you have all the panels listed below




1 Left End (DF3748)
(475 x 378mm)




2 Right End (DF3749)
(475 x 378mm)




3 Top (DF3750)
(475 x 381mm)




4 Base (DF3751)
(399 x 372mm)



5 Drawer Front (DF3752)
(393 x 194mm)




6 Drawer Back (W366-165)
(366 x 165mm)




7 Left Drawer Side (W350-165LH)
(350 x 165mm)



8 Right Drawer Side (W350-165RH)
(350 x 165mm)



9 Drawer Base (T378-347)
(378 x 347mm)



10 Back (X452-417)
(452 x 417mm)















Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 03456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Metal dowel (F901) x 2</p>	<p>B </p> <p>Small locking nut (F3) x 2</p>	<p>C </p> <p>Knock-in Peg (F171GY) x 4</p>
<p>D </p> <p>Small metal dowel (F893) x 8</p>	<p>E </p> <p>Hollow core locking nut (F892) x 8</p>	<p>F </p> <p>19mm Screw (F461) x 2</p>
<p>G </p> <p>9mm Screw (F74) x 2</p>	<p>H </p> <p>9mm Screw (F73) x 4</p>	<p>I </p> <p>Wedgefix (F639) x 2</p>
<p>J </p> <p>Nail (F51) x 12</p>	<p>K </p> <p>Drawer runner (F1004) x 2</p>	
<p>L </p> <p>Handle (F414) x 1</p>		

Tools required



Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


If you have damaged or missing components, call the
Customer Helpline: 03456 400800 quoting the reference
numbers below

Step 1

Prepare the drawer front

Screw 2 metal dowels **A** into the drawer front **5**.

Note: Tighten the metal dowels up fully against the panels.




Step 2

Prepare the drawer sides

Insert a small locking nut **B** into the hole shown on the left drawer side **7** and the right drawer side **8**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Step 3

Attach the drawer sides to the drawer front

Push the left drawer side **7** and right drawer side **8** onto the back of the drawer front **5**.

Turn the small locking nuts **B** on the left drawer side **7** and right drawer side **8**.

Note: Turn the locking nuts **B** clockwise to secure panels - more than 1/2 a turn.




Assembly Instructions

Step 4

Fit the drawer base

Slide the drawer base **9** down the grooves in the drawer sides **7** and **8** and down into the groove in the drawer front **5**.




Step 5

Fit the drawer back

Fit the drawer back **6** between the drawer sides **7** and **8**. Make sure that the drawer base **9** fits into the groove in the drawer back **6**.


Hold the drawer back **6** in position and tap the knock-in pegs **C** through the holes in the drawer sides **7** and **8**.



Step 6

Attach the handle



Attach the handle **L** to the drawer front **5** using screws **F**.



Step 7

Fit the wedgfixes

Turn the drawer assembly over and slide 2 wedgfixes **I** into the front and back grooves, as shown, and tighten up the screws.



Assembly Instructions

Step 8

Prepare the left end

a: Place a runner **K** on the left end **1** as shown. Slide back the top of runner and use the 1st hole from the front to fit the 1st screw **H**.






b: Slide the runner **K** back the other way and fit the 2nd screw **H** into the corresponding hole in the left end **1**.

c: Push 2 hollow core locking nuts **E** into the left end **1**, making sure that they are flush against the panel's surface.

Using a hammer, tap in the pin on the hollow core locking nut **E**.

Note: The pin should be tapped in flush with the top surface of the hollow core locking nut **E**.

Screw 2 small metal dowels **D** into the left end **1**.



Assembly Instructions

Step 9

Prepare the right end

a: Place a runner **K** on the right end **2** as shown. Slide back the top of runner and use the 1st hole from the front to fit the 1st screw **H**.


b: Slide the runner **K** back the other way and fit the 2nd screw **H** into the corresponding hole in the right end **2**.

c: Push 2 hollow core locking nuts **E** into the right end **2**, making sure that they are flush against the panel's surface.


Using a hammer, tap in the pin on the hollow core locking nut **E**.

Note: The pin should be tapped in flush with the top surface of the hollow core locking nut **E**.


Screw 2 small metal dowels **D** into the right end **2**.




a:



b:



c:




Assembly Instructions

Step 10

Prepare the base

Push 4 hollow core locking nuts **E** into the base **4**, making sure that they are flush against the panel's surface.

Using a hammer, tap in the pin on the hollow core locking nut **E**.




Step 11

Fit the base to the right end

Push the base **4** onto the right end **2**.

The 2 small metal dowels **D** fitted to the right end **2** must slide into the top of the 2 hollow core locking nuts **E** fitted to the base **4**.

Insert a screwdriver into the 2 hollow core locking nuts **E** and turn the nuts inside as far as they will go.




Step 12

Fit the left side

Push the left end **1** onto the base **4**.

The 2 small metal dowels **D** fitted to the left end **1** must slide into the top of the 2 hollow core locking nuts **E** fitted to the base **4**.

Insert a screwdriver into the 2 hollow core locking nuts **E** and turn the nuts inside as far as they will go.




Assembly Instructions

Step 13

Prepare the top

Screw 4 small metal dowels **D** into the top **3**.




Step 14

Fit the top

Push the top **3** onto the assembly.

The 4 small metal dowels **D** fitted to the top **3** must slide into the top of the 4 hollow core locking nuts **E** fitted to the ends **1** and **2**.

Insert a screwdriver into the 4 hollow core locking nuts **E** and turn the nuts inside as far as they will go.



Step 15

Fit the back

a: Square up the unit by making sure that measurement **x** to **x** equals **y** to **y**.


b: Place the back **10** onto the unit.

Nail **J** around the outside edges of the back **10**.

Note: Nails should be spaced about 150mm apart.

Stand the unit up for the next step.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y



Assembly Instructions

Step 16



Fit the drawers

Slide both the runners **K** forward and locate the drawer sides **7** and **8** between them, lining up the holes in the drawer wrap with the 2nd 'threaded' holes in the runners **K**.

Working from the inside of the drawer, insert 2 screws **G** through the drawer sides and out into the 2nd threaded hole in the runner.

Note: Do not overtighten the screws **G**. If they catch on the runner you may need to loosen them slightly.

Assembly is complete



If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800** and quote the reference numbers on the component pages.
Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

