


Newport - Chest Pack

Assembly Instructions - Please keep for future reference

245/8409

249/3842

418/3497



2 Drawer Chest Dimensions

Width - 65.5cm
Depth - 35.5cm
Height - 57.5cm

Bedside Chest Dimensions

Width - 35.5cm
Depth - 35.5cm
Height - 41cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 22.5kgs. Please lift with care.
- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Parts of the assembly will be easier with 2 people.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



• We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

• **Safety note:** It is recommended that the 2 Drawer Chest is secured to a wall using the bracket supplied.

• Dispose of all packaging carefully and responsibly.

Care and maintenance


- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels


If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the panels listed below


Drawer Panels




1 Left Drawer Side (W320-124LH)
(320 x 124mm) x 3



2 Right Drawer Side (W320-124RH)
(320 x 124mm) x 3



3 Small Drawer Front (DF276B)
(315 x 162mm)



4 Large Drawer Front (DF282B)
(615 x 162mm) x 2




5 Small Drawer Back (W286-124)
(286 x 124mm)



6 Large Drawer Back (W586-124)
(586 x 124mm) x 2



7 Small Drawer Base (T297-317)
(297 x 317mm)




8 Large Drawer Base (T597-317)
(597 x 317mm) x 2

Components - Panels


If you have damaged or missing components, call the
Customer Helpline: 03456 400800 quoting the reference
numbers below

Please check you have all the panels listed below


Bedside Chest Panels




9 Left End (DF272)
(395 x 351mm)




10 Right End (DF273)
(395 x 351mm)



11 Top (DF274)
(355 x 352mm)



12 Fixed Shelf (DF275)
(319 x 325mm)




13 Plinth (DF278)
(319 x 65mm)




14 Back (X345-182)
(345 x 182mm)


2 Drawer Chest Panels




15 Left End (DF420)
(560 x 351mm)



16 Right End (DF421)
(560 x 351mm)




17 Top (DF281)
(655 x 352mm)



18 Plinth (DF284)
(619 x 65mm) x 2



19 Fixed Shelf (DF422)
(619 x 325mm)



20 Back (X645-532)
(645 x 532mm)














Components - Fittings


If you have damaged or missing components, call the
Customer Helpline: 03456 400800 quoting the reference
numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

| | | |
|---|--|--|
| A  Wooden dowel (F22) x 6 | B  Metal dowel (F901) x 28 | C  Small locking nut (F3) x 6 |
| D  Large locking nut (F900) x 22 | E  25mm Screw (F50) x 5 | F  Handle (F314) x 5 |
| G  Nail (F51) x 22 | H  Plastic Nail (F91) x 8 | I  Knock-in Peg (F171GY) x 12 |
| J  Wedgex (F639) x 10 | K  Drawer stops (F599) x 6 Runners (F600) x 3 and (F601) x 3 | |

Tools required



Rule



Cross-head screwdriver



Scissors



Hammer




Eye protection
(when using a hammer or drill)



Electric drill
(do not use for fitting screws)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


If you have damaged or missing components, call the
Customer Helpline: 03456 400800 quoting the reference
numbers below

Step 1

Prepare the small drawer front

Screw 2 metal dowels **B** into the small drawer front **3**.

Note: Tighten the metal dowels up fully against the panels.




Steps 1-20 will show you how to build the Bedside Chest

Step 2

Prepare 1 pair of drawer sides

Insert a small locking nut **C** into the hole shown on the left drawer side **1** and the right drawer side **2**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.





Step 3

Attach the drawer sides to the small drawer front

Push the left drawer sides **1** and right drawer sides **2** onto the back of the small drawer front **3**.

Turn the small locking nuts **C** on the left drawer side **1** and right drawer side **2**.

Note: Turn the locking nuts **C** clockwise to secure panels - more than 1/2 a turn.




Assembly Instructions

Step 4

Fit the small drawer base

Slide the small drawer base **7** down the grooves in the drawer sides **1** and **2** and down into the groove in the small drawer front **3**.




Step 5

Fit the small drawer back

Fit the small drawer back **5** between the drawer sides **1** and **2**. Make sure that the small drawer base **7** fits into the groove in the small drawer back **5**.

Hold the small drawer back **5** in position and tap the knock-in pegs **1** through the holes in the drawer sides **1** and **2**.




Step 6

Push in drawer stops

Carefully break off 2 drawer stops (F599) from a pair of the drawer runners **K**.

Push the drawer stops fully through the drawer sides **1** and **2** from the inside.




Assembly Instructions

Step 7

Attach the handle

Attach a handle **F** to the small drawer front **3** using screw **E**.



Note: Do not overtighten the screws.



Step 8

Fit the wedgefixes

Turn the drawer assemblies over and slide 2 wedgefixes **J** into the front and back grooves, as shown, and tighten up the screws.



Step 9

Prepare the right end

Separate the runners **K**.



Push fit a right runner **K** marked 'R' into the holes shown on the right end **10**.

Note: Runners must be fitted flat against the panel. If necessary gently tap into final position.

Screw 3 metal dowels **B** into the right end **10**.

Insert 2 large locking nuts **D** into the right end **10**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Assembly Instructions

Step 10

Prepare the fixed shelf

Insert 4 large locking nuts **D** into the fixed shelf **12**.





Step 11

Fit the fixed shelf to the right end

Push the fixed shelf **12** onto the right end **10**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the fixed shelf **12**.

Note: Turn the large locking nuts **D** as far as they will go - more than 1/2 a turn.





Step 12

Prepare the plinth

Tap 2 wooden dowels **A** into the plinth **13**.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.

Insert 2 large locking nuts **D** into the plinth **13**.




Assembly Instructions

Step 13

Fit the plinth

Push the plinth **13** onto the right end **10**.

Use a screwdriver to tighten the large locking nut **D** fitted to the plinth **13**.





Step 14

Prepare the left end

Push fit a left runner **K** marked 'L' into the holes shown on the left end **9**.

Screw 3 metal dowels **B** into the left end **9**.

Insert 2 large locking nuts **D** into the left end **9**.




Step 15

Fit the left end

Push the left end **9** onto the assembly.

Use a screwdriver to tighten the 3 large locking nuts **D** fitted to the fixed shelf **12** and the plinth **13**.




Assembly Instructions

Step 16

Prepare the top

Screw 4 metal dowels **B** into the top **11**.




Step 17

Fit the top

Push the top **11** onto the assembly.


Use a screwdriver to tighten the 4 large locking nuts **D** fitted to the left end **9** and right end **10**.



Step 18

Fit the 4 plastic nails

Tap 2 plastic nails **H** into the bottom edge of each of the ends **9** and **10**.



Assembly Instructions

Step 19

Fit the back

a: Square up the unit by making sure that measurement **x to x** equals **y to y**.


b: Place the back **14** onto the unit.

Nail **G** around the outside edges of the back **14**.

Note: Nails should be spaced about 150mm apart.

Stand the unit up for the next step.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




Step 20

Insert the drawer

Lift the front of the drawer whilst inserting to overcome the 'stop' system.

Note: To ensure that your drawer runs smoothly, spray a small amount of furniture polish into the grooves.

The bedside chest assembly is complete




Assembly Instructions

Step 21

Prepare the 2 large drawer fronts

Screw 2 metal dowels **B** into each large drawer front **4**.

Note: Tighten the metal dowels up fully against the panels.




Steps 21-41 will show you how to build the 2 Drawer Chest

Step 22

Prepare 2 pairs of drawer sides

Insert a small locking nut **C** into the hole shown on the left drawer side **1** and the right drawer side **2**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.





Step 23

Attach the drawer sides to the large drawer fronts

Push the left drawer sides **1** and right drawer sides **2** onto the back of the large drawer fronts **4**.

Turn the small locking nuts **C** on the left drawer side **1** and right drawer side **2**.

Note: Turn the locking nuts **C** clockwise to secure panels - more than 1/2 a turn.




Assembly Instructions

Step 24

Fit the large drawer base

Slide the large drawer base **8** down the grooves in the drawer sides **1** and **2** and down into the groove in the large drawer front **4**.




Step 25

Fit the large drawer back

Fit the large drawer back **6** between the drawer sides **1** and **2**. Make sure that the large drawer base **8** fits into the groove in the large drawer back **6**.

Hold the large drawer back **6** in position and tap the knock-in pegs **1** through the holes in the drawer sides **1** and **2**.




Step 26

Push in drawer stops

Carefully break off the 2 drawer stops (F599) from each pair of the drawer runners **K**.

Push the drawer stops fully through the drawer sides **1** and **2** from the inside.




Assembly Instructions

Step 27

Attach the handles

Attach 2 handles **F** to each large drawer front **4** using screws **E**.

Note: Do not overtighten the screws.




x 2

Step 28

Fit the wedgfixes

Turn the drawer assemblies over and slide 2 wedgfixes **J** into the front and back grooves, as shown, and tighten up the screws.



x 2

Step 29



Prepare the right end

Separate the runners **K**.

Push fit 2 right runners **K** marked 'R' into the holes shown on the right end **16**.

Screw 4 metal dowels **B** into the right end **16**.

Insert 2 large locking nuts **D** into the right end **16**.




Assembly Instructions

Step 30

Prepare the fixed shelf

Insert 4 large locking nuts **D** into the fixed shelf **19**.




Step 31

Fit the fixed shelf to the right end

Push the fixed shelf **19** onto the right end **16**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the fixed shelf **19**.





Step 32

Prepare the left end

Push fit 2 left runners **K** marked 'L' into the holes shown on the left end **15**.

Screw 4 metal dowels **B** into the left end **15**.

Insert 2 large locking nuts **D** into the left end **15**.




Assembly Instructions

Step 33

Prepare the 2 plinths

Tap 2 wooden dowels **A** into each plinth **18**.

Insert 2 large locking nuts **D** into each plinth **18**.




Step 34

Fit the 2 plinths

Push the 2 plinths **18** onto the right end **16**.

Use a screwdriver to tighten the large locking nut **D** fitted to each of the plinths **18**.




Step 35

Fit the left end

Push the left end **15** onto the assembly.

Use a screwdriver to tighten the 4 large locking nuts **D** fitted to the fixed shelf **19** and the 2 plinths **18**.




Assembly Instructions

Step 36

Prepare the top

Screw 4 metal dowels **B** into the top **17**.




Step 37

Fit the top

Push the top **17** onto the assembly.


Use a screwdriver to tighten the 4 large locking nuts **D** fitted to the left end **15** and right end **16**.



Step 38

Fit the 4 plastic nails

Tap 2 plastic nails **H** into the bottom edge of each of the ends **15** and **16**.



Assembly Instructions

Step 39

Fit the back

a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

b: Place the back **[20]** onto the unit.

Nail **G** around the outside edges of the back **[20]**.


Note: Nails should be spaced about 150mm apart.

Stand the unit up for the next step.



Warning: The unit is heavy. Lift with care.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




Step 40

Insert the drawers

Lift the front of the drawers whilst inserting to overcome the 'stop' system.

Note: To ensure that your drawers run smoothly, spray a small amount of furniture polish into the grooves.

The chest assembly is complete



If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

