


# Stowe - Cabin Bed

427/0977

424/1085

**IMPORTANT!**  
**KEEP THESE ASSEMBLY INSTRUCTIONS**  
**FOR FUTURE REFERENCE**

**WARNING!**  
**NOT SUITABLE FOR CHILDREN**  
**UNDER 4 YEARS OF AGE .**



This product conforms to  
BS 8509: 2008+A1: 2011

## Dimensions

Width - 198.2cm

Depth - 96.4cm

Height - 66.2cm



**MADE IN  
BRITAIN**

**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please visit [www.argos-support.co.uk](http://www.argos-support.co.uk)  
or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk) (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020



## Safety and Care Advice

**Important** - Please read these instructions fully before starting assembly

- The recommended mattress size is 900mm x 1900mm.
- Minimum mattress height of 200mm to be used.
- **WARNING!** Do not place this child's bed near heat sources, windows and other furniture.
- **WARNING!** Do not use this child's bed if any part is broken, torn or missing.
- **WARNING!** Not suitable for children under 4 years old.
- **WARNING!** Children are likely to play, bounce, jump and climb on beds, therefore the child's bed should not be placed too close to other furniture or windows, blinds or cords, curtain pulls or other strings or cords and should be placed either tight to any wall or have a gap of 300mm between the wall and the side of the bed.
- This unit is not designed to be dismantled for storage or transportation.

### **IMPORTANT!**

**On a regular basis please check that the screws and fittings have not become loose as this could present a potential choke hazard.**



# Safety and Care Advice

## Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 78kgs. Please lift with care.
  - Check you have all the components and tools listed on pages 2, 3 and 4.
  - Remove all fittings from the plastic bags and separate them into their groups.
  - Keep children and animals away from the work area, small parts could choke if swallowed.
  - Parts of the assembly will be easier with 2 people.
  - Make sure you have enough space to layout the parts before starting.
  - Do not stand or put weight on the product, this could cause damage.
  - Assemble the item as close to its final position (in the same room) as possible.
  - Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).
- 
- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.
  - **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings (not supplied).
  - Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Tools required

Scissors / Rule / Hammer / Cross-head screwdriver / Square / Spirit level

Eye protection (when using a hammer)

## Components - Panels


If you need help or have damaged or missing parts, please visit [www.argos-support.co.uk](http://www.argos-support.co.uk)

or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk) (quoting your original order number)


Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020


## Please check you have all the panels listed below




**1** Drawer Front (DF3723)  
(94.6 x 17.7cm) x 2



**2** Left Drawer Side (W330-124LH)  
(33 x 12.4cm) x 2



**3** Right Drawer Side (W330-124RH)  
(33 x 12.4cm) x 2



**4** Drawer Back (W903-124)  
(90.3 x 12.4cm) x 2



**5** Drawer Base (T914-327)  
(91.4 x 32.7cm) x 2


# Components - Panels

If you need help or have damaged or missing parts, please visit [www.argos-support.co.uk](http://www.argos-support.co.uk) or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk) (quoting your original order number)


Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020

Please check you have all the panels listed below




**6** Head Board (DF3733)  
(94.9 x 66.2cm)




**7** Foot Board (DF3734)  
(94.9 x 66.2cm)




**8** Cross Rail (DF3726)  
(95.25 x 9.2cm) x 2




**9** Quadrant (DF3698)  
(63 x 15.8cm) x 2



**10** Mattress Base (DF3732)  
(192 x 47.4cm) x 2




**11** Left Divider (DF3725)  
(48.8 x 66cm)



**12** Right Divider (DF3727)  
(38.2 x 63.4cm)




**13** Mattress Back (DF3697)  
(192 x 15.8cm)



**14** Back Rail (DF3701)  
(192 x 9.2cm) x 2




**15** Drawer Back (DF3731)  
(92.25 x 48.8cm)




**16** Left Door Back (DF3730)  
(46.85 x 48.8cm)




**17** Right Door Back (DF3735)  
(46.85 x 48.8cm)



**18** Door Base (DF3728)  
(95.2 x 29.5cm)



**19** Left Door (DF3724)  
(37.6 x 47.1cm)



**20** Right Door (DF5017)  
(37.6 x 47.1cm)



**21** Side Plinth (DF3699)  
(94.9 x 9.1cm) x 2



**22** Front Plinth (DF3700)  
(198.2 x 9.2cm)



**23** Shelf (DF3729)  
(46.8 x 26.8cm) x 2





# Components - Fittings



























If you need help or have damaged or missing parts, please visit [www.argos-support.co.uk](http://www.argos-support.co.uk) or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk) (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020

Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<b>A</b>  Wooden dowel (F22) x 27	<b>B</b>  Metal dowel (F901) x 12	<b>C</b>  Knock-in Peg (F171GY) x 8
<b>D</b>  Shelf stud (F110) x 8	<b>E</b>  Large locking nut (F900) x 8	<b>F</b>  Small locking nut (F3) x 4
<b>G</b>  50mm Screw (F49) x 48	<b>H</b>  38mm Screw (F81) x 4	<b>I</b>  25mm Screw (F50) x 8
<b>J</b>  19mm Screw (F461) x 4	<b>K</b>  13mm Screw (F79) x 10	<b>L</b>  9mm Screw (F73) x 12
<b>M</b>  13mm Screw (F63) x 20	<b>N</b>  Modesty Block (F240) x 2	<b>O</b>  Allen Key (F36) x 1
<b>P</b>  Wedge (F639) x 8	<b>Q</b>  Bracket (F945) x 5	<b>R</b>  Plastic Nail (F91) x 11
<b>S</b>  Hinge plate (F523) x 4	<b>T</b>  Hinge (F522) x 4	<b>U</b>  Oak Handle (F463) x 4
<b>Va</b>  L Runner (F961) x 2	<b>OR</b>  <b>U</b>  White Handle (F565) x 4	
<b>Vb</b>  R Runner (F962) x 2		
<b>Vc</b>  L Runner (F963) x 2		
<b>Vd</b>  R Runner (F964) x 2		


# Assembly Instructions

## Step 1

### Prepare the 2 drawer fronts

Screw 2 metal dowels **B** into each of the drawer fronts **1**.

**Note:** Tighten the metal dowels up fully against the panels.




## Step 2

### Prepare the drawer sides

Insert a small locking nut **F** into the hole shown on the left drawer side **2** and the right drawer side **3**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.




## Step 3

### Attach the drawer sides to the drawer fronts

Push the left drawer sides **2** and right drawer sides **3** onto the back of the drawer fronts **1**.

Turn the small locking nuts **F** on the left drawer side **2** and right drawer side **3**.

**Note:** Turn the locking nuts **F** clockwise to secure panels - more than 1/2 a turn.




# Assembly Instructions

## Step 4

### Fit the drawer base

Slide the drawer base **5** down the grooves in the drawer sides **2** and **3** and down into the groove in the drawer front **1**.




## Step 5

### Fit the drawer back

Fit the drawer back **4** between the drawer sides **2** and **3**. Make sure that the drawer base **5** fits into the groove in the drawer back **4**.

Hold the drawer back **4** in position and tap the knock-in pegs **C** through the holes in the drawer sides **2** and **3**.




## Step 6

### Attach the handles

Attach a handle **U** to each of the drawer fronts **7**.

Use screw **H** for an oak handle and screw **J** for a white handle.




# Assembly Instructions

## Step 7

### Fit the wedgefixes

Turn the drawer assemblies over and slide 4 wedgefixes **P** into the front and back grooves, as shown, and tighten up the screws.




## Step 8

### Fit runners to the drawers

Fit runner **Vd**, marked with 'R', to the bottom edge of the right drawer side **3**, as shown, making sure that it is pushed up against the back of the small drawer front **1**. Use a bradawl to mark the fixing positions, then secure with 2 screws **M**.

Fit runner **Vc**, marked 'L', to the bottom edge of the left drawer side **2** using the same method.





# Assembly Instructions

## Step 9

### Prepare the foot board

Fit 2 hinge plates **S** onto the foot board **7**, making sure that the slot is facing towards the front edge.





## Step 10

### Prepare the door base

Tap 2 wooden dowels **A** into the door base **18**.


**Note:** Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.



## Step 11

### Fit the door base to the foot board

Attach the door base **18** to the foot board **7** using 2 screws **G** and tighten them using the allen key **O**.




# Assembly Instructions

## Step 12

### Prepare the right door back

Tap 2 wooden dowels **A** into the right door back **17**.




## Step 13

### Fit the right door back

Attach the right door back **17** to the foot board **7** using 2 screws **G** and tighten them using the allen key **O**.

**Note:** The bottom edge of the right door back must be flush with the foot board.




## Step 14

### Prepare the right divider

Tap 3 wooden dowels **A** into the right divider **12**.

Screw 2 metal dowels **B** into the right divider **12**.




# Assembly Instructions

## Step 15

### Fit the right divider

Attach the right divider **12** to the right door back **17** and the door base **18** using 4 screws **G** and tighten them using the allen key **O**.




## Step 16

### Prepare the left door back

Tap 2 wooden dowels **A** into the left door back **16**.

Insert 2 large locking nuts **E** into the left door back **16**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.




## Step 17

### Fit the left door back

Push the left door back **16** onto the right divider **12**.

Use a screwdriver to tighten the 2 large locking nuts **E** fitted to the left door back **16**.

**Note:** Turn the large locking nuts **E** as far as they will go - more than 1/2 a turn.



# Assembly Instructions

## Step 18

### Prepare the left divider

**a:** Fit 2 runners **Vb** to the left divider **11**.

The 1st screw **L** uses the 1st hole in from the front of the runner.

The 2nd and 3rd screws **L** use the holes that line up with the other panel holes.




**b:** Fit a screw **M** into the 2nd hole in at the top of the runner **Vb**.

Screw 2 metal dowels **B** into the left divider **11**.



**Turn the left divider over**

**c:** Tap 2 wooden dowels **A** into the left divider **11**.

Fit 2 hinge plates **S** onto the left divider **11**, making sure that the slot is facing towards the front edge.



**Turn the left divider over**






# Assembly Instructions

## Step 19

### Fit the left divider

Attach the left divider **11** to the left door back **16** and the door base **18** using 4 screws **G** and tighten them using the allen key **O**.




## Step 20

### Prepare the 2 cross rails

Tap 2 wooden dowels **A** into each of the 2 cross rails **8**.

Insert 2 large locking nuts **E** into each of the 2 cross rails **8**.




## Step 21

### Fit the 2 cross rails

Push the 2 cross rails **8** onto the left divider **11**.

Use a screwdriver to tighten the large locking nut **E** fitted to each of the 2 cross rails **8**.




# Assembly Instructions

## Step 22

### Prepare the 2 mattress bases


Tap 2 wooden dowels **A** into each of the 2 mattress bases **10**.



## Step 23

### Fit a mattress base

Attach a mattress base **10** to the foot board **7**, left divider **11** and right divider **12** using 4 screws **G** and tighten them using the allen key **O**.




# Assembly Instructions

## Step 24

### Fit a mattress base

Attach a mattress base **10** to the foot board **7**, left divider **11** and right divider **12** using 6 screws **G** and tighten them using the allen key **O**.



## Step 25

### Prepare the head board



**a:** Fit a runner **Va** to the headboard **6**.

The 1st screw **L** uses the 1st hole in from the front of the runner.



The 2nd and 3rd screws **L** use the holes that line up with the other panel holes.

**b:** Fit a screw **M** into the 2nd hole in at the top of the runner **Va**.

Screw 2 metal dowels **B** into the head board **6**.



**b:**




# Assembly Instructions

## Step 26

### Prepare the drawer back

Tap 2 wooden dowels **A** into the drawer back **15**.




## Step 27

### Fit the right divider

Attach the drawer back **15** to the head board **6** using 2 screws **G** and tighten them using the allen key **O**.


**Note:** The bottom edge of the drawer back must be flush with the head board.



## Step 28

### Prepare the mattress back

Tap 2 wooden dowels **A** into the mattress back **13**.




# Assembly Instructions

## Step 29

### Fit a back rail

Attach a back rail **14** to the foot board **7** using 2 screws **G** and tighten them using the allen key **O**.




## Step 30

### Fit the mattress back

Attach the mattress back **13** to the foot board **7** using 2 screws **G** and tighten them using the allen key **O**.

**Note:** Support the mattress back until the head board has been fitted in the next step.




# Assembly Instructions

## Step 31

### Fit the headboard


Attach the headboard **6** and drawer back **15** to the assembly using 12 screws **G** and tighten them using the allen key **O**.



## Step 32

### Secure the 2 cross rails to the headboard

Use a screwdriver to tighten the large locking nut **E** fitted to each of the 2 cross rails **8**.




# Assembly Instructions

## Step 33

### Fit the other back rail

Attach the back rail **14** to the headboard **6** and footboard **7** using 4 screws **G** and tighten them using the allen key **O**.



## Step 34


### Fit the 11 plastic nails

Tap 11 plastic nails **R** into the bottom edge of the panels shown.

**Note:** To make it easier to fit the plinths, place 2 polystyrene blocks from the packaging underneath the headboard and footboard panels to raise the assembly.



**Warning:** The unit is heavy. Lift with care.




# Assembly Instructions

## Step 35

### Prepare a side plinth

Insert a large locking nut **E** into 1 of the side plinths **21**.

Tap a wooden dowel **A** into the side plinth **21**.




## Step 36

### Prepare the other side plinth

Insert a large locking nut **E** into the side plinth **21**.


Tap a wooden dowel **A** into the side plinth **21**.



## Step 37

### Prepare the front plinth

Screw 2 metal dowels **B** into the front plinth **22**.






# Assembly Instructions

## Step 38

### Fit the plinths together

Push the 2 side plinths **21** onto the front plinth **22**.

Use a screwdriver to tighten the large locking nuts **E** fitted to the side plinths **21**.




## Step 39

### Fit the plinths

Position the 3 plinths around the outside of the assembly, ensuring that the bottom edge of the plinths are flush with the bottom edge of the sides, as shown.

Secure the 2 side plinths **21** through the headboard **6** and footboard **7** using screws **1**.



# Assembly Instructions

## Step 40


### Secure the front plinth

Screw 2 modesty blocks **N** to the front plinth **22** using screws **I**.

**Carefully stand the unit up for the next step.**




**Warning:** The unit is heavy. Lift with care.



## Step 41

### Prepare the 2 quadrants

Tap a wooden dowel **A** into each of the 2 quadrants **9**.




# Assembly Instructions

## Step 42

### Fit the quadrants

Attach the 2 quadrants **9** using screws **G** and tighten them using the allen key **O**.




## Step 43

### Fit the 5 brackets

Fix 3 brackets **Q** to the mattress back **13** and mattress base **10** using screws **K**.

Fix a bracket **Q** about 10cm in from the end of each of the quadrants **13** and the mattress base **10** using screws **K**.




# Assembly Instructions

## Step 44

### Fit the drawers

Slide the wheels on the runners fitted to the drawers over the wheels of the runners fitted to the side panels and push the drawers into position.




## Step 45

### Fit the shelves

For each of the 2 shelves **23**, insert 4 shelf studs **D**.

Lower the 2 shelves **23** down onto the shelf studs **D**.



# Assembly Instructions



## Step 46

### Prepare the left door

Push fit 2 hinges **T** into the left door **19**.

Secure each hinge with 2 screws **M**.

**Note:** Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the edge of the door.




## Step 47

### Prepare the right door

Push fit 2 hinges **T** into the right door **20**.

Secure each hinge with 2 screws **M**.

**Note:** Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the edge of the door.



# Assembly Instructions

## Step 48

### Fit doors and handles

**Note:** The easiest way to attach each door **19** and **20** is to fit the top hinge first, then align and fit the other hinges.

**a:** Push the hinge **T** onto the front part of the hinge plate **S**. The recess at the bottom of screw B goes into the slot in the hinge plate.



**b:** Keep the hinge **T** FLAT against the hinge plate **S** as you slide it across as far as it will go. Tighten screw A.

**c:** The hinge **T** must be flat against the hinge plate **S** prior to any adjustment.

**d:** The hinge **T** must NOT be AT AN ANGLE to the hinge plate **S** when assembled.

This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure.

Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.




# Assembly Instructions

## Step 49

### Fit the handles

Attach a handle **U** to each door **19** and **20**.

Use screw **H** for oak handles and screw **J** for white handles.



# Assembly Instructions

## Step 50

### Adjust the doors if needed

**a:** Before adjusting the doors, use a spirit level to check the base (or top) of the unit is level, front-to-back and side-to-side in the 3 positions shown. Use suitable packing pieces (not supplied) to make the unit level BEFORE making any adjustment to the hinges, as shown.

### **b:** Height adjustment.


Loosen screws A on hinge plates and move door up or down as required. Retighten screw A.

### **c:** Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required. Retighten screw B.

### **d:** Sideways adjustment.

To move door 'out' loosen screw C. To move door 'in' tighten screw C.






# Assembly Instructions

## Step 51

**Assembly is complete**



### **IMPORTANT!**

**On a regular basis please check that the screws and fittings have not become loose as this could present a potential choke hazard.**

If you need help or have damaged or missing parts, please visit [www.argos-support.co.uk](http://www.argos-support.co.uk) or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk) (quoting your original order number)  
Alternatively, call the Spares Helpline on: 0370 112 1928.  
For any other queries please contact the Customer Helpline on: 0345 640 2020

