Sparkle - 3 Door Mirrored Robe



Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400800

A Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- *Warning:* This unit weighs approximately 68kgs. Please lift with care.
- Check you have all the components and tools listed on pages 1, 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).




• We do not recommend the use of power drill/drivers *for inserting screws*,

as this could damage the unit. Only use hand screwdrivers.


- **Safety note:** It is recommended that this unit is secured to a wall using the overbalance protector kit supplied or, an alternative fixing method of your choice.
- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.



Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.




Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 03456 400800** *quoting the reference numbers below*

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



130 140 150 160 170

If you have damaged or missing components, call the numbers below

Step 1

Prepare the left side

a: Screw 4 metal dowels **A** into the left side 1.

Note: Tighten the metal dowels up fully against the panels.

Insert 2 large locking nuts **B** into the left side 1.


Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.

Tap 2 wooden dowels C into the left side 1.

Note: Wooden dowels must not stick out from the edge by more than 10mm or they may damage other panels.

b: To fit the rail holder screw through the top hole with screw F and into the mark hole drilled in the left side 1. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **(F)** using the lower hole.

Fit 4 hinge plates **P** onto the left side **1**, making sure that the slot is facing towards the finished front edge.



Step 2


Prepare the right side

a: Screw 4 metal dowels (A) into the right side (2).

Insert 2 large locking nuts 3 into the right side 2.

Tap 2 wooden dowels **G** into the right side **2**.

b: Fit 4 hinge plates **P** onto the right side **2**, making sure that the slot is facing towards the finished front edge.



Step 3

Prepare the base

Insert 4 large locking nuts **B** into the base **5**.

Tap 4 wooden dowels **C** into the base **5**.


Step 4

Fit the base to the right side

Push the base **5** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **B** fitted to the base **5**.

Note: Turn the large locking nuts **B** as far as they will go - more than 1/2 a turn.



Step 5


Prepare the divider

Insert 2 large locking nuts (3) into the divider (3).

Tap 4 wooden dowels **G** into the divider **3**.

To fit the rail holder **D** screw through the top hole with screw **F** and into the mark hole drilled in the divider **3**. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **F** using the lower hole.

Fit 4 hinge plates **P** onto the divider **3**, making sure that the slot is facing towards the finished front edge.



Step 6

Prepare the small rail

Insert 2 large locking nuts (B) into the small rail (B).

Tap a wooden dowel **C** into the small rail **8**.

Step 7

Fit the small rail

Push the small rail **8** onto the right side **2**.

Use a screwdriver to tighten the large locking nut (B) fitted to the small rail (8).

Step 8


Fit the divider

a: Push the divider **3** onto the base **5** and attach it using 2 screws **D**.

b: Tap a double metal dowel **(x)** through the divider **(3)** and into the small rail **(8)** until it "bottoms out".

Tap a large wooden dowel **1** through the divider **3** and into the small rail **8** until it "bottoms out".

C: Use a screwdriver to tighten the large locking nut **B** fitted to the small rail **B**.




Step 9

Prepare the plinth

Insert 2 large locking nuts **B** into the plinth **7**.

Tap 2 wooden dowels **C** into the plinth **7**.




Step 10

Fit the plinth

Push the plinth **7** onto the right side **2**.

Use a screwdriver to tighten the large locking nut (B) fitted to the plinth (7).




Step 11

Prepare the large rail

Insert 2 large locking nuts **B** into the large rail **9**.

Tap a wooden dowel **C** into the large rail **9**.




Step 12

Fit the large rail

Push the large rail 9 onto the divider 3.

Use a screwdriver to tighten the large locking nut B fitted to the large rail 9.



Step 13

Fit the left side

Push the left side 1 onto the assembly.


Use a screwdriver to tighten the 4 large locking nuts **B** fitted to

the base **5**, the plinth

Step 14

Prepare the top

Screw 6 metal dowels A into the top 4.




Step 15

Fit the top

Note: To make it easier to fit the top, place polystyrene blocks from the packaging underneath the side and divider panels to raise the assembly.

Push the top **4** onto the assembly.


Use a screwdriver to tighten the 2 large locking nuts fitted to the left side 1, the right side 2 and the divider 3.



Step 16

Fit the 4 plastic nails

Tap 2 plastic nails (1) into the bottom edge of each of the sides 1 and 2.



Step 17


Fit the 2 back panels

a: Square up the unit by making sure that measurement x:x equals y:y.

Place the small back **13** and large back 14, coloured surface facing down, onto the unit as shown.

Make sure that the 2 backs are pushed up tight against each other and that they meet in the centre of the divider's back edge.

The measurement from top corner X to bottom corner X must be a: equal to the measurement from top corner Y to bottom corner Y




backs.

Step 18

Fit the shelf studs


For each of the 3 shelves **6**, insert 4 shelf studs **1**.



Step 19

Fit the shelves


Lower the 3 shelves 6 down onto the shelf studs 1.




Step 20

Fit the hanging rail

Push the hanging rail **10** into the rail holders **b** fitted to the side panels.






Step 21

Prepare the 3 doors

Push fit 4 hinges (2) into each of the 2 plain doors 11 and the mirror door 12.

Secure each hinge with 2 screws **(**).

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the edge of the door.



Step 22

Fit doors and handles

Note: The easiest way to attach each door **11** and **12** is to fit the top hinge first, then align and fit the other hinges.


a: Push the hinge **Q** onto the front part of the hinge plate **P**. The recess at the bottom of screw B goes into the slot in the hinge plate.

b: Keep the hinge **Q** FLAT against the hinge plate **P** as you slide it across as far as it will go. Tighten screw A.

C: The hinge **Q** must be flat against the hinge plate **P** prior to any adjustment.

d: The hinge **O** must NOT be AT AN ANGLE to the hinge plate **P** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **O** to the 2 plain doors **11** using 3 screws **E**.



Step 23

Adjust the doors if needed

a: Before adjusting the doors, use a spirit level to check the base (or top) of the unit is level, front-to-back and side-to-side in the 3 positions shown. Use suitable packing pieces (not supplied) to make the unit level BEFORE making any adjustment to the hinges, as shown.

b: Height adjustment.


Loosen screws A on hinge plates and move door up or down as required. Retighten screw A.

C: Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required. Retighten screw B.

d: Sideways adjustment.

To move door 'out' loosen screw C. To move door 'in' tighten screw C.




Step 24

Fit the overbalance protector

To prevent possible overbalancing we recommend that this unit is secured to a suitable wall by fitting of the overbalance protector kit **R** to the unit, or an alternative fixing method of your choice.


Wall fixings are not supplied as they will need to suit the wall type.

Note: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.



Step 25

Assembly is complete



IMPORTANT INFORMATION ABOUT THIS PRODUCT

This product complies with the requirements of BS 7449:1991 and has been manufactured by DECORATIVE PANELS FURNITURE LTD, TEESSIDE INDUSTRIAL ESTATE, THORNABY-ON-TEES, CLEVELAND, TS17 9LT.

The product code for this unit and the item code(s) for the glass components are listed in the Assembly Instructions along with a description of the type of glass used. All clear/tinted glass complies with the requirements of BS 6206 Class A. All mirrors comply with the requirements of BS 6206 Class C. If the glass component contained in this unit is chipped or broken consult the furniture manufacturer, retailer, or agent with regard to obtaining a manufacturing specification and shape for replacement glass guoting the unit description and batch number or date of manufacture.

Do not place very hot or very cold items against or in close proximity to glass surface(s) unless adequately thick insulating material is used to prevent such items coming in contact with the glass. Do not strike the glass with hard or pointed items.

Do not sit or stand upon horizontal glass surfaces.

When cleaning glass panels use a damp cloth or leather with washing up liquid or soft soap if necessary - do not use washing powders or any other substance containing abrasives since these substances scratch glass.

If stated in the instruction leaflet, it is essential that this unit is fixed to a wall.

KEEP THESE INSTRUCTIONS FOR FUTURE USE

If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400800 and quote the reference numbers on the component pages. Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW