


Kensington - 3 Drawer 3 Door Robe

Assembly Instructions - Please keep for future reference

424/7429

402/7216



Dimensions

Width - 127.4cm

Depth - 49.5cm

Height - 198.8cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• **Warning:** This unit weighs approximately 85kgs. Please lift with care.

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Parts of the assembly will be easier with 2 people.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



• We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

• **Safety note:** It is recommended that this unit is secured to a wall using the overbalance protector kit supplied or, an alternative fixing method of your choice.

• Dispose of all packaging carefully and responsibly.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.


• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Tools required




Rule



Spirit level




Eye protection (when using a hammer or drill)



Cross-head screwdriver



Electric drill (only use when drilling into walls)



Step ladder




Square



Scissors




Hammer



Bradawl

Ruler - Use this ruler to help correctly identify the screws




Components - Panels

If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020

Please check you have all the panels listed below



1 Drawer Front (DF2414)
(79.1 x 19.2cm) x 3



2 Left Drawer Side (W370-124LH)
(37 x 12.4cm) x 3




3 Right Drawer Side (W370-124RH)
(37 x 12.4cm) x 3




4 Drawer Back (W765-124)
(76.5 x 12.4cm) x 3




5 Drawer Base (T776-367)
(77.6 x 36.7cm) x 3




6 Large Shelf (DF2413)
(79.7 x 47.4cm)




7 Left Side (DF3773)
(197.3 x 47.5cm)




8 Right Side (DF3774)
(197.3 x 47.5cm)



9 Divider (DF3776)
(197.3 x 47.5cm)



10 Narrow Shelf (DF3778)
(40 x 45cm)




11 Narrow Base (DF3779)
(40 x 47.4cm)



12 Large Hanging Rail (FHR791)
(79.1cm long)



13 Small Hanging Rail (FHR394)
(39.4cm long)



14 Top (DF3772)
(127.4 x 49.5cm)



15 Narrow Rail (DF3777)
(40 x 8.9cm) x 2



17 Rail (DF2412)
(79.7 x 8.9cm) x 5



16 Side Plinth (DF2431)
(47.5 x 9.1cm) x 2



18 Front Plinth (DF3775)
(127.4 x 9.2cm)




Components - Panels

If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020


Please check you have all the panels listed below



19 Small Left Door (DF3874)
(120.6 x 39.4cm)




20 Small Right Door (DF3780)
(120.6 x 39.4cm)



21 Large Door (DF3767)
(184.5 x 39.4cm)



22 Small Back (X1892-419)
(189.2 x 41.9cm)



23 Large Back (X1914-816)
(191.4 x 81.6cm)



Components - Fittings







If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Metal dowel (F901) x 38</p>	<p>B </p> <p>Large locking nut (F900) x 34</p>	<p>C </p> <p>Small locking nut (F3) x 6</p>
<p>D </p> <p>Wooden dowel (F22) x 30</p>	<p>E </p> <p>Nail (F51) x 42</p>	<p>F </p> <p>Knock-in Peg (F171GY) x 12</p>
<p>G </p> <p>25mm Screw (F50) x 6</p>	<p>H </p> <p>19mm Screw (F461) x 9</p>	<p>I </p> <p>9mm Screw (F74) x 6</p>
<p>J </p> <p>9mm Screw (F73) x 12</p>	<p>K </p> <p>13mm Screw (F63) x 28</p>	<p>L </p> <p>Plastic Nail (F91) x 6</p>
<p>M </p> <p>Drawer runner (F1004) x 6</p>		<p>N </p> <p>Wedgefix (F639) x 12</p>
<p>O </p> <p>Rail Holder (F891) x 4</p>	<p>P </p> <p>Hinge plate (F523) x 10</p>	<p>Q </p> <p>Hinge (F522) x 10</p>
<p>R </p> <p>Handle (F220) x 9</p>	<p>S </p> <p>Shelf stud (F110) x 2</p>	<p>T </p> <p>Strap</p> <p> Screw  Washer x 2</p> <p>Overbalance protector kit (F269) x 1</p>
<p>U </p> <p>Large wooden dowel (F40) x 1</p>	<p>V </p> <p>Double metal dowel (F566) x 1</p>	
<p>W </p> <p>Nail screw (F277) x 6</p>	<p>X  *These can also be round</p> <p>Back holder (F276) x 6</p>	


Assembly Instructions

Step 1

Prepare the 3 drawer fronts

Screw 2 metal dowels **A** into each of the 3 drawer fronts **1**.

Note: Tighten the metal dowels up fully against the panels.




Step 2

Prepare the drawer sides

Insert a small locking nut **C** into the hole shown on the left drawer side **2** and the right drawer side **3**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Step 3

Attach the drawer sides to the drawer fronts

Push the left drawer sides **2** and right drawer sides **3** onto the back of the drawer fronts **1**.

Turn the small locking nuts **C** on the left drawer side **2** and right drawer side **3**.

Note: Turn the locking nuts **C** clockwise to secure panels - more than 1/2 a turn.




Assembly Instructions

Step 4

Fit the drawer base

Slide the drawer base **5** down the grooves in the drawer sides **2** and **3** and down into the groove in the drawer front **1**.




Step 5

Fit the drawer back

Fit the drawer back **4** between the drawer sides **2** and **3**. Make sure that the drawer base **5** fits into the groove in the drawer back **4**.


Hold the drawer back **4** in position and tap the knock-in pegs **F** through the holes in the drawer sides **2** and **3**.



Step 6

Attach the handles


Attach 2 handles **R** to each drawer front **1** using screws **H**.



Step 7

Fit the wedgifixes

Turn the drawer assemblies over and slide 4 wedgifixes **N** into the front and back grooves, as shown, and tighten up the screws.



Assembly Instructions

Step 8

Prepare the divider

a: Place 3 runners **M** on the divider **9** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **J**.

Fit 3 hinge plates **P** onto the divider **9**, making sure that the slot is facing towards the finished front edge.

b: Slide the runners **M** back the other way and fit the 2nd screw **J** into the corresponding holes in the divider **9**.


Insert 2 large locking nuts **B** into the divider **9**.

Note: The arrow on the locking nuts **must** point towards the hole in the edge of the panel.

Tap 2 wooden dowels **D** into the divider **9**.

c: Screw 6 metal dowels **A** into the divider **9**.

To fit the rail holder **O** screw through the top hole with screw **K** and into the mark hole drilled in the divider **9**. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **K** using the lower hole.




Assembly Instructions

Step 9

Turn the divider over and prepare its other surface

Screw 5 metal dowels **A** into the divider **9**.

To fit the rail holder **O** screw through the top hole with screw **K** and into the mark hole drilled in the divider **9**. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **K** using the lower hole.




Step 10

Prepare the large shelf

Insert 4 large locking nuts **B** into the large shelf **6**.

Tap 4 wooden dowels **D** into the large shelf **6**.




Step 11

Fit the large shelf to the divider

Push the large shelf **6** onto the divider **9**.

Use a screwdriver to tighten the 2 large locking nuts **B** fitted to the large shelf **6**.

Note: Turn the large locking nuts **B** as far as they will go - more than 1/2 a turn.




Assembly Instructions

Step 12

Prepare the narrow base

Insert 4 large locking nuts **B** into the narrow base **11**.

Tap 4 wooden dowels **D** into the narrow base **11**.




Step 13

Fit the narrow base to the divider

Push the narrow base **11** onto the divider **9**.

Use a screwdriver to tighten the 2 large locking nuts **B** fitted to the narrow base **11**.




Step 14

Prepare 1 of the narrow rails

Insert 2 large locking nuts **B** into the narrow rail **15**.

Tap 1 wooden dowel **D** into the narrow rail **15**.



Assembly Instructions

Step 15


Fit the narrow rail

a: Position the narrow rail **15** up against the 2 holes in the divider **9**.

b: Tap a double metal dowel **V** through the divider **9** and into the narrow rail **15** until it "bottoms out".

Tap a large wooden dowel **U** through the divider **9** and into the narrow rail **15** until it "bottoms out".

c: Use a screwdriver to tighten the large locking nut **B** fitted to the narrow rail **15**.




Step 16

Prepare the other narrow rail

Insert 2 large locking nuts **B** into the narrow rail **15**.

Tap 2 wooden dowels **D** into the narrow rail **15**.




Assembly Instructions

Step 17

Fit the narrow rail to the divider

Push the narrow rail **15** onto the divider **9**.

Use a screwdriver to tighten the large locking nut **B** fitted to the narrow rail **15**.




Step 18

Prepare the narrow shelf

Insert 4 large locking nuts **B** into the narrow shelf **10**.

Tap 4 wooden dowels **D** into the narrow shelf **10**.




Step 19

Fit the narrow shelf to the divider

Push the narrow shelf **10** onto the divider **9**.

Use a screwdriver to tighten the 2 large locking nuts **B** fitted to the narrow shelf **10**.



Assembly Instructions

Step 22

Prepare the left side

a: Place 3 runners **M** on the left side **7** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **J**.

Fit 3 hinge plates **P** onto the left side **7**, making sure that the slot is facing towards the finished front edge.

b: Slide the runners **M** back the other way and fit the 2nd screw **J** into the corresponding holes in the left side **7**.





Insert 2 large locking nuts **B** into the left side **7**.

Note: The arrow on the locking nuts **must** point towards the hole in the edge of the panel.

Tap 2 wooden dowels **D** into the left side **7**.

c: Screw 7 metal dowels **A** into the left side **7**.

To fit the rail holder **O** screw through the top hole with screw **K** and into the mark hole drilled in the left side **7**. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **K** using the lower hole.




Assembly Instructions

Step 23

Prepare 4 rails

Insert 2 large locking nuts **B** into 4 of the rails **17**.

Tap 2 wooden dowels **D** into 4 of the rails **17**.




Step 24

Prepare the other rail

Insert 2 large locking nuts **B** into the rail **17**.

Tap 1 wooden dowel **D** into the rail **17**.




Step 25

Fit the 5 rails

Push the 5 rails **17** onto the divider **9**.

Use a screwdriver to tighten the large locking nut **B** fitted to each of the 5 rails **17**.




Assembly Instructions

Step 26

Fit the left side

Push the left side **7** onto the assembly.


Use a screwdriver to tighten the 7 large locking nuts **B** fitted to the large shelf **6** and the 5 rails **17**.



Step 27

Prepare the top

Screw 6 metal dowels **A** into the top **14**.



Assembly Instructions


Step 28

Fit the top

Note: To make it easier to fit the top and plinths, place polystyrene blocks from the packaging underneath the side and divider panels to raise the assembly.

Push the top **14** onto the assembly.

Use a screwdriver to tighten the 6 large locking nuts **B** fitted to the sides **7** and **8** and the divider **9**.




Warning: The unit is heavy. Lift with care.

Step 29

Secure the top rail to the top

Screw through the 2 holes in the top **14** and into the top rail **17** using 2 screws **G**.



Assembly Instructions

Step 30

Fit the 2 back panels

a: Square up the unit by making sure that measurement **x:x equals y:y**.

Place the small back **22** and large back **23**, coloured surface facing down, onto the unit as shown.

Make sure that the 2 backs are pushed up tight against each other and that they meet in the centre of the divider's back edge.


b: Nail **E** around the outside edges of the 2 backs.

Note: Do not nail where the 2 backs meet.


c: Push the nail screws **W** through the back holders **X** and tap them down between the small back **22** and large back **23** and into the back edge of the divider **9**.

Keep tapping the nail screws **W** in until the back holders **X** dig into the small and large back.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y



Note: If ever you need to take the backs off to dismantle the unit, the nail screws can be taken out using a screwdriver.




Assembly Instructions

Step 31

Fit the 4 plastic nails

Tap 2 plastic nails **L** into the bottom edge of each of the sides **7** and **8** and the divider **9**.




Step 32

Prepare a side plinth

Insert a large locking nut **B** into 1 of the side plinths **16**.

Tap a wooden dowel **D** into the side plinth **16**.




Step 33

Prepare the other side plinth

Insert a large locking nut **B** into the side plinth **16**.

Tap a wooden dowel **D** into the side plinth **16**.




Assembly Instructions

Step 34

Prepare the front plinth

Screw 2 metal dowels **A** into the front plinth **18**.




Step 35

Fit the plinths together

Push the 2 side plinths **16** onto the front plinth **18**.

Use a screwdriver to tighten the large locking nuts **B** fitted to the side plinths **16**.




Step 36

Fit the plinths

Position the 3 plinths around the outside of the assembly, ensuring that the bottom edge of the plinths are flush with the bottom edge of the sides, as shown.

Secure the 2 side plinths **16** through the left side **7** and right side **8** using screws **G**.

Carefully stand the unit up for the next step.



Warning: The unit is heavy. Lift with care.

Assembly Instructions



Step 37

Fit the drawers

Starting with the bottom drawer, slide both the runners **M** forward and locate the drawer sides **2** and **3** between them, lining up the holes in the drawer wrap with the 2nd 'threaded' holes in the runners **M**.

Working from the inside of the drawer, insert 2 screws **I** through the drawer sides and out into the 2nd threaded hole in the runner.

Note: Do not overtighten the screws **I**. If they catch on the runner you may need to loosen them slightly.





Step 38

Fit the hanging rails and shelf studs

Push the large hanging rail **12** and small hanging rail **13** into the rail holders **O**.

Push the 2 shelf studs **S** down into the holes in the large shelf **6** to act as door buffers.



Assembly Instructions




Step 39

Prepare the 2 small doors

Push fit 3 hinges **Q** into each of the 2 small doors **19** and **20**.

Secure each hinge with 2 screws **K**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the edge of the door.




Step 40

Prepare the large door

Push fit 4 hinges **Q** into the large door **21**.

Secure each hinge with 2 screws **K**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the edge of the door.



Assembly Instructions

Step 41

Fit doors and handles

Note: The easiest way to attach each door **19**, **20** and **21** is to fit the top hinge first, then align and fit the other hinges.



a: Push the hinge **Q** onto the front part of the hinge plate **P**. The recess at the bottom of screw B goes into the slot in the hinge plate.

b: Keep the hinge **Q** FLAT against the hinge plate **P** as you slide it across as far as it will go. Tighten screw A.

c: The hinge **Q** must be flat against the hinge plate **P** prior to any adjustment.

d: The hinge **Q** must NOT be AT AN ANGLE to the hinge plate **P** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **R** to each door **19**, **20** and **21** using screws **H**.



Assembly Instructions

Step 42

Adjust the doors if needed

a: Before adjusting the doors, use a spirit level to check the base (or top) of the unit is level, front-to-back and side-to-side in the 3 positions shown. Use suitable packing pieces (not supplied) to make the unit level BEFORE making any adjustment to the hinges, as shown.

b: Height adjustment.


Loosen screws A on hinge plates and move door up or down as required. Retighten screw A.

c: Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required. Retighten screw B.

d: Sideways adjustment.

To move door 'out' loosen screw C. To move door 'in' tighten screw C.



Assembly Instructions


Step 43

Fit the overbalance protector

To prevent possible overbalancing we recommend that this unit is secured to a suitable wall by fitting of the overbalance protector kit **T** to the unit, or an alternative fixing method of your choice.

Wall fixings are not supplied as they will need to suit the wall type.


Note: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.



Assembly Instructions

Step 44

Assembly is complete



If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)
Alternatively, call the Spares Helpline on: 0370 112 1928.
For any other queries please contact the Customer Helpline on: 0345 640 2020

