

Athina - 500 Drawer Unit

Assembly Instructions - Please keep for future reference

608/0804

608/0921

608/0866

608/0983



Dimensions

Width - 50cm

Depth - 59cm

Height - 89.5cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 34kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the brackets supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the panels listed below




1 Left Side (D0315A)
(870 X 570mm)



2 Right Side (D0316A)
(870 x 570mm)




3 Top (D0338A)
(500 x 590mm)



4 Base (D0319A)
(470 X 499mm)




5 Rail (D0321A)
(470 x 60mm) x 2




7 Drawer Front (D0318A)
(497 x 176mm) x 4




6 Plinth (D0322A)
(470 x 150mm)




8 Drawer Back (W413BCK)
(422 x 120mm) x 4




9 Left Drawer Side (W413LH)
(450 x 120mm) x 4



11 Drawer Base (T413)
(447 x 433mm) x 4



10 Right Drawer Side (W413RH)
(450 x 120mm) x 4



12 Back (X739)
(480 x 533mm)




















Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 12</p>	<p>B </p> <p>Metal dowel (F901) x 18</p>	<p>C </p> <p>Large locking nut (F900) x 10</p>
<p>D </p> <p>Small locking nut (F3) x 8</p>	<p>E </p> <p>Nail (F51) x 8</p>	<p>F </p> <p>Bracket (F945) x 4</p>
<p>G </p> <p>25mm Screw (F50) x 2</p>	<p>H </p> <p>13mm Screw (F79) x 6</p>	<p>I </p> <p>13mm Screw (F63) x 32</p>
<p>J </p> <p>Door Buffer (F137) x 8</p>	<p>K </p> <p>45mm Screw (F65) x 16</p>	<p>L a  Handle (F847a) x 4</p> <p>L b  Handle Screw (F847b) x 8</p>
<p>M a  CR Runner x 4</p>		
<p>M b  CL Runner x 4</p>		
<p>M c  DR Runner x 4</p>		
<p>M d  DL Runner x 4</p>		

Tools required



Rule



Cross-head screwdriver



Scissors



Hammer




Eye protection (when using a hammer or drill)



Electric drill

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

If you have damaged or missing components, call the Customer Helpline: 08456 400800 quoting the reference numbers below



Step 1

Prepare 4 drawer fronts

Screw 2 metal dowels **B** into the holes shown on the back of each drawer front **7**.

Note: Tighten metal dowels up fully against the panels.

Stick a drawer buffer **J** into the top corners of each drawer front **7**.






Step 2

Prepare the drawer sides

Insert a small locking nut **D** into the hole shown on the left drawer side **9** and right drawer side **10**.


Note: Arrow on locking nut **must** point towards hole in edge of panel.



Step 3

Assemble drawer sides and back


Fit the left drawer side **9** and right drawer side **10** to the drawer back **8** using 4 screws **K**.



Step 4

Fit drawer base

Slide the drawer base **11** along the grooves of the drawer sides **9** and **10** into the groove of the drawer back **8**.




Assembly Instructions

Step 5

Attach drawer front

Turn the drawer assembly over and push onto the back of the drawer front **7**.


Note: Turn locking nuts **D** clockwise to secure panels - more than 1/2 a turn.



Step 6

Attach 2 handles

Attach each handle **L a** to the drawer fronts **7** using 2 screws **L b**




Step 7

Fit runners to the drawers

Turn the 4 drawer assemblies over.

Fit runner **M c**, marked with 'DR', to the bottom edge of the right drawer side **10**, making sure that it is pushed up against the back of the drawer front **7**. Use a bradawl to mark the fixing positions, then secure with 2 screws **I**.

Fit runner **M d**, marked 'DL', to the bottom edge of the left drawer side **9** using the same method.



Assembly Instructions

Step 8



Fit 2 brackets to the left side

Fit a bracket **F** to the left side **1**, 100mm in from the back edge, see diagram.

Fit another bracket **F** to the left side **1**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.




Step 9

Fit runners to the left side

Fit the 4 runners **M b** marked 'CL' to the left side **1**.

The 1st screw **I** uses the 2nd hole in from the front of the runner.

The 2nd screw **I** uses the 6th hole in from the back of the runner.




Step 10

Fit metal dowels to the left side

Screw 5 metal dowels **B** into the holes shown on the left side **1**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 11


Fit 2 brackets to the right side

Fit a bracket **F** to the right side **2**, 100mm down from the back edge, see diagram.

Fit another bracket **F** to the right side **2**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.




Step 12

Fit runners to the right side

Fit the 4 runners **Ma** marked 'CR' to the right side **2**.

The 1st screw **I** uses the 2nd hole in from the front of the runner.

The 2nd screw **I** uses the 6th hole in from the back of the runner.




Step 13

Fit metal dowels to the right side

Screw 5 metal dowels **B** into the holes shown on the right side **2**.

Note: Tighten metal dowels up fully against



Assembly Instructions

Step 14




Prepare the base

Insert 4 large locking nuts **C** into the base **4** as shown.

Note: Arrow on locking nut **must** point towards hole in edge of panel.

Tap 6 wooden dowels **A** into the base **4** as shown.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.





Step 15

Fit the base to the right side

Push the base **4** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base **4**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Step 16

Prepare the 2 rails and plinth

Insert 2 large locking nuts **C** into each of the 2 rails **5** and plinth **6** as shown.

Tap 2 wooden dowels **A** into the 2 rails **5** and plinth **6** as shown.



Assembly Instructions

Step 17


Fit the 2 rails and plinth

One at a time, push the 2 rails **5** and plinth **6** onto the right side **2** as shown.

Use a screwdriver to tighten the 3 large locking nuts **C** fitted to the 3 panels, as shown.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.

Note: Support the rail near the back edge of the unit until the left side has been fitted in the next stage.




Step 18

Fit the left side

Push the left side **1** onto the assembly.

Use a screwdriver to tighten the 5 large locking nuts **C** fitted to the base **4**, rails **5** and plinth **6**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Assembly Instructions

Step 19

Fit the back



a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

b: Slide the back **12** into the grooves along the left **1** and right **2** sides, as shown.

c: Secure the back **12** by tapping 4 nails **E** down into the back edge of the base **4** and 4 nails **E** into the back edge of the rail **5**.

Stand the unit up for the next stage.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




Assembly Instructions

Step 20

Fit the top

Position the top **3** onto the unit, making sure that the back edge is flush with the back edge of the sides **1** and **2**.


Secure the top **3** using screw **H** through the 2 brackets **F** fitted at the top edge of the side panels **1** and **2**.



Step 21

Secure the front of the top

To secure the front of the top **3**, screw up through the 2 holes in the rail **5** at the front of the unit using screws **G**.



Assembly Instructions

Step 22


Secure the unit to the wall

Using the brackets **F** fitted to the back edge of the sides **1** and **2** screw the unit to the wall.

Fixings are not supplied as they will need to suit the wall type, and the length of screw will depend on the distance of the back of the Unit to the wall.





Warning: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.



Step 23

Fit the drawers

Slide the wheels on the runners fitted to the drawer sides over the wheels on the runners fitted to the side panels and push the drawer into position.




Assembly Instructions

Step 24

Assembly is complete



Warning: The unit is heavy. Lift with care.



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

Athina - 500 Drawer Unit

Assembly Instructions - Please keep for future reference

608/0804

608/0921

608/0866

608/0983

608/2974



Dimensions

Width - 50cm

Depth - 59cm

Height - 89.5cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 34kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the brackets supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the panels listed below




1 Left Side (D0315B)
(870 X 570mm)



2 Right Side (D0316B)
(870 x 570mm)




3 Top (D0338A)
(500 x 590mm)



4 Base (D0319A)
(470 X 499mm)




5 Rail (D0321A)
(470 x 60mm) x 2




7 Drawer Front (D0318A)
(497 x 176mm) x 4




6 Plinth (D0322A)
(470 x 150mm)




8 Drawer Back (W413BCK)
(422 x 120mm) x 4




9 Left Drawer Side (W413LH)
(450 x 120mm) x 4



11 Drawer Base (T413)
(447 x 433mm) x 4



12 Back (X739)
(480 x 533mm)



10 Right Drawer Side (W413RH)
(450 x 120mm) x 4




















Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 12</p>	<p>B </p> <p>Metal dowel (F901) x 18</p>	<p>C </p> <p>Large locking nut (F900) x 10</p>
<p>D </p> <p>Small locking nut (F3) x 8</p>	<p>E </p> <p>Nail (F51) x 8</p>	<p>F </p> <p>Bracket (F945) x 4</p>
<p>G </p> <p>25mm Screw (F50) x 2</p>	<p>H </p> <p>13mm Screw (F79) x 6</p>	<p>I </p> <p>13mm Screw (F63) x 16</p>
<p>J </p> <p>Door Buffer (F137) x 8</p>	<p>K </p> <p>45mm Screw (F65) x 16</p>	<p>L </p> <p>13mm Screw (F52) x 16</p>
<p>M a  CR Runner (F133) x 4</p> <p>M b  CL Runner (F134) x 4</p> <p>M c  DR Runner (F135) x 4</p> <p>M d  DL Runner (F136) x 4</p>		<p>N a Handle (F847a) x 4</p> <p>N b Handle Screw (F847b) x 8</p> 

Tools required



Rule



Scissors



Cross-head screwdriver



Hammer




Eye protection (when using a hammer or drill)



Electric drill

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below



Step 1

Prepare 4 drawer fronts

Screw 2 metal dowels **B** into the holes shown on the back of each drawer front **7**.

Note: Tighten metal dowels up fully against the panels.

Stick a drawer buffer **J** into the top corners of each drawer front **7**.






Step 2

Prepare the drawer sides

Insert a small locking nut **D** into the hole shown on the left drawer side **9** and right drawer side **10**.


Note: Arrow on locking nut **must** point towards hole in edge of panel.



Step 3

Assemble drawer sides and back


Fit the left drawer side **9** and right drawer side **10** to the drawer back **8** using 4 screws **K**.



Step 4

Fit drawer base

Slide the drawer base **11** along the grooves of the drawer sides **9** and **10** into the groove of the drawer back **8**.




Assembly Instructions

Step 5

Attach drawer front

Turn the drawer assembly over and push onto the back of the drawer front **7**.


Note: Turn locking nuts **D** clockwise to secure panels - more than 1/2 a turn.



Step 6

Attach 2 handles

Attach each handle **N a** to the drawer fronts **7** using 2 screws **N b**




Step 7

Fit runners to the drawers

Turn the 4 drawer assemblies over.

Fit runner **M c**, marked with 'DR', to the bottom edge of the right drawer side **10**, making sure that it is pushed up against the back of the drawer front **7**. Use a bradawl to mark the fixing positions, then secure with 2 screws **I**.

Fit runner **M d**, marked 'DL', to the bottom edge of the left drawer side **9** using the same method.



Assembly Instructions

Step 8



Fit 2 brackets to the left side

Fit a bracket **F** to the left side **1**, 100mm in from the back edge, see diagram.

Fit another bracket **F** to the left side **1**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.




Step 9

Fit runners to the left side

Fit the 4 runners **M b** marked 'CL' to the left side **1**.

The 1st screw **L** uses the 2nd hole in from the front of the runner.

The 2nd screw **L** uses the 4th hole in from the back of the runner.




Step 10

Fit metal dowels to the left side

Screw 5 metal dowels **B** into the holes shown on the left side **1**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 11


Fit 2 brackets to the right side

Fit a bracket **F** to the right side **2**, 100mm down from the back edge, see diagram.

Fit another bracket **F** to the right side **2**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.




Step 12

Fit runners to the right side

Fit the 4 runners **Ma** marked 'CR' to the right side **2**.

The 1st screw **L** uses the 2nd hole in from the front of the runner.

The 2nd screw **L** uses the 4th hole in from the back of the runner.




Step 13

Fit metal dowels to the right side

Screw 5 metal dowels **B** into the holes shown on the right side **2**.

Note: Tighten metal dowels up fully against



Assembly Instructions

Step 14




Prepare the base

Insert 4 large locking nuts **C** into the base **4** as shown.

Note: Arrow on locking nut **must** point towards hole in edge of panel.

Tap 6 wooden dowels **A** into the base **4** as shown.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.





Step 15

Fit the base to the right side

Push the base **4** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base **4**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Step 16

Prepare the 2 rails and plinth

Insert 2 large locking nuts **C** into each of the 2 rails **5** and plinth **6** as shown.

Tap 2 wooden dowels **A** into the 2 rails **5** and plinth **6** as shown.



Assembly Instructions

Step 17


Fit the 2 rails and plinth

One at a time, push the 2 rails **5** and plinth **6** onto the right side **2** as shown.

Use a screwdriver to tighten the 3 large locking nuts **C** fitted to the 3 panels, as shown.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.

Note: Support the rail near the back edge of the unit until the left side has been fitted in the next stage.




Step 18

Fit the left side

Push the left side **1** onto the assembly.

Use a screwdriver to tighten the 5 large locking nuts **C** fitted to the base **4**, rails **5** and plinth **6**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Assembly Instructions

Step 19

Fit the back



a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

b: Slide the back **12** into the grooves along the left **1** and right **2** sides, as shown.

c: Secure the back **12** by tapping 4 nails **E** down into the back edge of the base **4** and 4 nails **E** into the back edge of the rail **5**.

Stand the unit up for the next stage.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




Assembly Instructions

Step 20

Fit the top

Position the top **3** onto the unit, making sure that the back edge is flush with the back edge of the sides **1** and **2**.


Secure the top **3** using screw **H** through the 2 brackets **F** fitted at the top edge of the side panels **1** and **2**.



Step 21

Secure the front of the top

To secure the front of the top **3**, screw up through the 2 holes in the rail **5** at the front of the unit using screws **G**.



Assembly Instructions

Step 22


Secure the unit to the wall

Using the brackets **F** fitted to the back edge of the sides **1** and **2** screw the unit to the wall.

Fixings are not supplied as they will need to suit the wall type, and the length of screw will depend on the distance of the back of the Unit to the wall.





Warning: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.



Step 23

Fit the drawers

Slide the wheels on the runners fitted to the drawer sides over the wheels on the runners fitted to the side panels and push the drawer into position.




Assembly Instructions

Step 24

Assembly is complete



Warning: The unit is heavy. Lift with care.



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

Athina - 500 Drawer Unit

Assembly Instructions - Please keep for future reference


608/0804

608/0921

608/0866

608/0983

608/2974



Dimensions

Width - 50cm

Depth - 59cm

Height - 89.5cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 34kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the brackets supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 03456 400800** quoting the reference numbers below

Please check you have all the panels listed below




1 Left Side (D0315B)
(870 X 570mm)



2 Right Side (D0316B)
(870 x 570mm)




3 Top (D0338A)
(500 x 590mm)



4 Base (D0319A)
(470 X 499mm)



5 Rail (D0321A)
(470 x 60mm) x 2



7 Drawer Front (D0318A)
(497 x 176mm) x 4




6 Plinth (D0322A)
(470 x 150mm)




8 Drawer Back (W422-120)
(422 x 120mm) x 4



9 Left Drawer Side (W450-120LH)
(450 x 120mm) x 4



11 Drawer Base (T413)
(447 x 433mm) x 4



12 Back (X739)
(480 x 533mm)



10 Right Drawer Side (W450-120RH)
(450 x 120mm) x 4




















Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 03456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 12</p>	<p>B </p> <p>Metal dowel (F901) x 18</p>	<p>C </p> <p>Large locking nut (F900) x 10</p>
<p>D </p> <p>Small locking nut (F3) x 8</p>	<p>E </p> <p>Nail (F51) x 8</p>	<p>F </p> <p>Bracket (F945) x 4</p>
<p>G </p> <p>25mm Screw (F50) x 2</p>	<p>H </p> <p>13mm Screw (F79) x 6</p>	<p>I </p> <p>13mm Screw (F63) x 16</p>
<p>J </p> <p>Door Buffer (F137) x 8</p>	<p>K </p> <p>Knock-in Peg (F171GY) x 16</p>	<p>L </p> <p>13mm Screw (F52) x 16</p>
<p>M a  CR Runner (F133) x 4</p> <p>M b  CL Runner (F134) x 4</p> <p>M c  DR Runner (F135) x 4</p> <p>M d  DL Runner (F136) x 4</p>		<p>N a Handle (F847a) x 4</p> <p>N b Handle Screw (F847b) x 8</p> 

Tools required



Rule



Scissors



Cross-head screwdriver



Hammer



Eye protection (when using a hammer or drill)



Electric drill

Ruler - Use this ruler to help correctly identify the screws

mm 10 20 30 40 50 60 70 80 90 100 110 120 130 140 150 160 170

Assembly Instructions

If you have damaged or missing components, call the
Customer Helpline: 03456 400800 quoting the reference
numbers below


Step 1

Prepare 4 drawer fronts

Screw 2 metal dowels **B** into the holes shown on the back of each drawer front **7**.

Note: Tighten metal dowels up fully against the panels.

Stick a drawer buffer **J** into the top corners of each drawer front **7**.




Step 2

Prepare the drawer sides

Insert a small locking nut **D** into the hole shown on the left drawer side **9** and right drawer side **10**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Step 3

Attach the drawer sides to the drawer fronts

Push the left drawer side **9** and right drawer side **10** onto the back of the drawer front **7**.

Turn the small locking nuts **D** on the left drawer side **9** and right drawer side **10**.

Note: Turn the locking nuts **D** clockwise to secure panels - more than 1/2 a turn.




Assembly Instructions

Step 4

Fit the drawer bases

Slide the drawer base **11** down the grooves in the drawer sides **9** and **10** and down into the groove in the drawer front **7**.




Step 5

Fit the drawer backs

Fit the drawer back **8** between the drawer sides **9** and **10**.

Make sure that the drawer base **11** fits into the groove in the drawer back **8**.


Hold the drawer back **8** in position and tap the knock-in pegs **K** through the holes in the drawer sides **9** and **10**.



Step 6

Attach the handles

Attach a handle **Na** to each drawer front **7** using 2 screws **Nb**.



Assembly Instructions


Step 7

Fit runners to the drawers

Turn the 4 drawer assemblies over.

Fit runner **Mc**, marked with 'DR', to the bottom edge of the right drawer side **10**, making sure that it is pushed up against the back of the drawer front **7**. Use a bradawl to mark the fixing positions, then secure with 2 screws **I**.

Fit runner **Md**, marked 'DL', to the bottom edge of the left drawer side **9** using the same method.



Assembly Instructions

Step 8



Fit 2 brackets to the left side

Fit a bracket **F** to the left side **1**, 100mm in from the back edge, see diagram.

Fit another bracket **F** to the left side **1**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.




Step 9

Fit runners to the left side

Fit the 4 runners **M b** marked 'CL' to the left side **1**.

The 1st screw **L** uses the 2nd hole in from the front of the runner.

The 2nd screw **L** uses the 4th hole in from the back of the runner.




Step 10

Fit metal dowels to the left side

Screw 5 metal dowels **B** into the holes shown on the left side **1**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 11


Fit 2 brackets to the right side

Fit a bracket **F** to the right side **2**, 100mm down from the back edge, see diagram.

Fit another bracket **F** to the right side **2**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.




Step 12

Fit runners to the right side

Fit the 4 runners **Ma** marked 'CR' to the right side **2**.

The 1st screw **L** uses the 2nd hole in from the front of the runner.

The 2nd screw **L** uses the 4th hole in from the back of the runner.




Step 13

Fit metal dowels to the right side

Screw 5 metal dowels **B** into the holes shown on the right side **2**.

Note: Tighten metal dowels up fully against



Assembly Instructions

Step 14




Prepare the base

Insert 4 large locking nuts **C** into the base **4** as shown.

Note: Arrow on locking nut **must** point towards hole in edge of panel.

Tap 6 wooden dowels **A** into the base **4** as shown.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.





Step 15

Fit the base to the right side

Push the base **4** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base **4**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Step 16

Prepare the 2 rails and plinth

Insert 2 large locking nuts **C** into each of the 2 rails **5** and plinth **6** as shown.

Tap 2 wooden dowels **A** into the 2 rails **5** and plinth **6** as shown.



Assembly Instructions

Step 17


Fit the 2 rails and plinth

One at a time, push the 2 rails **5** and plinth **6** onto the right side **2** as shown.

Use a screwdriver to tighten the 3 large locking nuts **C** fitted to the 3 panels, as shown.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.

Note: Support the rail near the back edge of the unit until the left side has been fitted in the next stage.




Step 18

Fit the left side

Push the left side **1** onto the assembly.

Use a screwdriver to tighten the 5 large locking nuts **C** fitted to the base **4**, rails **5** and plinth **6**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Assembly Instructions

Step 19

Fit the back



a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

b: Slide the back **12** into the grooves along the left **1** and right **2** sides, as shown.

c: Secure the back **12** by tapping 4 nails **E** down into the back edge of the base **4** and 4 nails **E** into the back edge of the rail **5**.

Stand the unit up for the next stage.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




Assembly Instructions

Step 20

Fit the top

Position the top **3** onto the unit, making sure that the back edge is flush with the back edge of the sides **1** and **2**.


Secure the top **3** using screw **H** through the 2 brackets **F** fitted at the top edge of the side panels **1** and **2**.



Step 21

Secure the front of the top

To secure the front of the top **3**, screw up through the 2 holes in the rail **5** at the front of the unit using screws **G**.



Assembly Instructions

Step 22


Secure the unit to the wall

Using the brackets **F** fitted to the back edge of the sides **1** and **2** screw the unit to the wall.

Fixings are not supplied as they will need to suit the wall type, and the length of screw will depend on the distance of the back of the Unit to the wall.





Warning: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.



Step 23

Fit the drawers

Slide the wheels on the runners fitted to the drawer sides over the wheels on the runners fitted to the side panels and push the drawer into position.




Assembly Instructions

Step 24

Assembly is complete



Warning: The unit is heavy. Lift with care.



If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

Athina - 1000 Base Unit


Assembly Instructions - Please keep for future reference

608/0811

608/0938

608/0873

608/0990



Dimensions

Width - 100cm

Depth - 59cm

Height - 89.5cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 42kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the bracket supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the panels listed below




1 Left Side (D0315A)
(870 X 570mm)



2 Right Side (D0316A)
(870 x 570mm)



3 Top (D0339A)
(1000 x 590mm)



4 Base (D0323A)
(970 X 499mm)



5 Shelf (D0324A)
(969 X 427mm)




6 Rail (D0321A)
(970 x 60mm) x 2



7 Plinth (D0322A)
(970 x 150mm)



8 Munting (D0324A)
(689 x 60mm)



9 Door (D0317A)
(716 x 497mm) x 2



10 Back (X740)
(980 x 533mm)


















Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 14</p>	<p>B </p> <p>Metal dowel (F901) x 10</p>	<p>C </p> <p>Large locking nut (F900) x 10</p>
<p>D </p> <p>Nail (F51) x 14</p>	<p>E </p> <p>Shelf support (F110) x 4</p>	<p>F </p> <p>Bracket (F945) x 4</p>
<p>G </p> <p>25mm Screw (F50) x 4</p>	<p>H </p> <p>13mm Screw (F79) x 6</p>	<p>I </p> <p>13mm Screw (F63) x 8</p>
<p>J </p> <p>Door Buffer (F137) x 4</p>	<p>K </p> <p>Hinge Plate (F853) x 4</p>	<p>L </p> <p>Hinge (F852) x 4</p>
<p>M a </p> <p>Handle (F847a) x 2</p>	<p>M b </p> <p>Handle Screw (F847b) x 4</p>	<p>N </p> <p>40mm Screw (F910) x 2</p>

Tools required



Rule




Cross-head screwdriver



Scissors



Hammer




Eye protection (when using a hammer or drill)



Electric drill

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Step 1


Fit 2 brackets to the left side

Fit a bracket **F** to the left side **1**, 100mm in from the back edge, see diagram.

Fit another bracket **F** to the left side **1**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.




Step 2

Prepare the left side

a: Fit 2 hinge plates **K** onto the left side **1**, making sure that the slot is facing towards the front edge.

b: Screw 5 metal dowels **B** into the holes shown on the left side **1**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 3



Fit 2 brackets to the right side

Fit a bracket **F** to the right side **2**, 100mm down from the back edge, see diagram.

Fit another bracket **F** to the right side **2**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.





Step 4

Prepare the right side

a: Fit 2 hinge plates **K** onto the right side **2**, making sure that the slot is facing towards the front edge.

b: Screw 5 metal dowels **B** into the holes shown on the right side **2**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 5


Prepare the base

Insert 4 large locking nuts **C** into the base **4** as shown.

Note: Arrow on locking nut **must** point towards hole in edge of panel.

Tap 6 wooden dowels **A** into the base **4** as shown.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.




Step 6

Fit the base to the right side

Push the base **4** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base **4**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Assembly Instructions

Step 7

Prepare the 2 rails and munting

Insert 2 large locking nuts **C** and 2 wooden dowels **A** into each of the 2 rails **6**.

Tap 2 wooden dowels **A** into the munting **8**.




Step 8

Fit a rail to the right side

Push one of the rails **6** onto the right side **2** as shown.

Use a screwdriver to tighten the large locking nut **C**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Assembly Instructions

Step 9

Fit the munting


Fit the munting **8** to the rail **6** and base **4** and secure using 2 screws **N**.



Step 10

Prepare the plinth

Insert 2 large locking nuts **C** and 2 wooden dowels **A** into the plinth **7**.



Assembly Instructions

Step 11


Fit the rail and plinth

Push the rail **6** and plinth **7** onto the right side **2** as shown.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the 2 panels, as shown.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.

Note: Support the rail **6** until the left side has been fitted in the next stage.




Step 12

Fit the left side

Push the left side **1** onto the assembly.

Use a screwdriver to tighten the 5 large locking nuts **C** fitted to the base **4**, rails **6** and plinth **7**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Assembly Instructions

Step 13

Fit the back



a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

b: Slide the back **10** into the grooves along the left **1** and right **2** sides, as shown.

c: Secure the back **10** by tapping 7 nails **D** down into the back edge of the base **4** and 7 nails **D** into the back edge of the rail **6**.

Stand the unit up for the next stage.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




Assembly Instructions

Step 14

Fit the top

Position the top **3** onto the unit, making sure that the back edge is flush with the back edge of the sides **1** and **2**.


Secure the top **3** using screw **H** through the 2 brackets **F** fitted at the top edge of the side panels **1** and **2**.



Step 15

Secure the front of the top

To secure the front of the top **3**, screw up through the 4 holes in the rail **6** at the front of the unit using screws **G**.



Assembly Instructions

Step 16


Secure the unit to the wall

Using the brackets **F** fitted to the back edge of the sides **1** and **2** screw the unit to the wall.

Fixings are not supplied as they will need to suit the wall type, and the length of screw will depend on the distance of the back of the Unit to the wall.




Warning: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.



Step 17

Fit the shelf studs

Push 4 shelf studs **E** into the holes in the side panels **1** and **2** at the desired height.




Assembly Instructions

Step 18

Fit the shelf

Manouvre the shelf **5** into the unit onto the shelf studs **E**.




Step 19

Prepare the 2 doors

Push fit the 2 hinges **L** into the door **9**.

Secure each hinge with 2 screws **I**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the front edge of the door.



Assembly Instructions

Step 20

Drill the handle holes in the door

Important: Please follow these instructions carefully.

Lay the doors **9** down onto a smooth surface.


Important: Check that the holes and hinges are in the same place as the diagrams.

Note: We recommend the use of a small piece of waste wood, placed behind the hole while drilling, to reduce the possibility of any breakout.


Using the pilot hole in the rear face of the door **9**, drill through the holes indicated opposite, using a 2.5mm diameter drill.

Turn the door **9** over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.

This will be the left door



This will be the right door



Assembly Instructions

Step 21

Fit doors and handles

2 people are needed here

Note: The easiest way to attach the door **9** is to fit the top hinge first, then align and fit the other hinges.



a: Push the hinge **L** onto the front part of the hinge plate **K**.

b: Keep the hinge **L** FLAT against the hinge plate **K** as you slide it across as far as it will go. Tighten screw A.

c: The hinge **L** must be flat against the hinge plate **K** prior to any adjustment.

d: The hinge **L** must NOT be AT AN ANGLE to the hinge plate **K** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **M a** to the door **9** using 2 screws **M b**.



Assembly Instructions

Step 22

Adjust the doors if needed

a: Height adjustment.


Loosen screws A on hinge plates and move door up or down as required.
Retighten screw A.

b: Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required.
Retighten screw B.

c: Sideways adjustment.


To move door 'out' loosen screw C.
To move door 'in' tighten screw C



Step 23

Fit the door buffers to both doors

Stick a door buffer **J** onto each corner of the door **9** so that they hit the edge of the side panel when the door is closed.




Assembly Instructions

Step 24

Assembly is complete



Warning: The unit is heavy. Lift with care.



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

Athina - 1000 Base Unit

Assembly Instructions - Please keep for future reference


608/0811

608/0938

608/0873

608/0990

608/2981



Dimensions

Width - 100cm

Depth - 59cm

Height - 89.5cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 42kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the brackets supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the panels listed below




1 Left Side (D0315B)
(870 X 570mm)



2 Right Side (D0316B)
(870 x 570mm)



3 Top (D0339A)
(1000 x 590mm)



4 Base (D0323A)
(970 X 499mm)



5 Shelf (D0324A)
(969 X 427mm)



6 Rail (D0325A)
(970 x 60mm) x 2



7 Plinth (D0326A)
(970 x 150mm)



8 Munting (D0327A)
(689 x 59mm)



9 Door (D0317A)
(716 x 497mm) x 2



10 Back (X740)
(980 x 533mm)


















Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 14</p>	<p>B </p> <p>Metal dowel (F901) x 10</p>	<p>C </p> <p>Large locking nut (F900) x 10</p>
<p>D </p> <p>Nail (F51) x 14</p>	<p>E </p> <p>Shelf support (F110) x 4</p>	<p>F </p> <p>Bracket (F945) x 4</p>
<p>G </p> <p>25mm Screw (F50) x 4</p>	<p>H </p> <p>13mm Screw (F79) x 6</p>	<p>I </p> <p>13mm Screw (F63) x 8</p>
<p>J </p> <p>Door Buffer (F137) x 4</p>	<p>K </p> <p>Hinge Plate (F853) x 4</p>	<p>L </p> <p>Hinge (F852) x 4</p>
<p>M a </p> <p>Handle (F847a) x 2</p>	<p>M b </p> <p>Handle Screw (F847b) x 4</p>	<p>N </p> <p>40mm Screw (F910) x 2</p>

Tools required



Rule



Cross-head screwdriver



Scissors



Hammer



Eye protection (when using a hammer or drill)



Electric drill

Ruler - Use this ruler to help correctly identify the screws

mm 10 20 30 40 50 60 70 80 90 100 110 120 130 140 150 160 170

Assembly Instructions

If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Step 1


Fit 2 brackets to the left side

Fit a bracket **F** to the left side **1**, 100mm in from the back edge, see diagram.

Fit another bracket **F** to the left side **1**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.




Step 2

Prepare the left side

a: Fit 2 hinge plates **K** onto the left side **1**, making sure that the slot is facing towards the front edge.

b: Screw 5 metal dowels **B** into the holes shown on the left side **1**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 3



Fit 2 brackets to the right side

Fit a bracket **F** to the right side **2**, 100mm down from the back edge, see diagram.

Fit another bracket **F** to the right side **2**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.





Step 4

Prepare the right side

a: Fit 2 hinge plates **K** onto the right side **2**, making sure that the slot is facing towards the front edge.

b: Screw 5 metal dowels **B** into the holes shown on the right side **2**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 5


Prepare the base

Insert 4 large locking nuts **C** into the base **4** as shown.

Note: Arrow on locking nut **must** point towards hole in edge of panel.

Tap 6 wooden dowels **A** into the base **4** as shown.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.




Step 6

Fit the base to the right side

Push the base **4** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base **4**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Assembly Instructions

Step 7

Prepare the 2 rails and munting

Insert 2 large locking nuts **C** and 2 wooden dowels **A** into each of the 2 rails **6**.

Tap 2 wooden dowels **A** into the munting **8**.




Step 8

Fit a rail to the right side

Push one of the rails **6** onto the right side **2** as shown.

Use a screwdriver to tighten the large locking nut **C**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Assembly Instructions

Step 9

Fit the munting


Fit the munting **8** to the rail **6** and base **4** and secure using 2 screws **N**.



Step 10

Prepare the plinth

Insert 2 large locking nuts **C** and 2 wooden dowels **A** into the plinth **7**.



Assembly Instructions

Step 11


Fit the rail and plinth

Push the rail **6** and plinth **7** onto the right side **2** as shown.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the 2 panels, as shown.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.

Note: Support the rail **6** until the left side has been fitted in the next stage.




Step 12

Fit the left side

Push the left side **1** onto the assembly.

Use a screwdriver to tighten the 5 large locking nuts **C** fitted to the base **4**, rails **6** and plinth **7**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Assembly Instructions

Step 13

Fit the back



a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

b: Slide the back **10** into the grooves along the left **1** and right **2** sides, as shown.

c: Secure the back **10** by tapping 7 nails **D** down into the back edge of the base **4** and 7 nails **D** into the back edge of the rail **6**.

Stand the unit up for the next stage.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




Assembly Instructions

Step 14

Fit the top

Position the top **3** onto the unit, making sure that the back edge is flush with the back edge of the sides **1** and **2**.


Secure the top **3** using screw **H** through the 2 brackets **F** fitted at the top edge of the side panels **1** and **2**.



Step 15

Secure the front of the top

To secure the front of the top **3**, screw up through the 4 holes in the rail **6** at the front of the unit using screws **G**.



Assembly Instructions

Step 16


Secure the unit to the wall

Using the brackets **F** fitted to the back edge of the sides **1** and **2** screw the unit to the wall.

Fixings are not supplied as they will need to suit the wall type, and the length of screw will depend on the distance of the back of the Unit to the wall.




Warning: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.



Step 17

Fit the shelf studs

Push 4 shelf studs **E** into the holes in the side panels **1** and **2** at the desired height.




Assembly Instructions

Step 18

Fit the shelf

Manouvre the shelf **5** into the unit onto the shelf studs **E**.




Step 19

Prepare the 2 doors

Push fit the 2 hinges **L** into the door **9**.

Secure each hinge with 2 screws **I**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the front edge of the door.



Assembly Instructions

Step 20

Drill the handle holes in the door

Important: Please follow these instructions carefully.

Lay the doors **9** down onto a smooth surface.

Important: Check that the holes and hinges are in the same place as the diagrams.


Note: We recommend the use of a small piece of waste wood, placed behind the hole while drilling, to reduce the possibility of any breakout.

Using the pilot hole in the rear face of the door **9**, drill through the holes indicated opposite, using a 2.5mm diameter drill.


Turn the door **9** over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.

IMPORTANT Carefully choose which 2 holes you need to drill in each of the doors

This will be the left door



This will be the right door



Assembly Instructions

Step 21

Fit doors and handles

2 people are needed here

Note: The easiest way to attach the door **9** is to fit the top hinge first, then align and fit the other hinges.



a: Push the hinge **L** onto the front part of the hinge plate **K**.

b: Keep the hinge **L** FLAT against the hinge plate **K** as you slide it across as far as it will go. Tighten screw A.

c: The hinge **L** must be flat against the hinge plate **K** prior to any adjustment.

d: The hinge **L** must NOT be AT AN ANGLE to the hinge plate **K** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **M a** to the door **9** using 2 screws **M b**.



Assembly Instructions

Step 22

Adjust the doors if needed

a: Height adjustment.

Loosen screws A on hinge plates and move door up or down as required.

Retighten screw A.

b: Forward and Back adjustment.


Loosen screw B on hinge plate and move door in or out as required.

Retighten screw B.

c: Sideways adjustment.

To move door 'out' loosen screw C.


To move door 'in' tighten screw C



Step 23

Fit the door buffers to both doors

Stick a door buffer **J** onto each corner of the door **9** so that they hit the edge of the side panel when the door is closed.




Assembly Instructions

Step 24

Assembly is complete



Warning: The unit is heavy. Lift with care.



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

Athina - 1000 Sink Unit


Assembly Instructions - Please keep for future reference

656/4069

656/4083

656/4076

656/4090



Dimensions

Width - 100cm

Depth - 59cm

Height - 89.5cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 36kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the bracket supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below


Please check you have all the panels listed below




1 Left Side (D0315A)
(870 X 570mm)



2 Right Side (D0316A)
(870 x 570mm)



3 Sink Top (D0340A)
(1000 x 590mm)



4 Base (D0323A)
(970 X 499mm)



5 Shelf (D0324A)
(969 X 427mm)




6 Rail (D0325A)
(970 x 60mm) x 2



7 Plinth (D0326A)
(970 x 150mm)



8 Munting (D0327A)
(689 x 60mm)



9 Door (D0317A)
(716 x 497mm) x 2



10 Back (X740)
(980 x 533mm)


















Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 14</p>	<p>B </p> <p>Metal dowel (F901) x 10</p>	<p>C </p> <p>Large locking nut (F900) x 10</p>
<p>D </p> <p>Nail (F51) x 14</p>	<p>E </p> <p>Shelf support (F110) x 4</p>	<p>F </p> <p>Bracket (F945) x 4</p>
<p>G </p> <p>25mm Screw (F50) x 4</p>	<p>H </p> <p>13mm Screw (F79) x 6</p>	<p>I </p> <p>13mm Screw (F63) x 8</p>
<p>J </p> <p>Door Buffer (F137) x 4</p>	<p>K </p> <p>Hinge Plate (F853) x 4</p>	<p>L </p> <p>Hinge (F852) x 4</p>
<p>M a </p> <p>Handle (F847a) x 2</p>	<p>M b </p> <p>Handle Screw (F847b) x 4</p>	<p>N </p> <p>40mm Screw (F910) x 2</p>

Tools required



Rule



Flat-head screwdriver




Cross-head screwdriver



Scissors



Hammer



Eye protection (when using a hammer or drill)



Electric drill

Ruler - Use this ruler to help correctly identify the screws

mm 10 20 30 40 50 60 70 80 90 100 110 120 130 140 150 160 170

Assembly Instructions

If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Step 1


Fit 2 brackets to the left side

Fit a bracket **F** to the left side **1**, 100mm in from the back edge, see diagram.

Fit another bracket **F** to the left side **1**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.




Step 2

Prepare the left side

a: Fit 2 hinge plates **K** onto the left side **1**, making sure that the slot is facing towards the front edge.

b: Screw 5 metal dowels **B** into the holes shown on the left side **1**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 3



Fit 2 brackets to the right side

Fit a bracket **F** to the right side **2**, 100mm down from the back edge, see diagram.

Fit another bracket **F** to the right side **2**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.





Step 4

Prepare the right side

a: Fit 2 hinge plates **K** onto the right side **2**, making sure that the slot is facing towards the front edge.

b: Screw 5 metal dowels **B** into the holes shown on the right side **2**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 5


Prepare the base

Insert 4 large locking nuts **C** into the base **4** as shown.

Note: Arrow on locking nut **must** point towards hole in edge of panel.

Tap 6 wooden dowels **A** into the base **4** as shown.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.




Step 6

Fit the base to the right side

Push the base **4** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base **4**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Assembly Instructions

Step 7

Prepare the 2 rails and munting

Insert 2 large locking nuts **C** and 2 wooden dowels **A** into each of the 2 rails **6**.

Tap 2 wooden dowels **A** into the munting **8**.




Step 8

Fit a rail to the right side

Push one of the rails **6** onto the right side **2** as shown.

Use a screwdriver to tighten the large locking nut **C**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Assembly Instructions

Step 9

Fit the munting


Fit the munting **8** to the rail **6** and base **4** and secure using 2 screws **N**.



Step 10

Prepare the plinth

Insert 2 large locking nuts **C** and 2 wooden dowels **A** into the plinth **7**.



Assembly Instructions

Step 11


Fit the rail and plinth

Push the rail **6** and plinth **7** onto the right side **2** as shown.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the 2 panels, as shown.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.

Note: Support the rail **6** until the left side has been fitted in the next stage.




Step 12

Fit the left side

Push the left side **1** onto the assembly.

Use a screwdriver to tighten the 5 large locking nuts **C** fitted to the base **4**, rails **6** and plinth **7**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Assembly Instructions

Step 13



Fit the back

a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

b: Slide the back **10** into the grooves along the left **1** and right **2** sides, as shown.

c: Secure the back **10** by tapping 7 nails **D** down into the back edge of the base **4** and 7 nails **D** into the back edge of the rail **6**.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




Assembly Instructions

Step 14

Fit the top

Position the top **3** onto the unit, making sure that the back edge is flush with the back edge of the sides **1** and **2**.


Secure the top **3** using screw **H** through the 2 brackets **F** fitted at the top edge of the side panels **1** and **2**.



Step 15

Secure the front of the top

To secure the front of the top **3**, screw up through the 4 holes in the rail **6** at the front of the unit using screws **G**.



Assembly Instructions

Step 16


Secure the unit to the wall

Using the brackets **F** fitted to the back edge of the sides **1** and **2** screw the unit to the wall.

Fixings are not supplied as they will need to suit the wall type, and the length of screw will depend on the distance of the back of the Unit to the wall.




Warning: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.



Step 17

Fit the shelf studs

Push 4 shelf studs **E** into the holes in the side panels **1** and **2** at the desired height.




Assembly Instructions

Step 18

Fit the shelf

Manouvre the shelf **5** into the unit onto the shelf studs **E**.




Step 19

Prepare the 2 doors

Push fit the 2 hinges **L** into the door **9**.

Secure each hinge with 2 screws **I**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the front edge of the door.



Assembly Instructions

Step 20

Drill the handle holes in the doors

Important: Please follow these instructions carefully.

Lay the doors **9** down onto a smooth surface.


Important: Check that the holes and hinges are in the same place as the diagrams.

Note: We recommend the use of a small piece of waste wood, placed behind the hole while drilling, to reduce the possibility of any breakout.


Using the pilot hole in the rear face of the door **9**, drill through the holes indicated opposite, using a 2.5mm diameter drill.

Turn the door **9** over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.

This will be the left door



This will be the right door



Assembly Instructions

Step 21

Fit doors and handles

2 people are needed here

Note: The easiest way to attach the door **9** is to fit the top hinge first, then align and fit the other hinges.



a: Push the hinge **L** onto the front part of the hinge plate **K**.

b: Keep the hinge **L** FLAT against the hinge plate **K** as you slide it across as far as it will go. Tighten screw A.

c: The hinge **L** must be flat against the hinge plate **K** prior to any adjustment.

d: The hinge **L** must NOT be AT AN ANGLE to the hinge plate **K** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **M a** to the door **9** using 2 screws **M b**.



Assembly Instructions

Step 22

Adjust the doors if needed

a: Height adjustment.


Loosen screws A on hinge plates and move door up or down as required.
Retighten screw A.

b: Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required.
Retighten screw B.

c: Sideways adjustment.


To move door 'out' loosen screw C.
To move door 'in' tighten screw C



Step 23

Fit the door buffers to both doors

Stick a door buffer **J** onto each corner of the door **9** so that they hit the edge of the side panel when the door is closed.



Assembly Instructions

Step 24

Sink Care, Maintenance and Assembly Instructions

Your sink is made of the finest quality stainless steel (CrNi 18/10), DIN1.4301 or AISI 304 (suitable for food contact).

Keep your sink looking as good as new by following the care and maintenance instructions.

Instructions

For everyday cleaning of the sink, use household detergents suitable for stainless steel. After each use, rinse the sink with warm water then wipe with a soft dry cloth.

- Do not use wire wool.
- Do not use chemical 'silver cleaners', bleaches or detergents containing chlorine or any of its derivatives.



Warning!

- If the sink comes into contact with acidic materials, rinse immediately with plenty of water and wipe with a soft, dry cloth.
- Do not leave rusty objects in contact with the sink. Rust can cause staining, cracking or even permanent damage to the sink surface.
- To avoid staining of the surface do not leave food or other materials with corrosive properties such as juices, salt, vinegar, mustard etc. on the sink for a long time.
- Do not place very hot objects directly on the sink. Place them on a special surface (board) made from wood or plastic etc.
- Avoid scraping the sink basin or draining board with utensils.
- Avoid dropping heavy or sharp objects onto the sink surface.

Step 25

Fit the seal tape

Adhere the seal tape around the underside of the edge of the sink, being careful to lay it smoothly (without ridges).





Step 26


Fit the anchor braces

Place the anchor braces vertically and pull them up to lock into their horizontal position.

Also refer to step 27.



NOTE: Do not attach the anchor brace which will be positioned at the front middle of the unit.



Assembly Instructions

Step 27

Secure the sink to the top.

These anchor braces are designed for use with counter tops 30-40mm thick (a).

If your counter top is thinner, you may need to insert wooden wedges between the counter top and the braces so as to secure them (b).

After placing two at each corner of the sink, place the rest evenly spaced around the perimeter of the sink.

It is advisable to screw the wooden wedges into the underside of the counter top to avoid any movement when tightening the anchor braces. Please take care that the length of the screw used is **5mm less than** the counter top and wooden wedge put together.




Tighten the screws of the anchor braces (with a hand screwdriver), to secure the sink in place.

If you are unsure about plumbing, please consult a qualified plumber.



Warning: The unit is heavy. Lift with care.

Assembly is complete



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

Athina - 1000 Sink Unit

Assembly Instructions - Please keep for future reference


656/4069

656/4083

656/4076

656/4090

633/3726



Dimensions

Width - 100cm

Depth - 59cm

Height - 89.5cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 36kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the bracket supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below


Please check you have all the panels listed below




1 Left Side (D0315B)
(870 X 570mm)



2 Right Side (D0316B)
(870 x 570mm)



3 Sink Top (D0340A)
(1000 x 590mm)



4 Base (D0323A)
(970 X 499mm)



5 Shelf (D0324A)
(969 X 427mm)




6 Rail (D0325A)
(970 x 60mm) x 2



7 Plinth (D0326A)
(970 x 150mm)



8 Munting (D0327A)
(689 x 60mm)



9 Door (D0317A)
(716 x 497mm) x 2



10 Back (X740)
(980 x 533mm)


















Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 14</p>	<p>B </p> <p>Metal dowel (F901) x 10</p>	<p>C </p> <p>Large locking nut (F900) x 10</p>
<p>D </p> <p>Nail (F51) x 14</p>	<p>E </p> <p>Shelf support (F110) x 4</p>	<p>F </p> <p>Bracket (F945) x 4</p>
<p>G </p> <p>25mm Screw (F50) x 4</p>	<p>H </p> <p>13mm Screw (F79) x 6</p>	<p>I </p> <p>13mm Screw (F63) x 8</p>
<p>J </p> <p>Door Buffer (F137) x 4</p>	<p>K </p> <p>Hinge Plate (F853) x 4</p>	<p>L </p> <p>Hinge (F852) x 4</p>
<p>M a </p> <p>Handle (F847a) x 2</p>	<p>M b </p> <p>Handle Screw (F847b) x 4</p>	<p>N </p> <p>40mm Screw (F910) x 2</p>

Tools required



Rule



Flat-head screwdriver



Cross-head screwdriver



Scissors



Hammer



Eye protection (when using a hammer or drill)



Electric drill

Ruler - Use this ruler to help correctly identify the screws

mm 10 20 30 40 50 60 70 80 90 100 110 120 130 140 150 160 170

Assembly Instructions

If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Step 1


Fit 2 brackets to the left side

Fit a bracket **F** to the left side **1**, 100mm in from the back edge, see diagram.

Fit another bracket **F** to the left side **1**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.




Step 2

Prepare the left side

a: Fit 2 hinge plates **K** onto the left side **1**, making sure that the slot is facing towards the front edge.

b: Screw 5 metal dowels **B** into the holes shown on the left side **1**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 3



Fit 2 brackets to the right side

Fit a bracket **F** to the right side **2**, 100mm down from the back edge, see diagram.

Fit another bracket **F** to the right side **2**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.





Step 4

Prepare the right side

a: Fit 2 hinge plates **K** onto the right side **2**, making sure that the slot is facing towards the front edge.

b: Screw 5 metal dowels **B** into the holes shown on the right side **2**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 5


Prepare the base

Insert 4 large locking nuts **C** into the base **4** as shown.

Note: Arrow on locking nut **must** point towards hole in edge of panel.

Tap 6 wooden dowels **A** into the base **4** as shown.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.




Step 6

Fit the base to the right side

Push the base **4** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base **4**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Assembly Instructions

Step 7

Prepare the 2 rails and munting

Insert 2 large locking nuts **C** and 2 wooden dowels **A** into each of the 2 rails **6**.

Tap 2 wooden dowels **A** into the munting **8**.




Step 8

Fit a rail to the right side

Push one of the rails **6** onto the right side **2** as shown.

Use a screwdriver to tighten the large locking nut **C**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Assembly Instructions

Step 9

Fit the munting


Fit the munting **8** to the rail **6** and base **4** and secure using 2 screws **N**.



Step 10

Prepare the plinth

Insert 2 large locking nuts **C** and 2 wooden dowels **A** into the plinth **7**.



Assembly Instructions

Step 11


Fit the rail and plinth

Push the rail **6** and plinth **7** onto the right side **2** as shown.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the 2 panels, as shown.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.

Note: Support the rail **6** until the left side has been fitted in the next stage.




Step 12

Fit the left side

Push the left side **1** onto the assembly.

Use a screwdriver to tighten the 5 large locking nuts **C** fitted to the base **4**, rails **6** and plinth **7**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Assembly Instructions

Step 13



Fit the back

a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

b: Slide the back **10** into the grooves along the left **1** and right **2** sides, as shown.

c: Secure the back **10** by tapping 7 nails **D** down into the back edge of the base **4** and 7 nails **D** into the back edge of the rail **6**.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




Assembly Instructions

Step 14

Fit the top

Position the top **3** onto the unit, making sure that the back edge is flush with the back edge of the sides **1** and **2**.


Secure the top **3** using screw **H** through the 2 brackets **F** fitted at the top edge of the side panels **1** and **2**.



Step 15

Secure the front of the top

To secure the front of the top **3**, screw up through the 4 holes in the rail **6** at the front of the unit using screws **G**.



Assembly Instructions

Step 16


Secure the unit to the wall

Using the brackets **F** fitted to the back edge of the sides **1** and **2** screw the unit to the wall.

Fixings are not supplied as they will need to suit the wall type, and the length of screw will depend on the distance of the back of the Unit to the wall.




Warning: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.



Step 17

Fit the shelf studs

Push 4 shelf studs **E** into the holes in the side panels **1** and **2** at the desired height.




Assembly Instructions

Step 18

Fit the shelf

Manouvre the shelf **5** into the unit onto the shelf studs **E**.




Step 19

Prepare the 2 doors

Push fit the 2 hinges **L** into the door **9**.

Secure each hinge with 2 screws **I**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the front edge of the door.



Assembly Instructions

Step 20

Drill the handle holes in the doors

Important: Please follow these instructions carefully.

Lay the doors **9** down onto a smooth surface.


Important: Check that the holes and hinges are in the same place as the diagrams.

Note: We recommend the use of a small piece of waste wood, placed behind the hole while drilling, to reduce the possibility of any breakout.


Using the pilot hole in the rear face of the door **9**, drill through the holes indicated opposite, using a 2.5mm diameter drill.

Turn the door **9** over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.

This will be the left door



This will be the right door



Assembly Instructions

Step 21

Fit doors and handles

2 people are needed here

Note: The easiest way to attach the door **9** is to fit the top hinge first, then align and fit the other hinges.



a: Push the hinge **L** onto the front part of the hinge plate **K**.

b: Keep the hinge **L** FLAT against the hinge plate **K** as you slide it across as far as it will go. Tighten screw A.

c: The hinge **L** must be flat against the hinge plate **K** prior to any adjustment.

d: The hinge **L** must NOT be AT AN ANGLE to the hinge plate **K** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **Ma** to the door **9** using 2 screws **Mb**.



Assembly Instructions

Step 22

Adjust the doors if needed

a: Height adjustment.


Loosen screws A on hinge plates and move door up or down as required.
Retighten screw A.

b: Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required.
Retighten screw B.

c: Sideways adjustment.


To move door 'out' loosen screw C.
To move door 'in' tighten screw C



Step 23

Fit the door buffers to both doors

Stick a door buffer **J** onto each corner of the door **9** so that they hit the edge of the side panel when the door is closed.



Assembly Instructions

Step 24

Sink Care, Maintenance and Assembly Instructions

Your sink is made of the finest quality stainless steel (CrNi 18/10), DIN1.4301 or AISI 304 (suitable for food contact).

Keep your sink looking as good as new by following the care and maintenance instructions.

Instructions

For everyday cleaning of the sink, use household detergents suitable for stainless steel. After each use, rinse the sink with warm water then wipe with a soft dry cloth.

- Do not use wire wool.
- Do not use chemical 'silver cleaners', bleaches or detergents containing chlorine or any of its derivatives.



Warning!

- If the sink comes into contact with acidic materials, rinse immediately with plenty of water and wipe with a soft, dry cloth.
- Do not leave rusty objects in contact with the sink. Rust can cause staining, cracking or even permanent damage to the sink surface.
- To avoid staining of the surface do not leave food or other materials with corrosive properties such as juices, salt, vinegar, mustard etc. on the sink for a long time.
- Do not place very hot objects directly on the sink. Place them on a special surface (board) made from wood or plastic etc.
- Avoid scraping the sink basin or draining board with utensils.
- Avoid dropping heavy or sharp objects onto the sink surface.

Step 25

Fit the seal tape

Adhere the seal tape around the underside of the edge of the sink, being careful to lay it smoothly (without ridges).





Step 26


Fit the anchor braces

Place the anchor braces vertically and pull them up to lock into their horizontal position.

Also refer to step 27.



NOTE: Do not attach the anchor brace which will be positioned at the front middle of the unit.



Assembly Instructions

Step 27

Secure the sink to the top.

These anchor braces are designed for use with counter tops 30-40mm thick (a).

If your counter top is thinner, you may need to insert wooden wedges between the counter top and the braces so as to secure them (b).

After placing two at each corner of the sink, place the rest evenly spaced around the perimeter of the sink.

It is advisable to screw the wooden wedges into the underside of the counter top to avoid any movement when tightening the anchor braces. Please take care that the length of the screw used is **5mm less than** the counter top and wooden wedge put together.




Tighten the screws of the anchor braces (with a hand screwdriver), to secure the sink in place.

If you are unsure about plumbing, please consult a qualified plumber.



Warning: The unit is heavy. Lift with care.

Assembly is complete



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

Athina - 500 Wall Unit

Assembly Instructions - Please keep for future reference


608/0835

608/0952

608/0897

608/1016

608/3007



Dimensions

Width - 50cm

Depth - 29cm

Height - 70cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 14kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the bracket supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the panels listed below




1 Side (D0331A)
(700 x 290mm) x 2




2 Top/Base (D0336A)
(470 x 269mm) x 2



3 Shelf (D0337A)
(470 x 197mm)



4 Door (D0332A)
(700 x 497mm)



5 Back (X737)
(480 x 698mm)

















Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 4</p>	<p>B </p> <p>Metal dowel (F901) x 8</p>	<p>C </p> <p>Large locking nut (F900) x 8</p>
<p>D </p> <p>Nail (F51) x 8</p>	<p>E </p> <p>Shelf support (F110) x 4</p>	<p>F </p> <p>This shows a bracket with 3 holes. They can also be supplied with just 2 holes.</p> <p>Wall bracket (F198) x 2</p>
<p>G </p> <p>25mm Screw (F50) x 4</p>	<p>H </p> <p>13mm Screw (F63) x 4</p>	<p>I </p> <p>Door Buffer (F137) x 2</p>
<p>J </p> <p>Hanging bracket (F849) x 2</p>	<p>K </p> <p>Hinge Plate (F853) x 2</p>	<p>L </p> <p>Hinge (F852) x 2</p>
<p>M a  Handle (F847a) x 1</p> <p>M b  Handle Screw (F847b) x 2</p>		

Tools required



Rule



Cross-head screwdriver



Scissors



Hammer




Eye protection (when using a hammer or drill)



Electric drill

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Step 1


Choose which way you would like the door to open

You can fit the door to the left side or right side.

If you would like your door to open this way, fit the hinge plates to the left side



If you would like your door to open this way, fit the hinge plates to the right side



Step 2

Prepare the left side

Use one of the side panels **1** to make the left side.


a: If you have chosen to fit the hinge plates to the left side (see step 1), fit 2 hinge plates **K** onto the left side **1**, making sure that the slot is facing towards the front edge.

Fit a hanging bracket to the left side **J** using 2 screws **G**, making sure that the hook is towards the back edge.

b: Screw 4 metal dowels **B** into the holes on the left side **1** as shown.



Note: Tighten metal dowels up fully against the panels.

a:



This is the left side

b:



This is the left side

Assembly Instructions

Step 3

Prepare the right side



Use one of the side panels **1** to make the right side.

a: If you have chosen to fit the hinge plates to the right side (see step 1), fit 2 hinge plates **K** onto the right side **1**, making sure that the slot is facing towards the front edge.

Fit a hanging bracket **J** to the right side **1** using 2 screws **G**, making sure that the hook is towards the back edge.

b: Screw 4 metal dowels **B** into the holes on the right side **1** as shown.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 4


Prepare the top and base

Insert 4 large locking nuts **C** into the 2 top/base panels **2** as shown.

Note: Arrow on locking nut **must** point towards hole in edge of panel.

Tap 2 wooden dowels **A** into the 2 top/base panels **2** as shown.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.




Step 5

Fit the base and top to the right side

Push the base and top panels **2** onto the right side **1**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base and top **2**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Assembly Instructions


Step 6

Fit the left side

Push the left side **1** onto the base and top panels **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base and top **2**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Step 7

Fit the back



a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

Note: The cut-out corners of the back **5** must be at the top of the unit.

b: Slide the back **5** into the grooves along the side panels **1**. Push it into the grooves until it is flush with the bottom end of the side panels **1**.

c: Secure the back **5** by tapping 4 nails **D** down into the back edge of the base **2** and 4 nails **D** into the back edge of the top **2**.

a: The measurement from top corner **X** to bottom corner **X** must be equal to the measurement from top corner **Y** to bottom corner **Y**



Assembly Instructions

Step 8

Fit the unit to the wall

To fix the unit to the wall, place the unit in the required position and lightly mark the outline of the top corners of the unit with a pencil.

Fit the 2 wall brackets **F** to the dimensions shown in the top diagram.

The screws and plugs are not supplied as they need to be the correct type to suit your wall.





Warning: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.

Place your unit onto the wall brackets **F**, via the hanging brackets **J** which you have fitted to the sides **1** of the unit.


Use the screw in the bottom of the wall brackets **J** to adjust the height of the unit.

Finally, pull the unit up against the wall by tightening up the top screw in the hanging brackets **J**.

Note: The diagrams show the wall brackets with 3 holes. They can also be supplied with just 2 holes.



Warning: The unit is heavy. Lift with care.




Assembly Instructions

Step 9

Fit the shelf

Push 4 shelf studs **E** into the holes in the side panels **1** at the desired height.

Place the shelf **3** into the unit onto the shelf studs **E**.





Step 10

Prepare the door

Push fit the 2 hinges **L** into the door **4**.

Secure each hinge with 2 screws **F**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the front edge of the door.



Assembly Instructions

Step 11

Drill the handle holes in the door

Important: Please follow these instructions carefully.

Lay the door **4** down onto a smooth surface.

Important: Carefully choose which holes you need to drill. This will depend on which side **1** you fitted the hinge plates **M**.

Check that the holes and hinges are in the same place as the diagrams.



Note: We recommend the use of a small piece of waste wood, placed behind the hole while drilling, to reduce the possibility of any breakout.

Using the pilot hole in the rear face of the door, **4** drill through the holes indicated opposite, using a 2.5mm diameter drill.

Turn the door **4** over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.



Carefully choose which 2 holes you will need to drill

Drill these 2 holes if you have fitted the hinges to the left side.



or

Drill these 2 holes if you have fitted the hinges to the right side.



Assembly Instructions

Step 12

Fit doors and handles

2 people are needed here

Note: The easiest way to attach the door **4** is to fit the top hinge first, then align and fit the other hinges.


a: Push the hinge **L** onto the front part of the hinge plate **K**.

b: Keep the hinge **L** FLAT against the hinge plate **K** as you slide it across as far as it will go. Tighten screw A.


c: The hinge **L** must be flat against the hinge plate **K** prior to any adjustment.

d: The hinge **L** must NOT be AT AN ANGLE to the hinge plate **K** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **M a** to the door **4** using 2 screws **M b**.



This shows the door being fitted to hinge plates on the right side. You may have fitted them to the left side.



Assembly Instructions

Step 13

Adjust the door if needed

a: Height adjustment.


Loosen screws A on hinge plates and move door up or down as required.
Retighten screw A.

b: Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required.
Retighten screw B.

c: Sideways adjustment.


To move door 'out' loosen screw C.
To move door 'in' tighten screw C



Step 14

Fit the door buffers

Stick a door buffer **1** onto the 2 corners of the door **4** as shown, so that they hit the edge of the side panel when the door is closed.




Assembly Instructions

Step 15

Assembly is complete



Warning: The unit is heavy. Lift with care.



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

Athina - 500 Wall Unit

Assembly Instructions - Please keep for future reference


608/0835

608/0952

608/0897

608/1016

608/3007



Dimensions

Width - 50cm

Depth - 29cm

Height - 70cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 14kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the brackets supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 03456 400800** quoting the reference numbers below

Please check you have all the panels listed below




1 Side (D0331B)
(700 x 290mm) x 2




2 Top/Base (D0336A)
(470 x 269mm) x 2



3 Shelf (D0337A)
(470 x 197mm)



4 Door (D0332A)
(700 x 497mm)



5 Back (X737)
(480 x 698mm)

















Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 03456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 4</p>	<p>B </p> <p>Metal dowel (F901) x 8</p>	<p>C </p> <p>Large locking nut (F900) x 8</p>
<p>D </p> <p>Nail (F51) x 8</p>	<p>E </p> <p>Shelf support (F110) x 4</p>	<p>F </p> <p>Wall bracket (F198) x 2</p>
<p>G </p> <p>25mm Screw (F50) x 4</p>	<p>H </p> <p>13mm Screw (F63) x 4</p>	<p>I </p> <p>Door Buffer (F137) x 2</p>
<p>J </p> <p>Hanging bracket (F181) x 2</p>	<p>K </p> <p>Hinge Plate (F853) x 2</p>	<p>L </p> <p>Hinge (F852) x 2</p>
<p>M a  Handle (F847a) x 1</p> <p>M b  Handle Screw (F847b) x 2</p>		

Tools required



Rule



Cross-head screwdriver



Scissors



Hammer




Eye protection (when using a hammer or drill)



Electric drill

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


If you have damaged or missing components, call the
Customer Helpline: 03456 400800 quoting the reference
numbers below

Step 1


Choose which way you would like the door to open

You can fit the door to the left side or right side.

If you would like your door to open this way, fit the hinge plates to the left side



If you would like your door to open this way, fit the hinge plates to the right side



Step 2

Prepare the left side

Use one of the side panels **1** to make the left side.


a: If you have chosen to fit the hinge plates to the left side (see step 1), fit 2 hinge plates **K** onto the left side **1**, making sure that the slot is facing towards the front edge.

Fit a hanging bracket to the left side **J** using 2 screws **G**, making sure that the hook is towards the back edge.


b: Screw 4 metal dowels **B** into the holes on the left side **1** as shown.

Note: Tighten metal dowels up fully against the panels.

a:



b:



Assembly Instructions

Step 3

Prepare the right side



Use one of the side panels **1** to make the right side.

a: If you have chosen to fit the hinge plates to the right side (see step 1), fit 2 hinge plates **K** onto the right side **1**, making sure that the slot is facing towards the front edge.

Fit a hanging bracket **J** to the right side **1** using 2 screws **G**, making sure that the hook is towards the back edge.

b: Screw 4 metal dowels **B** into the holes on the right side **1** as shown.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 4


Prepare the top and base

Insert 4 large locking nuts **C** into the 2 top/base panels **2** as shown.

Note: Arrow on locking nut **must** point towards hole in edge of panel.

Tap 2 wooden dowels **A** into the 2 top/base panels **2** as shown.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.




Step 5

Fit the base and top to the right side

Push the base and top panels **2** onto the right side **1**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base and top **2**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Assembly Instructions


Step 6

Fit the left side

Push the left side **1** onto the base and top panels **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base and top **2**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Step 7

Fit the back



a: Square up the unit by making sure that measurement **x** to **x** equals **y** to **y**.

Note: The cut-out corners of the back **5** must be at the top of the unit.

b: Slide the back **5** into the grooves along the side panels **1**. Push it into the grooves until it is flush with the bottom end of the side panels **1**.

c: Secure the back **5** by tapping 4 nails **D** down into the back edge of the base **2** and 4 nails **D** into the back edge of the top **2**.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y



Assembly Instructions

Step 8

Fit the unit to the wall

To fix the unit to the wall, place the unit in the required position and lightly mark the outline of the top corners of the unit with a pencil.

Fit the 2 wall brackets **F** to the dimensions shown in the top diagram. The screws and plugs are not supplied as they need to be the correct type to suit your wall.





Warning: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.


Place your unit onto the wall brackets **F**, via the hanging brackets **J** which you have fitted to the sides **1** of the unit.

Use the screw at the top of the wall brackets **J** to adjust the height of the unit.

Finally, pull the unit up against the wall by tightening up the bottom screw in the hanging brackets **J**.



Warning: The unit is heavy. Lift with care.




Assembly Instructions

Step 9

Fit the shelf

Push 4 shelf studs **E** into the holes in the side panels **1** at the desired height.

Place the shelf **3** into the unit onto the shelf studs **E**.





Step 10

Prepare the door

Push fit the 2 hinges **L** into the door **4**.

Secure each hinge with 2 screws **F**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the front edge of the door.



Assembly Instructions

Step 11

Drill the handle holes in the door

Important: Please follow these instructions carefully.

Lay the door **4** down onto a smooth surface.

Important: Carefully choose which holes you need to drill. This will depend on which side **1** you fitted the hinge plates **M**.

Check that the holes and hinges are in the same place as the diagrams.



Note: We recommend the use of a small piece of waste wood, placed behind the hole while drilling, to reduce the possibility of any breakout.

Using the pilot hole in the rear face of the door, **4** drill through the holes indicated opposite, using a 2.5mm diameter drill.

Turn the door **4** over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.



Carefully choose which 2 holes you will need to drill

Drill these 2 holes if you have fitted the hinges to the left side.



or

Drill these 2 holes if you have fitted the hinges to the right side.



Assembly Instructions

Step 12

Fit doors and handles

2 people are needed here

Note: The easiest way to attach the door **4** is to fit the top hinge first, then align and fit the other hinges.


a: Push the hinge **L** onto the front part of the hinge plate **K**.

b: Keep the hinge **L** FLAT against the hinge plate **K** as you slide it across as far as it will go. Tighten screw A.


c: The hinge **L** must be flat against the hinge plate **K** prior to any adjustment.

d: The hinge **L** must NOT be AT AN ANGLE to the hinge plate **K** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **M a** to the door **4** using 2 screws **M b**.



This shows the door being fitted to hinge plates on the right side. You may have fitted them to the left side.



Assembly Instructions

Step 13

Adjust the door if needed

a: Height adjustment.

Loosen screws A on hinge plates and move door up or down as required.

Retighten screw A.

b: Forward and Back adjustment.


Loosen screw B on hinge plate and move door in or out as required.

Retighten screw B.

c: Sideways adjustment.

To move door 'out' loosen screw C.


To move door 'in' tighten screw C



Step 14

Fit the door buffers

Stick a door buffer **1** onto the 2 corners of the door **4** as shown, so that they hit the edge of the side panel when the door is closed.




Assembly Instructions

Step 15

Assembly is complete



Warning: The unit is heavy. Lift with care.



If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800** and quote the reference numbers on the component pages.
Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

Athina - 1000 Wall Unit

Assembly Instructions - Please keep for future reference


608/0842

608/0969

608/0907

608/1023

608/3014



Dimensions

Width - 100cm

Depth - 29cm

Height - 70cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 23kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the bracket supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the panels listed below




1 Side (D0331A)
(700 x 290mm) x 2



2 Top/Base (D0333A)
(970 x 269mm) x 2



3 Shelf (D0334A)
(969 x 197mm)



4 Door (D0332A)
(700 x 497mm) x 2



5 Back (X738)
(980 x 698mm)



6 Munting (D0335A)
(668 x 60mm)


















Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 6</p>	<p>B </p> <p>Metal dowel (F901) x 8</p>	<p>C </p> <p>Large locking nut (F900) x 8</p>
<p>D </p> <p>Nail (F51) x 14</p>	<p>E </p> <p>Shelf support (F110) x 4</p>	<p>F </p> <p>This shows a bracket with 3 holes. They can also be supplied with just 2 holes.</p> <p>Wall bracket (F198) x 2</p>
<p>G </p> <p>25mm Screw (F50) x 4</p>	<p>H </p> <p>13mm Screw (F63) x 8</p>	<p>I </p> <p>40mm Screw (F910) x 2</p>
<p>J </p> <p>Door Buffer (F137) x 4</p>	<p>K </p> <p>Hanging bracket (F849) x 2</p>	<p>L </p> <p>Hinge Plate (F853) x 4</p>
<p>M </p> <p>Hinge (F852) x 4</p>	<p>N a </p> <p>Handle (F847a) x 2</p>	<p>N b </p> <p>Handle Screw (F847b) x 4</p>

Tools required



Rule



Cross-head screwdriver



Scissors



Hammer




Eye protection (when using a hammer or drill)



Electric drill

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Step 1

Prepare the left side



Use one of the side panels **1** to make the left side.

a: Fit 2 hinge plates **L** onto the left side **1**, making sure that the slot is facing towards the front edge.

Fit a hanging bracket **K** to the left side **1** using 2 screws **G**, making sure that the hook is towards the back edge.

b: Screw 4 metal dowels **B** into the holes on the left side **1** as shown.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 2

Prepare the right side

Use one of the side panels **1** to make the left side.

a: Fit 2 hinge plates **L** onto the right side **1**, making sure that the slot is facing towards the front edge.


Fit a hanging bracket **K** to the right side **1** using 2 screws **G**, making sure that the hook is towards the back edge.

b: Screw 4 metal dowels **B** into the holes on the right side **1** as shown.


Note: Tighten metal dowels up fully against the panels.

a:


This is the right side



b:



This is the right side



Assembly Instructions

Step 3


Prepare the top and base

Insert 4 large locking nuts **C** into the 2 top/base panels **2** as shown.

Note: Arrow on locking nut **must** point towards hole in edge of panel.

Tap 2 wooden dowels **A** into the 2 top/base panels **2** as shown.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.




Step 4

Fit the base and top to the right side

Push the base and top panels **2** onto the right side **1**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base and top **2**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Assembly Instructions

Step 5

Prepare the munting

Tap 2 wooden dowels **A** into the munting **6** as shown.


Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.



Step 6

Fit the munting

Fit the munting **6** to the top and base panels **2** and secure using 2 screws **1**.




Step 7

Fit the left side

Push the left side **1** onto the base and top panels **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base and top **2**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Assembly Instructions

Step 8

Fit the back



a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

Note: The cut-out corners of the back **5** must be at the top of the unit.

b: Slide the back **5** into the grooves along the side panels **1**. Push it into the grooves until it is flush with the bottom end of the side panels **1**.

c: Secure the back **5** by tapping 7 nails **D** down into the back edge of the base **2** and 7 nails **D** into the back edge of the top **2**.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y



Assembly Instructions

Step 9

Fit the unit to the wall

To fix the unit to the wall, place the unit in the required position and lightly mark the outline of the top corners of the unit with a pencil.

Fit the 2 wall brackets **F** to the dimensions shown in the top diagram. The screws and plugs are not supplied as they need to be the correct type to suit your wall.





Warning: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.

Place your unit onto the wall brackets **F**, via the hanging brackets **K** which you have fitted to the sides **1** of the unit.


Use the screw in the bottom of the wall brackets **K** to adjust the height of the unit.

Finally, pull the unit up against the wall by tightening up the top screw in the hanging brackets **K**.

Note: The diagrams show the wall brackets with 3 holes. They can also be supplied with just 2 holes.



Warning: The unit is heavy. Lift with care.




Assembly Instructions

Step 10


Insert the shelf studs

Push 4 shelf studs **E** into the holes in the side panels **1** at the desired height.



Step 11

Manoeuvre the shelf **3** into the unit and onto the shelf studs **E**.




Step 12

Prepare the doors

Push fit 2 hinges **M** into each of the 2 doors **4**.

Secure each hinge **M** with 2 screws **H**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the front edge of the door.



Assembly Instructions

Step 13

Drill the handle holes in the door

Important: Please follow these instructions carefully.

Lay the doors **4** down onto a smooth surface.


Important: Check that the holes and hinges are in the same place as the diagrams.

Note: We recommend the use of a small piece of waste wood, placed behind the hole while drilling, to reduce the possibility of any breakout.


Using the pilot hole in the rear face of the door **4**, drill through the holes indicated opposite, using a 2.5mm diameter drill.

Turn the door **4** over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.

This will be the left door



This will be the right door



Assembly Instructions

Step 14

Fit doors and handles

2 people are needed here

Note: The easiest way to attach the door **4** is to fit the top hinge first, then align and fit the other hinges.



a: Push the hinge **M** onto the front part of the hinge plate **L**.

b: Keep the hinge **M** FLAT against the hinge plate **L** as you slide it across as far as it will go. Tighten screw A.

c: The hinge **M** must be flat against the hinge plate **L** prior to any adjustment.

d: The hinge **M** must NOT be AT AN ANGLE to the hinge plate **L** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **Na** to the door **4** using 2 screws **Nb**.



Assembly Instructions

Step 15

Adjust the door if needed

a: Height adjustment.


Loosen screws A on hinge plates and move door up or down as required.
Retighten screw A.

b: Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required.
Retighten screw B.

c: Sideways adjustment.


To move door 'out' loosen screw C.
To move door 'in' tighten screw C



Step 16

Fit the door buffers

Stick a door buffer **J** onto the 2 corners of each door **4** as shown, so that they hit the edge of the side panel when the door is closed.




Assembly Instructions

Step 17

Assembly is complete



Warning: The unit is heavy. Lift with care.



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** and quote the reference numbers on the component pages.
Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

Athina - 1000 Wall Unit

Assembly Instructions - Please keep for future reference


608/0842

608/0969

608/0907

608/1023

608/3014



Dimensions

Width - 100cm

Depth - 29cm

Height - 70cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 23kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the brackets supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 03456 400800** quoting the reference numbers below

Please check you have all the panels listed below




1 Side (D0331B)
(700 x 290mm) x 2



2 Top/Base (D0333A)
(970 x 269mm) x 2



3 Shelf (D0334A)
(969 x 197mm)



4 Door (D0332A)
(700 x 497mm) x 2



5 Back (X738)
(980 x 698mm)



6 Munting (D0335A)
(668 x 60mm)


















Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 03456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 6</p>	<p>B </p> <p>Metal dowel (F901) x 8</p>	<p>C </p> <p>Large locking nut (F900) x 8</p>
<p>D </p> <p>Nail (F51) x 14</p>	<p>E </p> <p>Shelf support (F110) x 4</p>	<p>F </p> <p>Wall bracket (F198) x 2</p>
<p>G </p> <p>25mm Screw (F50) x 4</p>	<p>H </p> <p>13mm Screw (F63) x 8</p>	<p>I </p> <p>40mm Screw (F910) x 2</p>
<p>J </p> <p>Door Buffer (F137) x 4</p>	<p>K </p> <p>Hanging bracket (F181) x 2</p>	<p>L </p> <p>Hinge Plate (F853) x 4</p>
<p>M </p> <p>Hinge (F852) x 4</p>	<p>N a </p> <p>Handle (F847a) x 2</p>	<p>N b </p> <p>Handle Screw (F847b) x 4</p>

Tools required



Rule



Cross-head screwdriver



Scissors



Hammer




Eye protection (when using a hammer or drill)



Electric drill

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

If you have damaged or missing components, call the
Customer Helpline: 03456 400800 quoting the reference
numbers below

Step 1

Prepare the left side



Use one of the side panels **1** to make the left side.

a: Fit 2 hinge plates **L** onto the left side **1**, making sure that the slot is facing towards the front edge.

Fit a hanging bracket **K** to the left side **1** using 2 screws **G**, making sure that the hook is towards the back edge.

b: Screw 4 metal dowels **B** into the holes on the left side **1** as shown.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 2

Prepare the right side

Use one of the side panels **1** to make the left side.

a: Fit 2 hinge plates **L** onto the right side **1**, making sure that the slot is facing towards the front edge.


Fit a hanging bracket **K** to the right side **1** using 2 screws **G**, making sure that the hook is towards the back edge.

b: Screw 4 metal dowels **B** into the holes on the right side **1** as shown.


Note: Tighten metal dowels up fully against the panels.

a:


This is the right side



b:



This is the right side



Assembly Instructions

Step 3


Prepare the top and base

Insert 4 large locking nuts **C** into the 2 top/base panels **2** as shown.

Note: Arrow on locking nut **must** point towards hole in edge of panel.

Tap 2 wooden dowels **A** into the 2 top/base panels **2** as shown.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.




Step 4

Fit the base and top to the right side

Push the base and top panels **2** onto the right side **1**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base and top **2**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Assembly Instructions

Step 5

Prepare the munting

Tap 2 wooden dowels **A** into the munting **6** as shown.


Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.



Step 6

Fit the munting

Fit the munting **6** to the top and base panels **2** and secure using 2 screws **1**.




Step 7

Fit the left side

Push the left side **1** onto the base and top panels **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base and top **2**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Assembly Instructions

Step 8

Fit the back



a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

Note: The cut-out corners of the back **5** must be at the top of the unit.

b: Slide the back **5** into the grooves along the side panels **1**. Push it into the grooves until it is flush with the bottom end of the side panels **1**.

c: Secure the back **5** by tapping 7 nails **D** down into the back edge of the base **2** and 7 nails **D** into the back edge of the top **2**.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y



Assembly Instructions

Step 9

Fit the unit to the wall

To fix the unit to the wall, place the unit in the required position and lightly mark the outline of the top corners of the unit with a pencil.

Fit the 2 wall brackets **F** to the dimensions shown in the top diagram. The screws and plugs are not supplied as they need to be the correct type to suit your wall.





Warning: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.


Place your unit onto the wall brackets **F**, via the hanging brackets **K** which you have fitted to the sides **1** of the unit.

Use the screw at the top of the wall brackets **K** to adjust the height of the unit.

Finally, pull the unit up against the wall by tightening up the bottom screw in the hanging brackets **K**.



Warning: The unit is heavy. Lift with care.




Assembly Instructions

Step 10


Insert the shelf studs

Push 4 shelf studs **E** into the holes in the side panels **1** at the desired height.



Step 11

Manoeuvre the shelf **3** into the unit and onto the shelf studs **E**.




Step 12

Prepare the doors

Push fit 2 hinges **M** into each of the 2 doors **4**.

Secure each hinge **M** with 2 screws **H**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the front edge of the door.



Assembly Instructions

Step 13

Drill the handle holes in the door

Important: Please follow these instructions carefully.


Lay the doors **4** down onto a smooth surface.

Important: Check that the holes and hinges are in the same place as the diagrams.


Note: We recommend the use of a small piece of waste wood, placed behind the hole while drilling, to reduce the possibility of any breakout.

Using the pilot hole in the rear face of the door **4**, drill through the holes indicated opposite, using a 2.5mm diameter drill.

Turn the door **4** over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.



This will be the right door



Assembly Instructions

Step 14

Fit doors and handles

2 people are needed here

Note: The easiest way to attach the door **4** is to fit the top hinge first, then align and fit the other hinges.



a: Push the hinge **M** onto the front part of the hinge plate **L**.

b: Keep the hinge **M** FLAT against the hinge plate **L** as you slide it across as far as it will go. Tighten screw A.

c: The hinge **M** must be flat against the hinge plate **L** prior to any adjustment.

d: The hinge **M** must NOT be AT AN ANGLE to the hinge plate **L** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **Na** to the door **4** using 2 screws **Nb**.



Assembly Instructions

Step 15

Adjust the door if needed

a: Height adjustment.


Loosen screws A on hinge plates and move door up or down as required.
Retighten screw A.

b: Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required.
Retighten screw B.

c: Sideways adjustment.


To move door 'out' loosen screw C.
To move door 'in' tighten screw C



Step 16

Fit the door buffers

Stick a door buffer **J** onto the 2 corners of each door **4** as shown, so that they hit the edge of the side panel when the door is closed.




Assembly Instructions

Step 17

Assembly is complete



Warning: The unit is heavy. Lift with care.



If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

