

Athina - 500 Tall Cupboard


Assembly Instructions - Please keep for future reference

608/0794

608/0914

608/0859

608/0976



Dimensions

Width - 50cm

Depth - 59cm

Height - 200cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 51kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the brackets supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below


Please check you have all the panels listed below



1 Left Side (D0328A)
(2000 X 570mm)



2 Right Side (D0329A)
(2000 X 570mm)




3 Horizontal (D0319A)
(470 X 499mm) x 3




4 Shelf (D0320A)
(469 x 427mm) x 2




5 Plinth (D0322A)
(470 x 150mm)



6 Small Door (D0317A)
(716 x 497mm)



7 Large Door (D0330A)
(1126 x 497mm)



8 Back (X741)
(1848 x 480mm)
















Components - Fittings


If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Wooden dowel (F22) x 20	B  Metal dowel (F901) x 14	C  Large locking nut (F900) x 14
D  Nail (F51) x 8	E  Shelf support (F110) x 8	F  Bracket (F945) x 2
G  Door Buffer (F137) x 4	H  13mm Screw (F79) x 2	I  13mm Screw (F63) x 8
J  Hinge Plate (F853) x 4	K  Hinge (F852) x 4	
<div data-bbox="82 1167 560 1406"> L a  Handle (F847a) x 2 </div> <div data-bbox="560 1167 1031 1406"> L b  Handle Screw (F847b) x 4 </div>		

Tools required



Rule



Cross-head
screwdriver




Scissors



Hammer




Eye protection
(when using a
hammer or drill)



Electric drill

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Step 1


Choose which way you would like the doors to open

You can fit the doors to the left side or right side.

If you would like your doors to open this way, fit the hinge plates to the left side



If you would like your doors to open this way, fit the hinge plates to the right side




Step 2

Fit a bracket to the left side

Fit a bracket **F** to the left side **1**, 10mm down from the top edge, see diagram.

Secure the bracket **F** using screw **H**.

Note: The bracket must be flush with the back edge of the panel.




Step 3

Prepare the left side

a: Refer to step 1 and if required, fit 4 hinge plates **J** onto the left side **1**, making sure that the slot is facing towards the front edge.

b: Screw 7 metal dowels **B** into the holes shown on the left side **1**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions


Step 4

Fit 2 brackets to the right side

Fit a bracket **F** to the right side **2**, 10mm down from the top edge, see diagram.

Secure the bracket **F** using screw **H**.

Note: The bracket must be flush with the back edge of the panel.




Step 5

Prepare the right side

a: Refer to step 1 and if required, fit 4 hinge plates **J** onto the right side **2**, making sure that the slot is facing towards the front edge.

b: Screw 7 metal dowels **B** into the holes shown on the right side **2**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 6


Prepare the 3 horizontals

Insert 4 large locking nuts **C** into each horizontal **3** as shown.

Note: Arrow on locking nut **must** point towards hole in edge of panel.

Tap 6 wooden dowels **A** into each horizontal **3** as shown.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.




Step 7

Fit the 3 horizontals to the right side

Push the horizontals **3** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to each horizontal **3**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Step 8

Prepare the plinth

Insert 2 large locking nuts **C** into the plinth **5** as shown.

Tap 2 wooden dowels **A** into the plinth **5** as shown.



Assembly Instructions


Step 9

Fit the plinth to the right side

Push the plinth **5** onto the right side **2**, as shown.

Use a screwdriver to tighten the large locking nut **C** fitted to the plinth **5**, as shown.

Note: Turn the large locking nut **C** as far as they will go - more than 1/2 a turn.




Step 10

Fit the left side

Push the left side **1** onto the assembly.

Use a screwdriver to tighten the 7 large locking nuts **C** fitted to the 3 horizontals **3** and plinth **5**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Assembly Instructions

Step 11


Fit the back

a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

b: Slide the back **8** into the grooves along the left **1** and right **2** sides, as shown.

c: Secure the back **8** by tapping 4 nails **D** down into the back edge of the top horizontal **3** and 4 nails **D** into the back edge of the bottom horizontal **3**.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y



Stand the unit up for the next stage.

Assembly Instructions

Step 12


Secure the unit to the wall

Using the brackets **F** fitted to the back edge of the sides **1** and **2** screw the unit to the wall.

Fixings are not supplied as they will need to suit the wall type, and the length of screw will depend on the distance of the back of the Unit to the wall.



Warning: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.




Step 13

Fit the shelf studs

Choose the height required for the 2 shelves.

For each shelf, push 4 shelf studs **E** into the holes in the side panels **1** and **2**.




Assembly Instructions

Step 14

Fit the 2 shelves

Place the shelves **4** into the unit onto the shelf studs **E**.




Step 15

Prepare the doors

Push fit 2 hinges **K** into the small door **6** and large door **7**.

Secure each hinge **K** with 2 screws **I**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the front edge of the door.



Assembly Instructions

Step 16

Drill the handle holes in the doors

Important: Only carry out this step if the hinge plates have been fitted to the left side.

Lay the small door **6** and large door **7** down onto a smooth surface.

Important: Carefully choose which holes you need to drill.

Check that the holes and hinges are in the same place as the diagrams.

Note: We recommend the use of a small piece of waste wood, placed behind the hole while drilling, to reduce the possibility of any breakout.

Using the pilot hole in the rear face of the doors **6** and **7** drill through the holes indicated opposite, using a 2.5mm diameter drill.


Turn the doors **6** and **7** over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.

Carefully choose which 2 holes you will need to drill in each door.


This page shows the holes to drill if you have fitted the hinges to the left side.

Do not carry out this step if you have fitted the hinges to the right side, go to step 17.


Drill these 2 holes in the small door if you have fitted the hinges to the left side.




ONLY drill these 2 holes



Drill these 2 holes in the large door if you have fitted the hinges to the left side.



ONLY drill these 2 holes



Assembly Instructions

Step 17

Drill the handle holes in the doors

Important: Only carry out this step if the hinge plates have been fitted to the right side.

Lay the small door **6** and large door **7** down onto a smooth surface.

Important: Carefully choose which holes you need to drill.

Check that the holes and hinges are in the same place as the diagrams.

Note: We recommend the use of a small piece of waste wood, placed behind the hole while drilling, to reduce the possibility of any breakout.

Using the pilot hole in the rear face of the doors **6** and **7** drill through the holes indicated opposite, using a 2.5mm diameter drill.


Turn the doors **6** and **7** over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.

Carefully choose which 2 holes you will need to drill in each door.

This page shows the holes to drill if you have fitted the hinges to the right side.

Do not carry out this step if you have fitted the hinges to the left side, go back to step 16.


Drill these 2 holes in the small door if you have fitted the hinges to the right side.




ONLY drill these 2 holes




DO NOT drill these holes



Drill these 2 holes in the large door if you have fitted the hinges to the right side.




ONLY drill these 2 holes



Small piece of waste wood

DO NOT drill these holes



Assembly Instructions

Step 18

Fit doors and handles

2 people are needed here

Note: The easiest way to attach the doors **6** and **7** is to fit the top hinge first, then align and fit the other hinges.


a: Push the hinge **K** onto the front part of the hinge plate **J**.

b: Keep the hinge **K** FLAT against the hinge plate **J** as you slide it across as far as it will go. Tighten screw A.


c: The hinge **K** must be flat against the hinge plate **J** prior to any adjustment.

d: The hinge **K** must NOT be AT AN ANGLE to the hinge plate **J** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **L a** to the doors **6** and **7** using 2 screws **L b**.



This shows the doors being fitted to hinge plates on the right side. You may have fitted them to the left side.



Assembly Instructions

Step 19

Adjust the doors if needed

a: Height adjustment.

Loosen screws A on hinge plates and move door up or down as required.

Retighten screw A.

b: Forward and Back adjustment.


Loosen screw B on hinge plate and move door in or out as required.

Retighten screw B.

c: Sideways adjustment.

To move door 'out' loosen screw C.

To move door 'in' tighten screw C



Assembly Instructions

Step 20


Fit the 4 door buffers

Stick a door buffer **G** onto each corner of the doors **6** and **7** so that they hit the edge of the side panel when the door is closed.

Assembly is complete



Warning: The unit is heavy. Lift with care.



If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800 and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

Athina - 500 Tall Cupboard

Assembly Instructions - Please keep for future reference


608/0794

608/0914

608/0859

608/0976

608/2967



Dimensions

Width - 50cm

Depth - 59cm

Height - 200cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 51kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the brackets supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below


Please check you have all the panels listed below



1 Left Side (D0328A)
(2000 X 570mm)



2 Right Side (D0329A)
(2000 X 570mm)




3 Horizontal (D0319A)
(470 X 499mm) x 3




4 Shelf (D0320A)
(469 x 427mm) x 3




5 Plinth (D0322A)
(470 x 150mm)



6 Small Door (D0317A)
(716 x 497mm)



7 Large Door (D0330A)
(1126 x 497mm)



8 Back (X741)
(1848 x 480mm)
















Components - Fittings


If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Wooden dowel (F22) x 20	B  Metal dowel (F901) x 14	C  Large locking nut (F900) x 14
D  Nail (F51) x 8	E  Shelf support (F110) x 12	F  Bracket (F945) x 2
G  Door Buffer (F137) x 4	H  13mm Screw (F79) x 2	I  13mm Screw (F63) x 8
J  Hinge Plate (F853) x 4	K  Hinge (F852) x 4	
L a  Handle (F847a) x 2		L b  Handle Screw (F847b) x 4

Tools required



Rule



Cross-head
screwdriver




Scissors



Hammer




Eye protection
(when using a
hammer or drill)



Electric drill

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Step 1


Choose which way you would like the doors to open

You can fit the doors to the left side or right side.

If you would like your doors to open this way, fit the hinge plates to the left side



If you would like your doors to open this way, fit the hinge plates to the right side




Step 2

Fit a bracket to the left side

Fit a bracket **F** to the left side **1**, 10mm down from the top edge, see diagram.

Secure the bracket **F** using screw **H**.

Note: The bracket must be flush with the back edge of the panel.




Step 3

Prepare the left side

a: Refer to step 1 and if required, fit 4 hinge plates **J** onto the left side **1**, making sure that the slot is facing towards the front edge.

b: Screw 7 metal dowels **B** into the holes shown on the left side **1**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions


Step 4

Fit 2 brackets to the right side

Fit a bracket **F** to the right side **2**, 10mm down from the top edge, see diagram.

Secure the bracket **F** using screw **H**.

Note: The bracket must be flush with the back edge of the panel.




Step 5

Prepare the right side

a: Refer to step 1 and if required, fit 4 hinge plates **J** onto the right side **2**, making sure that the slot is facing towards the front edge.

b: Screw 7 metal dowels **B** into the holes shown on the right side **2**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 6


Prepare the 3 horizontals

Insert 4 large locking nuts **C** into each horizontal **3** as shown.

Note: Arrow on locking nut **must** point towards hole in edge of panel.

Tap 6 wooden dowels **A** into each horizontal **3** as shown.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.




Step 7

Fit the 3 horizontals to the right side

Push the horizontals **3** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to each horizontal **3**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Step 8

Prepare the plinth

Insert 2 large locking nuts **C** into the plinth **5** as shown.

Tap 2 wooden dowels **A** into the plinth **5** as shown.



Assembly Instructions


Step 9

Fit the plinth to the right side

Push the plinth **5** onto the right side **2**, as shown.

Use a screwdriver to tighten the large locking nut **C** fitted to the plinth **5**, as shown.

Note: Turn the large locking nut **C** as far as they will go - more than 1/2 a turn.




Step 10

Fit the left side

Push the left side **1** onto the assembly.

Use a screwdriver to tighten the 7 large locking nuts **C** fitted to the 3 horizontals **3** and plinth **5**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Assembly Instructions

Step 11


Fit the back

a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

b: Slide the back **8** into the grooves along the left **1** and right **2** sides, as shown.

c: Secure the back **8** by tapping 4 nails **D** down into the back edge of the top horizontal **3** and 4 nails **D** into the back edge of the bottom horizontal **3**.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y



Stand the unit up for the next stage.

Assembly Instructions

Step 12


Secure the unit to the wall

Using the brackets **F** fitted to the back edge of the sides **1** and **2** screw the unit to the wall.

Fixings are not supplied as they will need to suit the wall type, and the length of screw will depend on the distance of the back of the Unit to the wall.



Warning: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.




Step 13

Fit the shelf studs

Choose the height required for the 3 shelves.

For each shelf, push 4 shelf studs **E** into the holes in the side panels **1** and **2**.




Assembly Instructions

Step 14

Fit the 3 shelves

Place the 3 shelves **4** into the unit onto the shelf studs **E**.






Step 15

Prepare the doors

Push fit 2 hinges **K** into the small door **6** and large door **7**.

Secure each hinge **K** with 2 screws **I**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the front edge of the door.



Assembly Instructions

Step 16

Drill the handle holes in the doors

Important: Only carry out this step if the hinge plates have been fitted to the left side.

Lay the small door **6** and large door **7** down onto a smooth surface.

Important: Carefully choose which holes you need to drill.

Check that the holes and hinges are in the same place as the diagrams.

Note: We recommend the use of a small piece of waste wood, placed behind the hole while drilling, to reduce the possibility of any breakout.

Using the pilot hole in the rear face of the doors **6** and **7** drill through the holes indicated opposite, using a 2.5mm diameter drill.


Turn the doors **6** and **7** over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.

Carefully choose which 2 holes you will need to drill in each door.


This page shows the holes to drill if you have fitted the hinges to the left side.

Do not carry out this step if you have fitted the hinges to the right side, go to step 17.

Drill these 2 holes in the small door if you have fitted the hinges to the left side.




ONLY drill these 2 holes




DO NOT drill these holes

Drill these 2 holes in the large door if you have fitted the hinges to the left side.



ONLY drill these 2 holes



DO NOT drill these holes

Small piece of waste wood

Assembly Instructions

Step 17

Drill the handle holes in the doors

Important: Only carry out this step if the hinge plates have been fitted to the right side.

Lay the small door **6** and large door **7** down onto a smooth surface.

Important: Carefully choose which holes you need to drill.

Check that the holes and hinges are in the same place as the diagrams.

Note: We recommend the use of a small piece of waste wood, placed behind the hole while drilling, to reduce the possibility of any breakout.

Using the pilot hole in the rear face of the doors **6** and **7** drill through the holes indicated opposite, using a 2.5mm diameter drill.


Turn the doors **6** and **7** over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.

Carefully choose which 2 holes you will need to drill in each door.

This page shows the holes to drill if you have fitted the hinges to the right side.

Do not carry out this step if you have fitted the hinges to the left side, go back to step 16.


Drill these 2 holes in the small door if you have fitted the hinges to the right side.




ONLY drill these 2 holes




DO NOT drill these holes



Drill these 2 holes in the large door if you have fitted the hinges to the right side.




ONLY drill these 2 holes



Small piece of waste wood

DO NOT drill these holes



Assembly Instructions

Step 18

Fit doors and handles

2 people are needed here

Note: The easiest way to attach the doors **6** and **7** is to fit the top hinge first, then align and fit the other hinges.


a: Push the hinge **K** onto the front part of the hinge plate **J**.

b: Keep the hinge **K** FLAT against the hinge plate **J** as you slide it across as far as it will go. Tighten screw A.


c: The hinge **K** must be flat against the hinge plate **J** prior to any adjustment.

d: The hinge **K** must NOT be AT AN ANGLE to the hinge plate **J** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **L a** to the doors **6** and **7** using 2 screws **L b**.



This shows the doors being fitted to hinge plates on the right side. You may have fitted them to the left side.



Assembly Instructions

Step 19

Adjust the doors if needed

a: Height adjustment.

Loosen screws A on hinge plates and move door up or down as required.

Retighten screw A.

b: Forward and Back adjustment.


Loosen screw B on hinge plate and move door in or out as required.

Retighten screw B.

c: Sideways adjustment.

To move door 'out' loosen screw C.

To move door 'in' tighten screw C



Assembly Instructions

Step 20


Fit the 4 door buffers

Stick a door buffer **G** onto each corner of the doors **6** and **7** so that they hit the edge of the side panel when the door is closed.

Assembly is complete



Warning: The unit is heavy. Lift with care.



If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800 and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW