

Athina - 1000 Sink Unit

Assembly Instructions - Please keep for future reference


656/4069

656/4083

656/4076

656/4090

633/3726



Dimensions

Width - 100cm

Depth - 59cm

Height - 89.5cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 36kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the bracket supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the panels listed below




1 Left Side (D0315B)
(870 X 570mm)




2 Right Side (D0316B)
(870 x 570mm)



3 Sink Top (D0340A)
(1000 x 590mm)



4 Base (D0323A)
(970 X 499mm)



5 Shelf (D0324A)
(969 X 427mm)




6 Rail (D0325A)
(970 x 60mm) x 2



7 Plinth (D0326A)
(970 x 150mm)



8 Munting (D0327A)
(689 x 60mm)



9 Door (D0317A)
(716 x 497mm) x 2



10 Back (X740)
(980 x 533mm)









Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 14</p>	<p>B </p> <p>Metal dowel (F901) x 10</p>	<p>C </p> <p>Large locking nut (F900) x 10</p>
<p>D </p> <p>Nail (F51) x 14</p>	<p>E </p> <p>Shelf support (F110) x 4</p>	<p>F </p> <p>Bracket (F945) x 4</p>
<p>G </p> <p>25mm Screw (F50) x 4</p>	<p>H </p> <p>13mm Screw (F79) x 6</p>	<p>I </p> <p>13mm Screw (F63) x 8</p>
<p>J </p> <p>Door Buffer (F137) x 4</p>	<p>K </p> <p>Hinge Plate (F853) x 4</p>	<p>L </p> <p>Hinge (F852) x 4</p>
<p>M a </p> <p>Handle (F847a) x 2</p>	<p>M b </p> <p>Handle Screw (F847b) x 4</p>	<p>N </p> <p>40mm Screw (F910) x 2</p>

Tools required



Rule



Flat-head screwdriver



Cross-head screwdriver



Scissors



Hammer




Eye protection (when using a hammer or drill)



Electric drill

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Step 1


Fit 2 brackets to the left side

Fit a bracket **F** to the left side **1**, 100mm in from the back edge, see diagram.

Fit another bracket **F** to the left side **1**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.




Step 2

Prepare the left side

a: Fit 2 hinge plates **K** onto the left side **1**, making sure that the slot is facing towards the front edge.

b: Screw 5 metal dowels **B** into the holes shown on the left side **1**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 3



Fit 2 brackets to the right side

Fit a bracket **F** to the right side **2**, 100mm down from the back edge, see diagram.

Fit another bracket **F** to the right side **2**, 100mm down from the top edge, see diagram.

Secure each bracket using screw **H**.

Note: The brackets must be flush with the edges of the panel.





Step 4

Prepare the right side

a: Fit 2 hinge plates **K** onto the right side **2**, making sure that the slot is facing towards the front edge.

b: Screw 5 metal dowels **B** into the holes shown on the right side **2**.

Note: Tighten metal dowels up fully against the panels.



Assembly Instructions

Step 5


Prepare the base

Insert 4 large locking nuts **C** into the base **4** as shown.

Note: Arrow on locking nut **must** point towards hole in edge of panel.

Tap 6 wooden dowels **A** into the base **4** as shown.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.




Step 6

Fit the base to the right side

Push the base **4** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the base **4**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Assembly Instructions

Step 7

Prepare the 2 rails and munting

Insert 2 large locking nuts **C** and 2 wooden dowels **A** into each of the 2 rails **6**.

Tap 2 wooden dowels **A** into the munting **8**.




Step 8

Fit a rail to the right side

Push one of the rails **6** onto the right side **2** as shown.

Use a screwdriver to tighten the large locking nut **C**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.




Assembly Instructions

Step 9

Fit the munting


Fit the munting **8** to the rail **6** and base **4** and secure using 2 screws **N**.



Step 10

Prepare the plinth

Insert 2 large locking nuts **C** and 2 wooden dowels **A** into the plinth **7**.



Assembly Instructions

Step 11


Fit the rail and plinth

Push the rail **6** and plinth **7** onto the right side **2** as shown.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the 2 panels, as shown.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.

Note: Support the rail **6** until the left side has been fitted in the next stage.




Step 12

Fit the left side

Push the left side **1** onto the assembly.

Use a screwdriver to tighten the 5 large locking nuts **C** fitted to the base **4**, rails **6** and plinth **7**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.



Assembly Instructions

Step 13



Fit the back

a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

b: Slide the back **10** into the grooves along the left **1** and right **2** sides, as shown.

c: Secure the back **10** by tapping 7 nails **D** down into the back edge of the base **4** and 7 nails **D** into the back edge of the rail **6**.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




Assembly Instructions

Step 14

Fit the top

Position the top **3** onto the unit, making sure that the back edge is flush with the back edge of the sides **1** and **2**.


Secure the top **3** using screw **H** through the 2 brackets **F** fitted at the top edge of the side panels **1** and **2**.



Step 15

Secure the front of the top

To secure the front of the top **3**, screw up through the 4 holes in the rail **6** at the front of the unit using screws **G**.



Assembly Instructions

Step 16


Secure the unit to the wall

Using the brackets **F** fitted to the back edge of the sides **1** and **2** screw the unit to the wall.

Fixings are not supplied as they will need to suit the wall type, and the length of screw will depend on the distance of the back of the Unit to the wall.




Warning: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.



Step 17

Fit the shelf studs

Push 4 shelf studs **E** into the holes in the side panels **1** and **2** at the desired height.




Assembly Instructions

Step 18

Fit the shelf

Manouvre the shelf **5** into the unit onto the shelf studs **E**.




Step 19

Prepare the 2 doors

Push fit the 2 hinges **L** into the door **9**.

Secure each hinge with 2 screws **I**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the front edge of the door.



Assembly Instructions

Step 20

Drill the handle holes in the doors

Important: Please follow these instructions carefully.

Lay the doors **9** down onto a smooth surface.


Important: Check that the holes and hinges are in the same place as the diagrams.

Note: We recommend the use of a small piece of waste wood, placed behind the hole while drilling, to reduce the possibility of any breakout.


Using the pilot hole in the rear face of the door **9**, drill through the holes indicated opposite, using a 2.5mm diameter drill.

Turn the door **9** over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.

This will be the left door



This will be the right door



Assembly Instructions

Step 21

Fit doors and handles

2 people are needed here

Note: The easiest way to attach the door **9** is to fit the top hinge first, then align and fit the other hinges.



a: Push the hinge **L** onto the front part of the hinge plate **K**.

b: Keep the hinge **L** FLAT against the hinge plate **K** as you slide it across as far as it will go. Tighten screw A.

c: The hinge **L** must be flat against the hinge plate **K** prior to any adjustment.

d: The hinge **L** must NOT be AT AN ANGLE to the hinge plate **K** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **M a** to the door **9** using 2 screws **M b**.



Assembly Instructions

Step 22

Adjust the doors if needed

a: Height adjustment.


Loosen screws A on hinge plates and move door up or down as required.
Retighten screw A.

b: Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required.
Retighten screw B.

c: Sideways adjustment.


To move door 'out' loosen screw C.
To move door 'in' tighten screw C



Step 23

Fit the door buffers to both doors

Stick a door buffer **J** onto each corner of the door **9** so that they hit the edge of the side panel when the door is closed.



Assembly Instructions

Step 24

Sink Care, Maintenance and Assembly Instructions

Your sink is made of the finest quality stainless steel (CrNi 18/10), DIN1.4301 or AISI 304 (suitable for food contact).

Keep your sink looking as good as new by following the care and maintenance instructions.

Instructions

For everyday cleaning of the sink, use household detergents suitable for stainless steel. After each use, rinse the sink with warm water then wipe with a soft dry cloth.

- Do not use wire wool.
- Do not use chemical 'silver cleaners', bleaches or detergents containing chlorine or any of its derivatives.



Warning!

- If the sink comes into contact with acidic materials, rinse immediately with plenty of water and wipe with a soft, dry cloth.
- Do not leave rusty objects in contact with the sink. Rust can cause staining, cracking or even permanent damage to the sink surface.
- To avoid staining of the surface do not leave food or other materials with corrosive properties such as juices, salt, vinegar, mustard etc. on the sink for a long time.
- Do not place very hot objects directly on the sink. Place them on a special surface (board) made from wood or plastic etc.
- Avoid scraping the sink basin or draining board with utensils.
- Avoid dropping heavy or sharp objects onto the sink surface.

Step 25

Fit the seal tape

Adhere the seal tape around the underside of the edge of the sink, being careful to lay it smoothly (without ridges).





Step 26


Fit the anchor braces

Place the anchor braces vertically and pull them up to lock into their horizontal position.

Also refer to step 27.



NOTE: Do not attach the anchor brace which will be positioned at the front middle of the unit.



Assembly Instructions

Step 27

Secure the sink to the top.

These anchor braces are designed for use with counter tops 30-40mm thick (a).

If your counter top is thinner, you may need to insert wooden wedges between the counter top and the braces so as to secure them (b).

After placing two at each corner of the sink, place the rest evenly spaced around the perimeter of the sink.

It is advisable to screw the wooden wedges into the underside of the counter top to avoid any movement when tightening the anchor braces. Please take care that the length of the screw used is **5mm less than** the counter top and wooden wedge put together.




Tighten the screws of the anchor braces (with a hand screwdriver), to secure the sink in place.

If you are unsure about plumbing, please consult a qualified plumber.



Warning: The unit is heavy. Lift with care.

Assembly is complete



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

