

BOOST

BALANCE BIKE



PARTS LIST




1. FRAME



2. FRONT WHEEL SET



3. HANDLEBAR SET



4. WRENCH TOOL

EASY ASSEMBLY




STEP 1

Insert the front wheel set (2) through the frame's (1) steering tube as shown above.



STEP 2

Using the wrench (4) provided, remove screw and nut from the handlebar (3) and insert handlebar (3) into front wheel set (2) post as shown above.



STEP 3

Aligning the post openings of the assembled handlebar (3) and front wheel set (2), insert the screw through the post openings securely attaching the nut as shown above.

Lock in place the black protective covering to the upper black cup fixed to the steering tube.

MAINTENANCE

Wipe with a damp cloth using mild detergent and water only to remove dirt and dust.

Dry thoroughly before use. Do not use industrial cleaners or solvents that may damage the surface.

Routinely check that all parts are securely fastened and are in good working condition before each use. Replace worn or broken parts immediately.

Do not leave this product in high temperature, intense sunlight or dusty areas. Store in a dry place.

No modification other than to the manufacturer's instructions should be made.

WARNINGS

- When unpacking the Boost Bike, properly dispose of all plastic wrappings, and keep them away from children.
- Adult supervision is strongly recommended at all times.
- The Boost Bike should only be used by children ages 12+ months.
- Never use the Boost Bike near steps, swimming pools, other bodies of water.
- Never use the Boost Bike on sloped driveways and hills or rough or uneven surfaces. For use on smooth paved surfaces only. Keep away from motor vehicles.
- Avoid sharp bumps, drainage grates, and sudden surface changes. Bike may suddenly stop. Avoid streets and surfaces with water, sand, gravel, dirt, leaves, and other debris.
- The Boost Bike has no brake system. The rider should stop the bike with his or her feet.
- Never use the Boost Bike in wet or icy conditions, at night or at times of limited visibility.
- Always wear proper protective gear such as an approved helmet and elbow and knee pads. Failure to wear an approved helmet may result in serious injury or death.
- Always wear closed-toe shoes when riding the Boost Bike.
- Never allow more than one child to ride the Boost Bike at any time.
- The maximum load should not exceed 20kg.

CUSTOMER HELPLINE

Hy-Pro advise you to contact us directly and not to return this item to the place of purchase. Hy-Pro has taken great care to ensure this item has reached you in good condition, should you have a query please ring our helpline +44 (0)800 731 0006 where your call will be dealt with promptly. Alternatively please call us on email: customerservices@zinchq.com



*PLEASE RETAIN FOR FUTURE REFERENCE
COLOUR & CONTENTS MAY VARY FROM THOSE SHOWN ON PACKAGING.

HY-PRO®
LU5 5BN, UK

Hy-Pro House, Centrus Park
Arenson Way, Dunstable,
Bedfordshire LU5 5BN.
United Kingdom

Hy-Pro Asia
Room 1011, 10/F, Peninsula Centre,
67 Mody Road, Kowloon, Hong Kong.

Hy-Pro Europe
Cube Building, Monahan Road,
Cork, T12H1XY, Republic Of Ireland.

Customer Care Line
Tel: +44 (0) 800 731 0006
www.hy-pro.co.uk
www.zincsports.com

